

VS65

SOFTWARE AND PROGRAMMING MANUAL



MEDIUM VOLTAGE SOFT STARTER



MEDIUM VOLTAGE SOFT STARTER

Medium Voltage Soft Starter
Programming and Software Manual

Edition: May 2021

VS65MTSW01FI Rev. F

SAFETY SYMBOLS

Always follow safety instructions to prevent accidents and potential hazards from occurring.

In this manual, safety messages are classified as follows:

	WARNING	Identifies potentially hazardous situations where dangerous voltage may be present, which if not avoided, could result in minor personal injury, serious injury or death
		Be extremely careful and follow the instructions to avoid the risk of electrical shocks.
	CAUTION	Identifies potentially hazardous situations, which if not avoided, could result in product damage, or minor or moderate personal injury.
		Read the message and follow the instructions carefully.
	NOTICE	Identifies important measures to take in order to prevent damage equipment and warranty lost, as well as encouraging good use and environmental practices.

The following CAUTION symbols are used in this manual and they symbolise:

	Hot surface. Be careful and follow the instructions to avoid burns and personal injuries.
	Risk of fire. Be careful and follow the instructions to prevent causing an unintentional fire.

REVISION CONTROL		
DATE	REVISION	DESCRIPTION
12 July 2012	A	First Edition
14 March 2013	B	Digital Inputs update and default values revision
02 June 2015	C	Remote control functions and Modbus addresses summary
07 June 2017	D	Software version clarification
10 October 2017	E	Modbus address clarification
06 May 2021	F	Internal revision.

The equipment and technical documentation are periodically updated. Power Electronics reserves the right to modify all or part of the contents of this manual without previous notice. To consult the most updated information of this product, you may access through our website www.power-electronics.com, where the latest version of this manual can be downloaded.

TABLE OF CONTENTS

1. DISPLAY UNIT AND CONTROL KEYPAD	9
1.1. LCD Screen	9
1.2. Control Keypad	9
1.3. Start and Stop-Reset Buttons	10
2. STATUS MESSAGES	11
3. GENERAL INFORMATION SCREENS	12
4. PARAMETERS DESCRIPTION	13
4.1. Group 1 – G1: MENU OPTIONS.....	13
4.2. Group 2 – G2: NAMEPLATE	13
4.3. Group 3 – G3: PROTECTIONS	14
4.4. Group 4 – G4: ACCELERATION	16
4.5. Group 5 – G5: DECELERATION	17
4.6. Group 6 – G6: INPUTS	18
Local Jog V/S.....	18
Not available for this soft starter mode.....	18
4.7. Group 7 – G7: OUTPUTS.....	20
4.8. Group 8 – G8: DUAL SETTING	21
4.9. Group 10 – G10: FAULT HISTORY	24
4.10. Group 11 – G11: STATISTICS	24
4.11. Group 14 – G14: SERIAL COMMUNICATION	25
4.12. Group 15 – G15: AUTO RESET	25
4.13. Group 16 – G16: PUMP CONTROL	26
5. MODBUS COMMUNICATION	27
5.1. Modbus Protocol.....	27
5.2. Modbus Series Communication Installation Ref: E0004 VS65 Series	27
5.3. Supported Modbus Function Codes.....	27
5.3.1. Modbus Function Code n°3. Registers reading.....	28
5.3.2. Modbus Function Code n° 16.Writing Registers.....	29
5.4. Remote Control Functions	30
5.5. Summary of Modbus Addresses	30
5.5.1. Modbus Register 'GENERAL STATUS'	30
5.5.2. General Information Screens	31
5.5.3. Programming Parameters	31
6. FAULT MESSAGES. DESCRIPTION AND ACTIONS	34
7. TYPICAL CONFIGURATION	38
7.1. Start	38
7.2. Stop	38
8. CONFIGURATION REGISTER	39
DECLARATION OF CONFORMITY CE	43

SAFETY INSTRUCTIONS

IMPORTANT!

Read carefully this manual to maximize the performance of the product and to ensure its safe use.

In order to appropriately use the drive, please, follow all instructions described in the installation manual which refer to transportation, installation, electrical connection and commissioning of the equipment.

Power Electronics accepts no responsibility or liability for partial or total damages resulting from incorrect use of equipment.

Please, pay careful attention to the following recommendations:

 WARNING	 CAUTION	 NOTICE
<p>DANGEROUS VOLTAGE</p> <p>The medium voltage soft starters have dangerous voltages when connected to line voltage. Install and maintenance operations should be carried out by qualified personnel only.</p> <p>An improper motor or soft starter installation may cause faults in the equipment, serious injuries including death. Follow carefully the instructions given in the manual, the national electric codes and updated local codes.</p>	<p>SHORT CIRCUIT</p> <p>Medium Voltage soft starters are not tested against short circuits.</p> <p>In case of a severe overload or short circuit, the soft starter should be completely tested to keep the equipment in working order.</p>	<p>GENERAL PROTECTIONS AND EARTH GROUNDING.</p> <p>The installer or user is responsible to provide a proper soft starter earthing system and a complete protections system in accordance with the national electric codes and updated local codes.</p>



WARNING

Read carefully this manual and follow the instructions before proceeding.

All of the safety instructions would not cover every single potential equipment cause. However, the most common and important ones have been pointed out. The installer should follow the instructions described within the manual, provide quality electric work and localise all of the recommendations and warnings provided before starting the equipment.

Make sure the soft starter is completely disconnected from the power supply and earth grounded before any use or maintenance operation is carried out.

Check the maintenance section before proceeding. In order to prevent electric risks, disconnect the power supply input, earth ground the equipment and remove the control voltages before working in the equipment. Warning and safety labels should be properly placed in terminals, covers and control panels in accordance with local codes. Otherwise, electric shock hazard exists.

Do not connect any kind of power supply to the equipment while the doors are opened.

Totally prohibited to run the soft starter with the doors opened.

Once doors are properly closed, the power supply may be connected to the equipments power supply line. Otherwise, electric shock hazard exists.

Do not open the soft starter doors except for periodic inspections, wiring the unit even when the input voltage is not connected.

Otherwise, you may suffer an electric shock.

Operate the drive with dry hands.

Otherwise, you may get an electric shock.

Do not use cables with damaged insulation.

Otherwise, you may get an electric shock.

Do not subject the cables to abrasions, excessive stress, heavy loads or pinching.

Otherwise, you may get an electric shock.

Power factor compensation capacitors. (Optional)

The reactive compensation capacitors used to increase the power factor should be connected to the soft starter input terminals and not to the output ones. These capacitors should be connected with an additional contactor as shown in the electric connections section. The connection will be done only when the soft starter is running and it will be disconnected during the acceleration and deceleration ramp.

Otherwise, the soft starter can be damaged.

When working in electric installations always remember to apply the 5 golden rules:

1. Visible cut of all the voltage sources.
 2. Mechanic lock of every single cut elements.
 3. Verify no voltage is present.
 4. Earth ground and short circuit any possible voltage source.
 5. Define and post sign the working area.
-

CAUTION

Place the soft starter over non-flammable surface. Keep away from flammable materials.

Otherwise, fire risk existence.



Disconnect and earth ground the soft starter power input when the soft starter is damaged.

Otherwise, fire and secondary accident risk existence.

Keep clean the equipment, not allowing lint, paper, wooden chips, dust, metallic chips or other foreign matter (screws, pressure washers...) into the soft starter. Verify this point after the installation.

Otherwise, accident and fire risk existence.



After applying input voltage or after removing it, the soft starter will remain warm for a couple of minutes.

Otherwise, body injury or skin burn risk existence.



Do not apply voltage to a damaged or soft starter with parts missing even if the installation is complete.

Otherwise, electric shock hazard existence.

Do not exchange the soft starter input and output power connections.
Otherwise, excessive voltage could be found in the logic control circuit.



NOTICE

RECEPTION

- The soft starters are carefully tested and perfectly packed before delivering.
 - In the event of transport damage, please ensure to notify the transport agency and POWER ELECTRONICS: 902 40 20 70 (International +34 96 136 65 57), or your nearest agent, within 24hrs from receiving the goods.
-

UNPACKING

- Make sure model and serial number of soft starter are the same on the box, delivery note and unit.
 - Each soft starter is delivered with Hardware and Software technical manuals.
-

RECYCLING

Packaging equipment must be recycled. Separate all different materials (plastic, paper, cardboard, wood...) and place them in the corresponding containers. Ensure waste collection is properly managed with a Non-Hazardous Waste Agent.



To guarantee health and natural environmental sources protection, the European Union has adopted the WEEE directive concerning discarded electric and electronic equipment (SEEA).

Waste of electrical and electronic equipment (WEEE) must be collected selectively for proper environmental management.

Our products contain electronic cards, capacitors and other electronic devices that should be separated when they are no longer functional. These WEEEs should be managed accordingly with a Hazardous Waste Agent.

Power Electronics promotes good environmental practices and recommends that all its products sold outside of the European Union, once they reach the end of their life, are separated and the WEEE managed according to the particular country applicable legislation (especially: electronic cards, capacitors and other electronic devices).

If you have any questions about the electric and electronic equipment waste, please contact Power Electronics.

SAFETY

- Before starting the soft starter, read this manual completely to gain an understanding of the unit. In case of doubt, please contact Power Electronics (902 40 20 70 / +34 96 136 65 57) or your nearest agent.
- Wear safety goggles when operating the soft starter with voltage.
- Handle the equipment in accordance with the soft starters' weight.
- Proceed with the installation according to the instructions found in this manual.
- Do not stack the soft starter or place heavy objects on the soft starter.
- Ensure that the soft starter is correctly installed considering the recommendations within this manual.
- Do not drop the soft starter or to impact exposure.
- The VS65 Series soft starters contain static-sensitive printed circuit boards. Use static safety procedures when handling boards.

Avoid installing the soft starter in different conditions from those described in the Technical Characteristics section.

COMMISSIONING

- Before commissioning the soft starter, the user must read carefully this manual and pay particular attention to the connection and start sections.
 - Verify all of the parameters and make the necessary settings before starting the equipment. Depending on load and applications, the parameter values can be changed.
-


- Voltage and current levels applied in terminals as external signs should be in accordance with the manual data. Otherwise, the soft starter could be damaged.

GROUND CONNECTIONS

- Electric shock prevention:

The soft starter locker chassis must be properly earth ground connected to prevent a possible electric shock even when a leakage current flows through the locker. Disconnect all of the voltage supplies before proceeding with maintenance operations within the soft starter or motor.

- In case the equipment is provided with Power Factor Corrector, due to the existence of capacitors in the power section, the equipment will keep dangerous voltage even when the input voltage is disconnected. Use a cable to earth-ground it and discharge the existing voltage.
- Only connect the earth grounding to the soft starter earth plate. Do not use the case or the chassis screw for grounding.
- The earth protection cable must be connected first and disconnected last.
- The motor earth grounding will be connected to the soft starters' one and not to the installations one.
- The installations earth grounding will be connected to the soft starters' one.
- Equipment input cables are medium voltage cables. As shown in the figure, they are coaxial cables, each one including earth. To carry out with a correct connection it is necessary to join every phase's earth and connect it to the soft starters' earth plate.
- The output cables to the motor have the same characteristics. Their earths should also be joined and connected to the soft starters earth plate **IN THE SAME TERMINAL** than the input cables.



1.DISPLAY UNIT AND CONTROL KEYPAD




Figure 6.1 Display Unit

1.1. LCD Screen

The soft starters display has a two lined Display screen with sixteen characters per line (16 x2). Each line has different functions.

- **STATUS LINE (Upper):**

Always present and shows the soft starter status (COMMS/SLOW.S), the phase current and the voltage in the Medium Voltage line.

- **CONTROL LINE (Lower):**

Set the different soft starter parameters.

1.2. Control Keypad



and

To scroll between screen groups.



Press to unfold the screen groups.



and



Inside the group, to scroll to reach the parameter.



and




or



Press simultaneously to set the screen.



Used to exit screen groups until the group name is reached.



VS65DTC0007AI

Figure 6.2 Programming example

1.3. Start and Stop-Reset Buttons

The VS65 soft starter has two Start, Stop-Reset / Jog Slow Speed buttons available with which the following operations can be carried out:



Start



Soft starter Stop and Rearth

2. STATUS MESSAGES




Figure 7.1 Display Status Messages

Visualisation	Name	Description
RDY	READY	Equipment ready to run.
ITQ	INITIAL TORQUE	The soft starter is applying the initial torque shown in [G4.4] during the specified time given in [G4.5].
ACL	ACCELERATING	Motor accelerating phase.
RUN	RUNNING	The soft starter runs at nominal speed, after completing the accelerating ramp. (Input voltage = Output Voltage).
DEC	DECELERATING	Motor decelerating phase.
HAM	HAMMER	The hammer hit decelerating algorithm is running.
UNV	UNDER VOLTAGE	Under power voltage warning.
OVV	OVER VOLTAGE	Over power voltage warning.
OVL	OVERLOAD	Overload warning.
UDL	UNDERLOAD	Underload warning.
OVT	TEMPERATURE FAULT	Excessive temperature in the soft starter.
SHP	SHEARPIN	Shearpin current.
ASY	ASYMMETRIC CURRENT	Motor asymmetric current.
FLT	FAULT	Fault in soft starter produced.
STD	START DELAY	The soft starter is waiting the time given in the parameter [G4.1]. Start delay.
EXT	EXTERNAL FAULT	Fault status due to an external fault caused by a digital input.
P/T	TORQUE PULSE	The soft starter applies torque pulse configured in the parameter [G4.2] Torque pulse during the time given in parameter [G4.3] Torque pulse time.
ILT	CURRENT LIMIT	The soft starter has reached the maximum current consumption in accordance with the parameter [G4.7] Limit acceleration current.
HIP	OVER PRESSURE	Overpressure warning during the time settled in parameter [G16.4]
LOP	UNDER PRESSURE	Under pressure warning during the time settled in parameters [G16.5] and [G16.6].
NOF	NO FLOW	Cavitations warning during the time settled on screens [G16.7] and [G16.8].
LWA	LOW LEVEL	Water low level warning during the time settled on screen [G16.9].

3. GENERAL INFORMATION SCREENS

On the display lower line it is possible to visualise the general programming information screens (G1 to G16), which include all the information related to the motor and the equipment.

Screen	Description	Range	Units	Attribute	Function																	
800A 800A 800A	L1, L2 and L3 phase current	0 to 9999			Phase current. Shows the input three phases instantaneous current																	
6000V6000V6000V	L1-L2, L2-L3, L1-L3 Line voltage	0 to 999	-	-	Line voltage. Show the input soft starter voltage between phases																	
50Hz Cos=0.85	Supply frequency	0 to 99Hz	-	-	Supply frequency / Motor phi cosine. Show the supply frequency and the motor phi cosine. Note: This screen can only be visualised after the soft starter has completed the start.																	
	Motor Phi cosine	0 to 1																				
7200kW Pr=99%	Power consumption	1 to 900kW	-	-	Shows the power consumption and the axis torque. Note: This screen can be only visualised when the motor is running.																	
	Axis torque	0 to 999%																				
RELAYS 0 0 0	1, 2 and 3 Relay Status	0 – Open X – Closed	-	-	Shows the 1, 2 and 3 relay status.																	
DIG INPUT= 0 0 0 0 0 F	Digital Inputs status and Motor PTC status	0 – Open X – Closed K – Correct F – Fault	-	-	The first five digits refer to the digital input and the sixth one to the PTC temperature probe input. <table border="1" data-bbox="963 819 1372 1025"> <thead> <tr> <th>Input</th> <th>Terminal</th> <th>Range</th> </tr> </thead> <tbody> <tr> <td>Digital Input 1</td> <td>T11</td> <td rowspan="5">0: Open X: Closed</td> </tr> <tr> <td>Digital Input 2</td> <td>T12</td> </tr> <tr> <td>Digital Input 3</td> <td>T13</td> </tr> <tr> <td>Digital Input 4</td> <td>T14</td> </tr> <tr> <td>Digital Input 5</td> <td>T15</td> </tr> <tr> <td>Not used</td> <td>T16-T17</td> <td>K: Correct F: Fault</td> </tr> </tbody> </table>	Input	Terminal	Range	Digital Input 1	T11	0: Open X: Closed	Digital Input 2	T12	Digital Input 3	T13	Digital Input 4	T14	Digital Input 5	T15	Not used	T16-T17	K: Correct F: Fault
Input	Terminal	Range																				
Digital Input 1	T11	0: Open X: Closed																				
Digital Input 2	T12																					
Digital Input 3	T13																					
Digital Input 4	T14																					
Digital Input 5	T15																					
Not used	T16-T17	K: Correct F: Fault																				
O/L STATUS=0%	Motor Overload status	0 to 100%	-	Read only	When the motor current is smaller than the overload value introduced on screen [G3.2], the Overload Status is 1%. However, when the current increases over the overload value, the Overload Status factor increases, faster as the difference between values increases. When the Overload Status factor reaches 100%, the soft starter will "trip" due to F4.																	
AI1=0.00mA = 0%	Analogue Input 1 status	0-10V 4-20mA 0-20mA	V or mA User Units	Read only	When shown in mA the user has selected 0 or 1 on the [G6.8] screen. When shown in V, the user has selected option 2 on the [G6.8] screen. The following value will have BAR, °C, m, % units depending on the selection made on [G6.10] Screen.																	
AI2=0.00mA = 0%	Analogue Input 2 status	0-10V 4-20mA 0-20mA	V or mA User Units	Read Only	This screen shows the analogue input 2 in V or mA, depending on the configuration chosen on screen [G6.11] and the units the user has configured on screen G6.13 and the scale selected on screen [G6.12].																	
AO1=0.00mA =0%	Analogue Output 1 status	0-20mA 4-20mA	mA and %	Read Only	Show the output analogue 1 value, in real values and percentage over the analogue output range.																	
S/W 2.62 H/W 2.1	Software y Hardware revision	-	-	-	Shows the soft starter's Software (S/W) and Hardware (H/W) revision.																	

4. PARAMETERS DESCRIPTION

The different VS65 parameters are grouped due to functionality in groups (G1 to G16). To access these screens we will press the [*] key. Once the parameter has been selected, it may have a numeric value or a list of possible functions.

4.1. Group 1 – G1: MENU OPTIONS

Screen & Default Value	Name / Description	Range	Function						
1 LOCK PARAM=NO	G1.1 / Soft starter lock parameters	Yes No	Enables to lock the soft starter parameters. This lockage is effective introducing on screen [G1.2] a password. Activating the parameter lock we would not be able to modify any screen group [G1-G16]. However, we would be able to visualise any group screen.						
2 PASSWORD= 0	G1.2 / Programming mode password.	OFF, 0000 to 9999	Enables the user to introduce a password to prevent non authorised programming parameter modifications. To proceed with the setting, once [1 LOCK PARAM=YES] selected, this screen will appear automatically requesting the password: PASSWORD=XXXX To unlock the soft starter programming, follow the instructions: Access group [1 LOCK PARAM=YES] and press (+). [2 PASSWORD=XXXX] will appear on screen, where the previous password should be entered.						
3 WRONG P/W=XXXX	G1.3 / Password recovery	000 to 9999	Provides information for the lock password recovery according to the expression: PASSWORD = (WRONG PW/2)-3						
4 LANGUE=ENGLISH	G1.4 / Operating language selection	ENGLISH ESPANOL DEUTSCH	Establish display language. It would be effective after disconnecting and connecting the input power supply.						
5 INITIALISE=NO	G1.5 / Initialisation	YES NO	Initialise the VS65 parameter default values. It would be effective after disconnecting and connecting the input power supply.						
6 COMMISSION=YES	G1.6 / Commissioning	YES NO	Screen groups deactivation. <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>YES</td> <td>Enables parameter setting</td> </tr> <tr> <td>NO</td> <td>Disables parameter setting but enables visualisation</td> </tr> </tbody> </table>	OPTION	FUNCTION	YES	Enables parameter setting	NO	Disables parameter setting but enables visualisation
OPTION	FUNCTION								
YES	Enables parameter setting								
NO	Disables parameter setting but enables visualisation								

4.2. Group 2 – G2: NAMEPLATE

Screen & Default Value	Name / Description	Range	Function
1 I STARTER = InA[*]	G2.1 / Soft starters rated current	1 to 1600A	Shows the soft starter rated current. It is necessary for the equipment to know this value when calibrating the different protections found in the VS65 device. The soft starters are handled with default settings. To modify the rated current press the [*] button during 5 seconds. Once the letter "I" has changed into "I" the current value can be modified.
2 I MOTOR=XXX[*]A	G2.2 / Motor plate current	1 to 1600A	States the motor rated current. To set the motor nameplate current, introduce this parameter in accordance with the motor nameplate.

* Value that depends on the soft starter rated current

Screen & Default Value	Name / Description	Range	Function																				
3 V MOTOR=4	G2.3 / VS65 input line voltage	1 to 4	<p>Set the work rated voltage Depending on the line voltage, there are two versions of this parameter, one for voltages from 2300V to 6600V and another from 6600V to 13800V.</p> <p>From 2300 to 6600V: (Software VS65_R2.62)</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>2300V</td> </tr> <tr> <td>2</td> <td>3000 - 3300V</td> </tr> <tr> <td>3</td> <td>4160V</td> </tr> <tr> <td>4</td> <td>6000 - 6600V</td> </tr> </tbody> </table> <p>From 6600 to 13800V: (Software VS65_R2.68)</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>6600V(**)RESERVD</td> </tr> <tr> <td>2</td> <td>10000V</td> </tr> <tr> <td>3</td> <td>11000V</td> </tr> <tr> <td>4</td> <td>13800V</td> </tr> </tbody> </table> <p>Introduce this parameter in accordance with the VS65 input line voltage. Make sure the motor plate voltage is within the related voltage range.</p>	OPT.	DESCRIPTION	1	2300V	2	3000 - 3300V	3	4160V	4	6000 - 6600V	OPT.	DESCRIPTION	1	6600V(**)RESERVD	2	10000V	3	11000V	4	13800V
OPT.	DESCRIPTION																						
1	2300V																						
2	3000 - 3300V																						
3	4160V																						
4	6000 - 6600V																						
OPT.	DESCRIPTION																						
1	6600V(**)RESERVD																						
2	10000V																						
3	11000V																						
4	13800V																						
4 P MOTOR =XXXkW[*]	G2.4 / Motor Power Plate	4 to 999kW	Set the motor power.																				
5 COS PHI M =85%	G2.5 / Motor Phi cosine	40 to 99%	Set the Motor Phi cosine.																				
6 FREQ= 50Hz	G2.6 / Supply frequency	50Hz 50/60Hz	<p>States the motor supply frequency. Set this parameter to 50Hz where the frequency supply is 50Hz. Within the installations where this value is unknown or 60Hz, set to 50/60Hz. Note: When 50/60Hz is selected, the soft starter starts an algorithm to detect the line frequency. When 50Hz selected, it remains inactive.</p>																				

[*] Value that depends on the soft starter rated current.

[**] Not used setting, only for testing purposes.

4.3. Group 3 – G3: PROTECTIONS

Screen & Default Value	Name / Description	Range	Function								
1 PHASE SEQUEN=2	G3.1 / Phase sequence at the soft starter input	1 to 3	<p>This parameter establishes which input phase sequence is considered valid. In case a start order is received, the equipment will trig due to F2 WRONG PH/SQ.</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>NO SEQ PROTEC</td> </tr> <tr> <td>2</td> <td>L1 L2 L3 SEQ</td> </tr> <tr> <td>3</td> <td>INVERT SEQUE</td> </tr> </tbody> </table> <p>To set the soft starter input phase sequences. Set depending on the sequence. Note: When operating at Slow Speed, or DC-Brake, an operating sequence must be chosen, it is not possible to work WITHOUT A PROTECTION SEQUENCE [1 NO PROTEC SEQ].</p>	OPT.	DESCRIPTION	1	NO SEQ PROTEC	2	L1 L2 L3 SEQ	3	INVERT SEQUE
OPT.	DESCRIPTION										
1	NO SEQ PROTEC										
2	L1 L2 L3 SEQ										
3	INVERT SEQUE										
2 OV LOAD=InA	G3.2 / Motor overload current	(0.6 to 1.5)·In of the VS65	<p>States the current value at which the equipments overload protections should activate. The trigger time will depend on the exceeding current level set on this screen and the value set on the screen [G3.3] Before setting, look for the motor plate current reference and introduce the value on screen. Note: See figure in parameter [G3.3].</p>								

Screen & Default Value	Name / Description	Range	Function
3 OV/LOAD T=5	G3.3 / Overload curve	1 to 10	<p>The overload curve determines the response time under overload conditions. There is a non-linear relation between the overload parameter [G3 OV LOAD] and this parameter, in order to set the time required for tripping on F4 OVERLOAD. If [3 OV/LOAD T =1] is selected then the response time for an overload condition is almost immediate, but if [OV/LOAD T=10] then takes the soft starter trips on F4 OVERLOAD after a time delay.</p> <p>Setting when a fast response is needed under overload conditions, please select [OV/LOAD T =1]. When a slow response is needed, select [OV/LOAD T =10]. For normal operation leave this value as default [OV/LOAD T =5].</p> <p>The response time for the overload protection can be calculated from the following curve:</p>
4 OVL FAC=100%	G3.4 / Starting Overload Factor	100 to 500%	<p>The parameter function is to increase the overload curve during acceleration. Recommended to start loads with elevated torque momentum. Once the nominal rate is reached, this parameter deactivates and the overload protection will function as it has been explained in [G3.2] and [G3.3]. Adjust the default (100%) value for low inertia applications like pumps, fans (Torque = K x Speed²). Mills, crushers and centrifuges (high inertia moment) will normally require a start with low starting overload factor (150%) and increase this value until the load accelerates without tripping on F4 OVERLOAD.</p> <p>This parameter is set in % [G3.3] Overload Curve.</p>
5 MOTOR PTC=-	G3.5 / Enable/Disable PTC motor option	-	Not used for this soft starter model.
6 UNLOAD=0.0A	G3.6 / Under load current	(0 a 0.9)·In of VS65	<p>Underload current determines the current level the motor must not operate below. Leave the adjustment to 50% of the nominal current of the motor.</p> <p><u>Applications:</u> This protection helps to detect mechanical problems such as broken shafts, belts, when this occurs, the motor will run under no load conditions.</p> <p>When working with pumps, this protection helps to detect no load pump operation, due to a lack of water or pump input pipe water position.</p>
7 UNLOAD T=OFF	G3.7 / Under load delay	0 to 99s, OFF	<p>This parameter sets the maximum allowable operation time under load conditions before tripping.</p> <p>The setting depends on the application, but should be set to trip as soon as a condition occurs.</p> <p><u>Applications:</u> Pumps, fans.</p>
8 SHEARPIN=OFF	G3.8 / Shearpin current	(0.6 to 1.2)·In of VS65, OFF	<p>The soft starter will stop immediately when the current drawn by the motor reaches this value during normal operation. This parameter is off during acceleration or deceleration. The stop should be done in a controlled way.</p> <p>Set the current value to stop the VS65.</p> <p><u>Application:</u> Oversized electrical motors used for starting, but working under nominal conditions at running, may only reach the Shearpin current because of mechanical problems locked rotors, etc.</p>

E
N
G
L
I
S
H

Screen & Default Value	Name / Description	Range	Function						
9 ASYM I ENB=Y	G3.9 / Asymmetrical current	Y N	Enable/Disable the asymmetric current protection at the soft starter <table border="1"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>Y=YES</td> <td>When enabled, the soft starter will trip on F3 ASYM CURR if there is a current imbalance greater than 40%.</td> </tr> <tr> <td>N=NO</td> <td>Protection disabled.</td> </tr> </tbody> </table>	OPTION	FUNCTION	Y=YES	When enabled, the soft starter will trip on F3 ASYM CURR if there is a current imbalance greater than 40%.	N=NO	Protection disabled.
OPTION	FUNCTION								
Y=YES	When enabled, the soft starter will trip on F3 ASYM CURR if there is a current imbalance greater than 40%.								
N=NO	Protection disabled.								
10 UNDER V= -	G3.10 / Under voltage	1694 to 2178V @2300V 2431 to 3126V @3300V 3065 to 3941V @4160V 4421 to 5684V @6000V	To protect the motor or other equipment from low mains voltage. Low voltage will usually increase the motor current. Set the minimum tolerable level in conjunction with [11 Under voltage Delay].						
U/V DELAY=5s	G3.11 / Under voltage delay	0 to 10s, OFF	This parameter sets the maximum operation time for under voltage conditions before tripping. Set to maximum under voltage operation time allowed						
12 OVERVOLT= -	G3.12 / Over voltage	2421 to 2784V @2300V 3473 to 3994V @3300V 4378 to 5035V @4160V 6315 to 7263V @6000V	To protect the motor from high input voltage. Set the maximum level tolerable in conjunction with the [G3.13].						
13 O/V DELAY=5s	G3.13 / Over voltage delay	0 to 10s, OFF	This parameter sets the maximum operation time during over voltage conditions before tripping. Set to maximum over voltage operation time allowed						
14 START LIMIT=3	G3.14 / Maximum number of starts	1 to 10	Establish the maximum number of starts allowed before tripping on F12 EXCESIV STR. Set maximum number of starts allowed for the specified time at [15 START INTERVAL].						
15 STR/INT=15Min	G3.15 / Start interval	0 to 60Min, OFF	Establish the time allowed between the first and the last start in [14: START LIMIT] before tripping on F12 EXCESIV STR. Set the time limit for the maximum number of starts to occur. <u>Applications:</u> Mills, crushers, and applications where an excessive number of starts could damage the motor due to very high current during acceleration.						

4.4. Group 4 – G4: ACCELERATION

Screen & Default Value	Name / Description	Range	Function
1 STR DELAY=0s	G4.1 / Starting Delay	0 to 600s	Sets the time the VS65 will wait after a start command has been provided and acceleration will start. Adjust this value in accordance with the application.
2 PULS TORQ =50%	G4.2 / Torque Pulse	50 to 100%	Choose the torque pulse level applied to the motor for the time specified at [G4.3]. This value's setting must be done in conjunction with [G4.3] to initiate a first move of the motor.
3 PULS TQ T=OFF	G4.3 / Torque Pulse Time	OFF, 0.1 to 0.9s	Sets the time for the [2 PULS TORQ] to be applied.
INIT TORQ=35%	G4.4 / Initial Torque	30 to 99%	Establish the initial torque to be applied to the motor at the beginning of the ramp up. When adjusting, it is recommended to begin with a low initial torque value, normally default. Observe motor rotation immediately after start command. If the motor doesn't spin, machine torque requirement may be higher, and it may be necessary to increase this until the motor starts to turn normal after a start command has been applied. If a very high current is noticed at the very beginning of starting process, this could be due to an initial torque setting that is too high - this must be decreased until a proper value is achieved. <u>Applications:</u> For submerged pumps, generally a torque between 40% and 45% is required. For applications such as mills or crushers, the required torque is normally between 40% and 50%. Note: These values are typical adjustments. Each application requires individual settings to achieve the best performance.

Screen & Default Value	Name / Description	Range	Function
5 INIT TQ T=1s	G4.5 / Initial torque time	0 to 10s	Set the time for [3 INITIAL TORQUE] to be applied to the motor. To adjust the parameter when working with high inertia loads, increase the value in conjunction with parameter [4 INITIAL TORQUE], until the motor begins to turn. All other applications should leave this value as default. Applications: In pumps a usual value is 0, and in heavy load machines it can vary between 1 and 3 seconds.
<p style="text-align: right;">G4.1 Delay of the start G4.2 Torque pulse G4.3 Torque pulse time G4.4 Initial torque G4.5 Initial torque time G4.6 Acceleration time G5.2 Deceleration time</p> <p style="text-align: right;">DT0018D</p>			
6 ACEL TIME=6s	G4.6 / Acceleration Time	0 to 180s	Adjusts the motor acceleration time from standstill to nominal speed, provided that no current limit occurs as that will cause a longer acceleration time. Set depending on the application, the time set will vary in order to make sure no current limit takes place during acceleration. If this occurs, the acceleration time or acceleration current limit settings will need to be increased Applications: In submerged pumps, the usual acceleration time is between 4 and 8 seconds. With very high inertial loads, that can vary between 20 and 60 seconds. Note: These values are typical adjustments. Each application requires individual settings to achieve the best performance
7 I LIMIT=3.5In[*]	G4.7 / Current limit	(1.5 to 5)·In of VS65	Maximum current a motor can draw during the acceleration/deceleration. Set the maximum current a motor can draw during the acceleration/deceleration of the motor. Typically set to 2.5 to 3x nominal current of the motor. Values below 2 times of the motor rated current should be avoided. Under these conditions the resulting motor torque is normally insufficient to generate a successful start at full load; also the soft starter could trip on F4 Overload.

* Value that depends on the soft starter rated current

4.5. Group 5 – G5: DECELERATION

Screen & Default Value	Name / Description	Range	Function						
1 FREWEL STP=Y	G5.1 / Freewheel stop	Y N	Set the required stop mode. The stop could be controlled through a ramp down voltage or uncontrolled where the time to stop depends on the inertia of the load <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>Y=YES</td> <td>Freewheel stop enabled.</td> </tr> <tr> <td>N=NO</td> <td>Freewheel stop disabled.</td> </tr> </tbody> </table> To set controlled stop is select [1 FREWELSTOP=No], and [1 FREWELSTOP=Yes] for a spinning stop.	OPTION	FUNCTION	Y=YES	Freewheel stop enabled.	N=NO	Freewheel stop disabled.
OPTION	FUNCTION								
Y=YES	Freewheel stop enabled.								
N=NO	Freewheel stop disabled.								
2 DECL TIME=12s	G5.2 / Deceleration Time	1 to 180s	Establish the required time for a controlled stop. To set this parameter, firstly begin with a short time (10 or 15 seconds) and increase it until desired stop is achieved. If no satisfactorily results are obtained set hammer algorithm in [G5.3].						

E
N
G
L
I
S
H

Screen & Default Value	Name / Description	Range	Function						
3 DEC MD SEL=1	G5.3 / Motor Deceleration Algorithm	1 to 2	<p>In applications where it is necessary to avoid water hammer effect, select this algorithm. In other applications, the normal deceleration ramp is sufficient.</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>NORMAL CURVE.</td> </tr> <tr> <td>2</td> <td>HAMMER PREVENT.</td> </tr> </tbody> </table> <p>When setting applications with water hammer problems during deceleration, select the hammer algorithm. In other applications set normal deceleration algorithm. When selecting the hammer algorithm for the deceleration, 2 parameters must be set to properly adjust the stop. For correct adjustment of the deceleration time in applications with hammer problems it may be necessary to perform an interactive process by trial and error until the application is correctly commissioned.</p>	OPT.	DESCRIPTION	1	NORMAL CURVE.	2	HAMMER PREVENT.
OPT.	DESCRIPTION								
1	NORMAL CURVE.								
2	HAMMER PREVENT.								
4 HAMR FACT=75%	G5.4 / Hammer factor	1 to 99%	Set the time percentage for the hammer algorithm is to be active during deceleration						
5 MINI TORQ=1%	G5.5 / Minimum torque	1 to 60%	The minimum torque to be applied during deceleration (for Hammer Algorithm).						

4.6. Group 6 – G6: INPUTS

Screen & Default Value	Name / Description	Range	Function																		
1 OPER MODE=1	G6.1 / Control mode source	0 to 5	<p>Set the control mode of the soft starter</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disable</td> <td>No control source enabled. There is no way to Start/Stop-Reset the VS65.</td> </tr> <tr> <td>1</td> <td>Local</td> <td>Start/Stop-Reset enabled by keypad.</td> </tr> <tr> <td>2</td> <td>Remote</td> <td>Start/Stop-Reset enabled by digital inputs.</td> </tr> <tr> <td>3</td> <td>Serial Comms</td> <td>Start/Stop-Reset enabled by serial comms.</td> </tr> <tr> <td>4</td> <td>Local Jog V/S</td> <td>Not available for this soft starter mode.</td> </tr> </tbody> </table> <p>Note: In the case of making equipment reboot, the control mode will be LOCAL as default value, independently of the control mode established previously. From the Serial Comms option, user can take a look at the parameters but cannot make STARTS, STOPS or RESETS.</p>	OPT.	DESCRIPTION	FUNCTION	0	Disable	No control source enabled. There is no way to Start/Stop-Reset the VS65.	1	Local	Start/Stop-Reset enabled by keypad.	2	Remote	Start/Stop-Reset enabled by digital inputs.	3	Serial Comms	Start/Stop-Reset enabled by serial comms.	4	Local Jog V/S	Not available for this soft starter mode.
OPT.	DESCRIPTION	FUNCTION																			
0	Disable	No control source enabled. There is no way to Start/Stop-Reset the VS65.																			
1	Local	Start/Stop-Reset enabled by keypad.																			
2	Remote	Start/Stop-Reset enabled by digital inputs.																			
3	Serial Comms	Start/Stop-Reset enabled by serial comms.																			
4	Local Jog V/S	Not available for this soft starter mode.																			
2 LOCAL RESET=Y	G6.2 / Local reset control	Y N	Enable local reset via keypad.																		

Screen & Default Value	Name / Description	Range	Function																																				
3 DINPUT1 SEL=4	G6.3 / Multifunction 1 input	0 to 10	Select the task of the digital input once it is active (X). <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>OPT.</th> <th>MODE</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not active</td> <td>The input left without effect.</td> </tr> <tr> <td>1</td> <td>Start</td> <td>Start command given through pushbutton.</td> </tr> <tr> <td>2</td> <td>Stop</td> <td>Stop command given through pushbutton.</td> </tr> <tr> <td>3</td> <td>Stop-Reset NC</td> <td>Stop/Reset command given through pushbutton.</td> </tr> <tr> <td>4</td> <td>Start-Stop</td> <td>Start command when contact is closed and stop command when contact is opened.</td> </tr> <tr> <td>5</td> <td>Reset NC</td> <td>The reset is done when the contact is closed.</td> </tr> <tr> <td>6</td> <td>Slow Speed +</td> <td>Not available.</td> </tr> <tr> <td>7</td> <td>Slow Speed -</td> <td>Not available.</td> </tr> <tr> <td>8</td> <td>DC Brake</td> <td>Not available.</td> </tr> <tr> <td>9</td> <td>Dual setting</td> <td>Selection of the Second Setting at G8.</td> </tr> <tr> <td>10</td> <td>External trip</td> <td>Fault will be generated when the contact is opened.</td> </tr> </tbody> </table>	OPT.	MODE	FUNCTION	0	Not active	The input left without effect.	1	Start	Start command given through pushbutton.	2	Stop	Stop command given through pushbutton.	3	Stop-Reset NC	Stop/Reset command given through pushbutton.	4	Start-Stop	Start command when contact is closed and stop command when contact is opened.	5	Reset NC	The reset is done when the contact is closed.	6	Slow Speed +	Not available.	7	Slow Speed -	Not available.	8	DC Brake	Not available.	9	Dual setting	Selection of the Second Setting at G8.	10	External trip	Fault will be generated when the contact is opened.
OPT.	MODE	FUNCTION																																					
0	Not active	The input left without effect.																																					
1	Start	Start command given through pushbutton.																																					
2	Stop	Stop command given through pushbutton.																																					
3	Stop-Reset NC	Stop/Reset command given through pushbutton.																																					
4	Start-Stop	Start command when contact is closed and stop command when contact is opened.																																					
5	Reset NC	The reset is done when the contact is closed.																																					
6	Slow Speed +	Not available.																																					
7	Slow Speed -	Not available.																																					
8	DC Brake	Not available.																																					
9	Dual setting	Selection of the Second Setting at G8.																																					
10	External trip	Fault will be generated when the contact is opened.																																					
4 DINPUT2 SEL=- [1]	G6.4 / Multifunction 2 input	0 to 10																																					
5 DINPUT3 SEL=- [2]	G6.5 / Multifunction 3 input	0 to 10																																					
6 DINPUT4 SEL=- [2]	G6.6 / Multifunction 4 input	0 to 10																																					
7 DINPUT5 SEL=- [2]	G6.7 / Multifunction 5 input	0 to 10																																					
8 ANI1 FORMAT =1	G6.8 / Analogue Input 1 Format	0 to 2	It configures the AI1 as voltage or current signal. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0-20mA</td> </tr> <tr> <td>1</td> <td>4-20mA</td> </tr> <tr> <td>2</td> <td>0-10V</td> </tr> </tbody> </table>	OPT.	DESCRIPTION	0	0-20mA	1	4-20mA	2	0-10V																												
OPT.	DESCRIPTION																																						
0	0-20mA																																						
1	4-20mA																																						
2	0-10V																																						
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Format 0-20mA Range 0-10bar Sensor Output 0-20mA</p> <p>0 bar 0% 6 bar 60% 10 bar 100%</p> </div> <div style="text-align: center;"> <p>Format 4-20mA Range 0-10bar Sensor Output 4-20mA</p> <p>0 bar 0% 5 bar 50% 10 bar 100%</p> </div> </div>		DT0028C																																					
9 AI1 RANGE 0_10	G6.9 / Analogue Input Range	0_0 to 0_999	Set according to the range of the connected transducer in absolute units.																																				
10 AI1 UNITS=OFF	G6.10 / Analogue Input 1 units	OFF, Bar, °C, Mtr	When OFF, is displayed in %.																																				
11 ANI2 FORMAT =1	G6.11 / Analogue Input 2 Format	0 to 2	It configures the AI2 as voltage or current signal. <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0-20mA</td> </tr> <tr> <td>1</td> <td>4-20mA</td> </tr> <tr> <td>2</td> <td>0-10V</td> </tr> </tbody> </table>	OPT.	DESCRIPTION	0	0-20mA	1	4-20mA	2	0-10V																												
OPT.	DESCRIPTION																																						
0	0-20mA																																						
1	4-20mA																																						
2	0-10V																																						
12 AI2 RANGE 0_10	G6.12 / Analogue Input 2 Range	0_0 to 0_999	Set according to the range of the connected transducer.																																				
13 AI2 UNITS=OFF	G6.13 / Analogue Input 2 units	OFF, Bar, °C, Mtr	When OFF, is displayed in %.																																				

[1] Set to "10 EXTERNAL TRIP" in the case of using a motor protection relay.

[2] Reserved for internal use.

4.7. Group 7 – G7: OUTPUTS

Screen & Default Value	Name / Description	Range	Function																		
1 REL1 SEL ON=14	G7.1 / Relay 1 control source selection	1 or 14	<table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>ALWAYS ON</td> <td>Relay is enabled.</td> </tr> <tr> <td>9</td> <td>General Fault</td> <td>Relay will be active a fault occurs.</td> </tr> <tr> <td>14</td> <td>INSTANTANEOUS</td> <td>ON at the beginning of the ramp up / OFF at the end of the ramp down. Figure [G7.3]</td> </tr> <tr> <td>15</td> <td>Bypass/React</td> <td>ON at the end of the ramp up / OFF at the beginning of the ramp down. Figure [G7.3]</td> </tr> </tbody> </table>	OPT.	DESCRIPTION	FUNCTION	1	ALWAYS ON	Relay is enabled.	9	General Fault	Relay will be active a fault occurs.	14	INSTANTANEOUS	ON at the beginning of the ramp up / OFF at the end of the ramp down. Figure [G7.3]	15	Bypass/React	ON at the end of the ramp up / OFF at the beginning of the ramp down. Figure [G7.3]			
OPT.	DESCRIPTION	FUNCTION																			
1	ALWAYS ON	Relay is enabled.																			
9	General Fault	Relay will be active a fault occurs.																			
14	INSTANTANEOUS	ON at the beginning of the ramp up / OFF at the end of the ramp down. Figure [G7.3]																			
15	Bypass/React	ON at the end of the ramp up / OFF at the beginning of the ramp down. Figure [G7.3]																			
2 REL2 SEL ON=15	G7.2 / Relay 2 control source selection	15																			
3 REL3 SEL ON=9	G7.3 / Relay 3 control source selection	9																			
			<div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid black; padding: 5px; width: 45%;"> <p style="text-align: center;">INSTANTANEOUS</p> </div> <div style="border: 1px solid black; padding: 5px; width: 45%;"> <p style="text-align: center;">BYPASS/REACT</p> </div> </div> <p style="text-align: right;">VS65DT0010AI</p>																		
4 ANALOG1 SEL=0	G7.4 / Analogue output 1 source selection	0 to 7	<p>Provides the ability to select the driving source of the Analogue output, from the following list.</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>UNUSED</td> </tr> <tr> <td>1</td> <td>MOTOR CURRENT</td> </tr> <tr> <td>2</td> <td>MOTOR POWER</td> </tr> <tr> <td>3</td> <td>MOTOR TORQUE</td> </tr> <tr> <td>4</td> <td>COSINUS PHI</td> </tr> <tr> <td>5</td> <td>INPUT VOLTAGE</td> </tr> <tr> <td>6</td> <td>ANALOG I 1 ECHO</td> </tr> <tr> <td>7</td> <td>ANALOG I 2 ECHO</td> </tr> </tbody> </table>	OPT.	DESCRIPTION	0	UNUSED	1	MOTOR CURRENT	2	MOTOR POWER	3	MOTOR TORQUE	4	COSINUS PHI	5	INPUT VOLTAGE	6	ANALOG I 1 ECHO	7	ANALOG I 2 ECHO
OPT.	DESCRIPTION																				
0	UNUSED																				
1	MOTOR CURRENT																				
2	MOTOR POWER																				
3	MOTOR TORQUE																				
4	COSINUS PHI																				
5	INPUT VOLTAGE																				
6	ANALOG I 1 ECHO																				
7	ANALOG I 2 ECHO																				
5 AO1 FORMAT=0	G7.5 / Analogue output format	0 to 1	<p>Select the electrical format of the Analogue output.</p> <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0-20mA</td> </tr> <tr> <td>1</td> <td>4-20mA</td> </tr> </tbody> </table> <p>Note: To obtain an analogue output of 0-10V, you should configure the analogue output format as 0-20mA and connect a resistor of 500 Ω, ¼ W and 1% between terminals 22 and 23.</p>	OPT.	DESCRIPTION	0	0-20mA	1	4-20mA												
OPT.	DESCRIPTION																				
0	0-20mA																				
1	4-20mA																				

Screen & Default Value	Name / Description	Range	Function
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Format 0-20mA Lower limit 0% Higher limit 100%/ 200%</p> </div> <div style="text-align: center;"> <p>Format 4-20mA Lower limit 0% Higher limit 100%/ 200%</p> </div> </div> <p style="text-align: right;">DT0034B</p>			
6 AO1 LOW=0%	G7.6 / Analogue Output low set point	0 to 500%	It scales de Analogue Output in order to get a better reading
7 AO1 HIGH=100%	G7.7 / Analogue Output high set point	0 to 500%	

4.8. Group 8 – G8: DUAL SETTING

Screen & Default Value	Name / Description	Range	Function						
1 DUALSETING=N	G8.1 / Dual Setting	Y N	<p>Enable/Disable a second adjustment for [G4] acceleration, [G5] deceleration and for the overload curve [G3.3].</p> <table border="1" style="margin-left: 20px;"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>Y=YES</td> <td>Dual setting enabled.</td> </tr> <tr> <td>N=NO</td> <td>Dual setting disabled.</td> </tr> </tbody> </table> <p>When a second parameter is required set select Dual Setting to Yes. This second adjustment is activated by one of digital inputs. <u>Applications:</u> Mills, crushers and any application that at a certain operation stage requires a harder/softer parameter set.</p>	OPTION	FUNCTION	Y=YES	Dual setting enabled.	N=NO	Dual setting disabled.
OPTION	FUNCTION								
Y=YES	Dual setting enabled.								
N=NO	Dual setting disabled.								
2 PLS TORQ2=50%	G8.2 / Dual setting Torque Pulse	50 to 100%	Choose the torque pulse level applied to the motor for the time specified at [G8.3] Set this value in conjunction with G8.3 to initiate a first acceleration of the motor.						
3 PLS TQ T2=OFF	G8.3 / Dual setting Pulse Time.	OFF, 0.1 to 0.9s	Sets the time for the torque pulse [G8.2] to be applied.						
4 INIT TRQ2 =30%	G8.4 / Dual setting Initial Torque	30 to 99%	Establish the initial torque to be applied to the motor at the beginning of the ramp up. When adjusting, refer to parameter [G4.4] for further information.						
5 T PAR INI2=1s	G8.5 / Dual setting Initial Torque Time	0 to 10s	Set the time for the initial torque [G8.4] to be applied to the motor. Proceeding with the adjustment, refer to parameter [G4.5] for further information.						
6 ACC TIME2=12s	G8.6 / Dual setting Acceleration time	0 to 180s	Adjust the motor acceleration time from standstill to nominal speed, provided that no current limit occurs as that will cause a longer acceleration time. The time setting depends on the application. Refer to parameter [G4.6] for further information.						
7 I LIMIT2 =3 InA[*]	G8.7 / Dual Setting current limit	(1.5 to 5)·In of VS65	Maximum current a motor can draw during the acceleration/deceleration. Set to determine the maximum allowed current consumption during the acceleration / deceleration. Refer to parameter [G4.7] for further information.						
8 FREWEL STP2=N	G8.8 / Dual setting Freewheel stop	Y N	Set the required stop mode. The stop could be controlled through a ramp down voltage or uncontrolled where the time to stop depends on the inertia of the load, the freewheel stop. Set "N" for a spinning stop, set Y, in case a controlled stop is required. Refer to parameter [G5.1] for further information.						

* Value that depends on the soft starter rated current

ENGLISH

Screen & Default Value	Name / Description	Range	Function								
9 DEC TIME2=12s	G8.9 / Dual setting deceleration time	0 to 180s	Establish the required time for a controlled stop. For this parameter adjustment, begin with a short time and increase it until desired stop is achieved. Refer to parameter [G5.2] for further information.								
10 DEC MD SEL2= 1	G8.10 / Dual setting deceleration mode selection	1 to 2	In applications where it's desired to avoid water hammer effect, select this algorithm. In other applications, the normal deceleration ramp is sufficient. <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>NORMAL</td> </tr> <tr> <td>2</td> <td>HAMMER PREVENT</td> </tr> </tbody> </table> When setting for applications with water hammer problems during deceleration, select the hammer algorithm. In other applications set normal deceleration algorithm. When selecting the hammer algorithm for the deceleration, 2 parameters must be set to properly adjust the stop. Percentage of time the hammer algorithm is active during the deceleration time. Minimum torque the motor must deliver during the stop. To correctly adjust the deceleration of such an application with hammer problems you may need to perform an interactive process by trial and error until the application is correctly commissioned.	OPT.	DESCRIPTION	1	NORMAL	2	HAMMER PREVENT		
OPT.	DESCRIPTION										
1	NORMAL										
2	HAMMER PREVENT										
11 HAMR FAC2=75%	G8.11 / Dual setting hammer factor	1 to 99%	Set the percentage of time for the hammer algorithm is to be active during deceleration. It is set in % of the deceleration time of the motor [G8.9].								
12 MINI TRQ2=1%	G8.12 / Dual setting minimum torque	1 to 99%	Set the minimum torque to be applied during deceleration (for Hammer Algorithm).								
13 PHASE SEQ2=2	G8.13 / Dual setting in phase sequence at the input of the soft starter	1 to 3	This parameter sets the correct phase sequence at the input, when starting the motor. It can happen that the soft starter tries to start with a phase sequence at the input different than the one we have set. In this case the soft starter trips on F2 WRONG PH/SQ. <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>NO SEQ PROTECT</td> </tr> <tr> <td>2</td> <td>L1 L2 L3 SEQ</td> </tr> <tr> <td>3</td> <td>2 L1 L2 L3 seq</td> </tr> </tbody> </table> Before adjusting, determine your input phase sequence. Then set this parameter according to this sequence. Note: When operating at SLOW SPEED or DC BRAKE you must always select a phase sequence (L1 L2 L3 or Inverse Sequence). The option [1 NO SEQ PROTECT] is not allowed for these modes.	OPT.	DESCRIPTION	1	NO SEQ PROTECT	2	L1 L2 L3 SEQ	3	2 L1 L2 L3 seq
OPT.	DESCRIPTION										
1	NO SEQ PROTECT										
2	L1 L2 L3 SEQ										
3	2 L1 L2 L3 seq										
14 OV LOAD2=InA[*]	G8.14 / Dual setting overload motor current	(0.6 to 1.5)·In of VS65	Determines the current value in which the equipments overload protections will activate. For more details consult the parameter [3.2] In order to proceed with the adjustment, check the nameplate current and introduce the value on screen.								
15 OV/LOAD T2=5	G8.15 / Dual setting of overload curve	1 to 10	This parameter sets the overload motor current protection at nominal conditions. For more details, please consult parameter [G3.3]. Set [15 OV/LOAD T =1] in case you need a fast response under overload conditions. However, if you need a slow response, then select [OV/LOAD T =10]. For normal operation adjust to its default setting [OV/LOAD T =5].								
16 OVL FAC2=100%	G8.16 / Dual setting starting Overload Factor	100 to 500%	This parameter adjusts the overload curve during acceleration. Use this parameter when trying to accelerate high inertia load. In case of pumps, fans (Torque = K x Speed ²) leave as default (100%). This parameter is only active during acceleration and not in normal running conditions, where only [G3.2] and [G3.3] are active. For low inertia pumps, fans (Torque = K x Speed ²) leave as default value (100%). For mills, crushes and centrifuges (high inertia moment) start with low starting overload factor (150%) and increase this value till we can accelerate this load without tripping on F4 OVERLOAD.								
17 MTR PTC2=N	G8.17 / Dual setting PTC motor option	Y N	Enables /Disables the Motor PTC option in dual setting. Motor warming detection through a PTC thermistor. For further information consult [G3.5] parameter.								
18 UNLOAD2=0.0A	G8.18 / Dual setting of under load current	(0 to 0.9)·In of VS65	Under load current determines the current level the motor must not operate below. Usually adjust to 50% of the nominal current of the motor. Application: This protection detects mechanical problems, such as broken shafts, belts. When this occurs, the motor will run under no load conditions. When working with pumps, this protection help to detect no load pump operation, due to a lack of water or pump input pipe water position.								
19 UNLOAD T2=OFF	G8.19 / Dual setting of under load delay	0 to 99s, OFF	This parameter sets the maximum allowable operation time under load conditions before tripping. Set depending on the application, but should be set to trip as soon as a condition occurs. Applications: Pumps, fans.								

* Value that depends on the soft starter rated current

Screen & Default Value	Name / Description	Range	Function																				
20 SHRPIN2=OFF	G8.20 / Dual setting Shearpin current	(0.6 to 1.2)·In of VS65, OFF	The soft starter should stop immediately when the current drawn by the motor reaches this value during nominal conditions. This parameter is off during acceleration or deceleration. The stop should be done in a controlled way. Set current value for the VS65 to stop. Application: Oversized electrical motors used for starting, but working under nominal conditions at running, it may only reach the Shearpin current due to mechanical problems like locked rotors, etc.																				
21 ASYM I ENB2=N	G8.21 / Dual setting asymmetrical current	Y N	Enable/Disable the asymmetric current protection at the soft starter. When enabled, the soft starter will trip on F3 ASYMMETRIC CURRENT if there is a current imbalance greater than 40%.																				
22 I MTR2=xxxxA	G8.22 / Dual setting motor rated current	1 to 1200A	Set the nominal current of the motor. This is necessary for correct motor protection. Set this value according to rated (nameplate) motor current.																				
23 V MTR2=2	G8.23 / Dual Setting rated Motor Voltage	1 to 4	Set the work rated voltage Depending on the line voltage, there are two versions of this parameter, one for voltages from 2300V to 6000V and another from 6600V to 13800V. From 2300 to 6600V: (Software VS65_R2.62) <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>2300V</td> </tr> <tr> <td>2</td> <td>3300 - 3300V</td> </tr> <tr> <td>3</td> <td>4160V</td> </tr> <tr> <td>4</td> <td>6000 - 6600V</td> </tr> </tbody> </table> From 6600 to 13800V: (Software VS65_R2.68) <table border="1"> <thead> <tr> <th>OPT.</th> <th>DESCRIPTION</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>6600V[*]RESERVED</td> </tr> <tr> <td>2</td> <td>7200V</td> </tr> <tr> <td>3</td> <td>10000V</td> </tr> <tr> <td>4</td> <td>13800V</td> </tr> </tbody> </table> Introduce this parameter in accordance with the VS65 input line voltage. Make sure the motor plate voltage is within the related voltage range.	OPT.	DESCRIPTION	1	2300V	2	3300 - 3300V	3	4160V	4	6000 - 6600V	OPT.	DESCRIPTION	1	6600V[*]RESERVED	2	7200V	3	10000V	4	13800V
OPT.	DESCRIPTION																						
1	2300V																						
2	3300 - 3300V																						
3	4160V																						
4	6000 - 6600V																						
OPT.	DESCRIPTION																						
1	6600V[*]RESERVED																						
2	7200V																						
3	10000V																						
4	13800V																						
24 P MTR 2 =40kW	G8.24 / Dual setting motor rated power	40 to 9990kW	Set the nominal motor power rating.																				
25 COS PHI 2 =85%	G8.25 / Dual setting motor power factor	40 to 99%	Set the rated (nameplate) motor cos phi to for calculating the instantaneous torque developed by the motor.																				
26 FREQ 2= 50/60Hz	G8.26 / Dual setting supply frequency	50Hz 50/60Hz	Set the mains frequency. Set as default setting, where the mains frequency is 50Hz. Where the mains frequency is unknown or different than 50Hz (60Hz) set 50/60Hz. Note: When you set 50/60Hz the VS65 starts an algorithm to detect the mains frequency. This algorithm is off when setting 50Hz.																				

[**] Not used setting, only for testing purposes.

E
N
G
L
I
S
H

4.9. Group 10 – G10: FAULT HISTORY

Screen & Default Value	Name / Description	Range	Function																																																												
1 NO FAULT	G10.1 / Register 1 of fault history		The last fault will be displayed as following table indicates by pressing the “[*]” key. <u>Function:</u> Shows the last fault the soft starter tripped on. When a fault occurs, the soft starter automatically shows this screen. At the same time, the fault led lights up. This fault may be reset by pressing the STOP-RESET button on the display unit (if enabled) or using an externally configured RESET input.																																																												
2 NO FAULT	G10.2 / Register 2 of fault history		<u>Example:</u> When fault occurs led red will light and status line (upper line) will show FLT. The average current and voltage displayed are the values right when fault occurred. Last line will show the fault name and the status of VS65 when the fault occurred separated by “/” in case automatic reset was no activated, or by “:” in case it was activated																																																												
3 NO FAULT	G10.3 / Register 3 of fault history		If “**” key is pressed it will display the position of the fault in the history and the number related to it. Next, the faults are listed:																																																												
4 NO FAULT	G10.4 / Register 4 of fault history		<table border="1"> <thead> <tr> <th>COD</th> <th>FAULT</th> <th>COD</th> <th>FAULT</th> </tr> </thead> <tbody> <tr> <td>F0</td> <td>NO FAULT</td> <td>F14</td> <td>SCR1 FAULT</td> </tr> <tr> <td>F1</td> <td>PHA MISING</td> <td>F15</td> <td>SCR2 FAULT</td> </tr> <tr> <td>F2</td> <td>WRONG PH/SQ</td> <td>F16</td> <td>SCR3 FAULT</td> </tr> <tr> <td>F3</td> <td>ASYM CURR</td> <td>F17</td> <td>SCR_S FLT</td> </tr> <tr> <td>F4</td> <td>OVER LOAD</td> <td>F18</td> <td>EXCES T LS</td> </tr> <tr> <td>F5</td> <td>UNDER LOAD</td> <td>F19</td> <td>LS DISABLE</td> </tr> <tr> <td>F6</td> <td>PEAK CURR</td> <td>F20</td> <td>COMS T/OUT</td> </tr> <tr> <td>F7</td> <td>STARTER OT</td> <td>F21</td> <td>EXTRN TRIP</td> </tr> <tr> <td>F8</td> <td>MOTOR PTC</td> <td>F22</td> <td>CUR FLT</td> </tr> <tr> <td>F9</td> <td>SHEAR PIN</td> <td>F23</td> <td>CUR FLT2</td> </tr> <tr> <td>F10</td> <td>OVER VOLT</td> <td>F24</td> <td>HIGH PRESSURE</td> </tr> <tr> <td>F11</td> <td>UNDER VOLT</td> <td>F25</td> <td>LOW PRESSURE</td> </tr> <tr> <td>F12</td> <td>EXCESIV STR</td> <td>F26</td> <td>FLOW SWITCH</td> </tr> <tr> <td>F13</td> <td>MEMORY FLT</td> <td>F27</td> <td>DEEP WELL PROBE</td> </tr> </tbody> </table>	COD	FAULT	COD	FAULT	F0	NO FAULT	F14	SCR1 FAULT	F1	PHA MISING	F15	SCR2 FAULT	F2	WRONG PH/SQ	F16	SCR3 FAULT	F3	ASYM CURR	F17	SCR_S FLT	F4	OVER LOAD	F18	EXCES T LS	F5	UNDER LOAD	F19	LS DISABLE	F6	PEAK CURR	F20	COMS T/OUT	F7	STARTER OT	F21	EXTRN TRIP	F8	MOTOR PTC	F22	CUR FLT	F9	SHEAR PIN	F23	CUR FLT2	F10	OVER VOLT	F24	HIGH PRESSURE	F11	UNDER VOLT	F25	LOW PRESSURE	F12	EXCESIV STR	F26	FLOW SWITCH	F13	MEMORY FLT	F27	DEEP WELL PROBE
COD	FAULT	COD		FAULT																																																											
F0	NO FAULT	F14		SCR1 FAULT																																																											
F1	PHA MISING	F15		SCR2 FAULT																																																											
F2	WRONG PH/SQ	F16		SCR3 FAULT																																																											
F3	ASYM CURR	F17	SCR_S FLT																																																												
F4	OVER LOAD	F18	EXCES T LS																																																												
F5	UNDER LOAD	F19	LS DISABLE																																																												
F6	PEAK CURR	F20	COMS T/OUT																																																												
F7	STARTER OT	F21	EXTRN TRIP																																																												
F8	MOTOR PTC	F22	CUR FLT																																																												
F9	SHEAR PIN	F23	CUR FLT2																																																												
F10	OVER VOLT	F24	HIGH PRESSURE																																																												
F11	UNDER VOLT	F25	LOW PRESSURE																																																												
F12	EXCESIV STR	F26	FLOW SWITCH																																																												
F13	MEMORY FLT	F27	DEEP WELL PROBE																																																												
5 NO FAULT	G10.5 / Register 5 of fault history																																																														
6 DELET FAULTS=N	G10.6 / Clear fault history	Y N	Clear the fault history log which resets the above screens back to the default setting NO FAULTS. In order to adjust the parameter, select YES (Y) to clear the fault history log. The screen will automatically reset back to the default value NO (N) once the fault history is cleared.																																																												

4.10. Group 11 – G11: STATISTICS

Screen & Default Value	Name / Description	Range	Function
1 STARTS1 00000	G11.1 / Total number of starts	-	Shows the total number of the VS65 starts. This record cannot be reset to zero.
2 STARTS2 00000	G11.2 / Counter of starts 2	-	Shows the number of the VS65 starts made after [G11.3] has been cleared. This parameter can be reset to zero.
3 DEL STARTS2=NO	G11.3 / Delete Start registers	YES NO	It resets to 0 the number of starts displayed in [G11.2].
4 H1 =00000h:00m	G11.4 / Total Time Running	-	Shows the total soft starter operation hours. This record cannot be reset to zero.
5 H2= 00000h:00m	G11.5 / Total of working hours	-	Shows the total soft starter operation hours. This record cannot be reset to zero.
6 DEL HOURS2=NO	G11.6 / Working hours counter 2	YES NO	Shows the number of the VS65 operations hours made [G11.6] has been cleared.
7 TOTAL FLT=00	G11.7 / Total number of faults counter	-	Shows the total number where the V5 has tripped due to faults.
8 FAULT 2=0	G11.8 / Faults counter 2	-	Shows the number of faults occurred after [G11.9] has been cleared. This parameter cannot be reset to zero

Screen & Default Value	Name / Description	Range	Function
9 DEL FAULT2=NO	G11.9 / Clear faults counter 2	YES NO	Resets to 0 the number of faults displayed in [G11.8]
10 KWH=000000	G11.10 / Total number of KWH	-	Shows the total value of KWH done by the VS65. This parameter cannot be reset to zero.

4.11. Group 14 – G14: SERIAL COMMUNICATION

Screen & Default Value	Name / Description	Range	Function						
1 COM TIME 0=OFF	G14.1 / Serial Communication Timeout	OFF, 1 to 25s	Timeout condition for serial communication. When the time without communication exceeds this parameter the soft starter will trip by F20 Communication Time out. This setting is used to detect the loss of this communication between master and slave. The VS65 stops the motor until the communication is re-established and reset. In certain cases continuous communication is necessary.						
2 COM ADDRESS=10	G14.2 / Modbus Device Address	1 to 240	It sets the Modbus address for the equipment into a network.						
3 BAUD RATE=9600	G14.3 / Modbus Communication Baud Rate	OFF 1200 2400 4800 9600	Set the baud rate for Serial Communication.						
4 EVEN PARITY=N	G14.4 / Modbus communication parity	Y N	<p>Selects the parity for serial communication.</p> <table border="1"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>Y=YES</td> <td>Even parity enabled.</td> </tr> <tr> <td>N=NO</td> <td>No parity.</td> </tr> </tbody> </table> <p>Parity setting of the soft starter should match with the parity of the bus master into the network.</p>	OPTION	FUNCTION	Y=YES	Even parity enabled.	N=NO	No parity.
OPTION	FUNCTION								
Y=YES	Even parity enabled.								
N=NO	No parity.								

4.12. Group 15 – G15: AUTO RESET

This group enables VS65 to be automatically reset. Once reset is done, the VS65 will start again in case the fault occurred during start command, acceleration and run. If the fault occurred in ready status "RDY" it will auto reset and comes back to "RDY" again.

Screen & Default Value	Name / Description	Range	Function
1 AUTO RESET=NO	G15.1 / Automatic Reset	YES NO	Enable / Disable VS65 automatic reset function.
2 ATTEMP NUMBR=5	G15.2 / Number auto reset attempts before tripping	1 to 5	Provides the number of attempts to reset the VS65 before it trips.
3 R STR DEL=5s	G15.3 / Delay time from fault event to auto reset	5 to 120s	Allows the user to select the period of time between the fault trip and the auto reset.
4 RS COUNT=15Min	G15.4 / Time after the attempt counter will be reset	1 to 60Min	Enables the selection of time that the VS65 has to run without fault and after this the internal attempt counter will be reset.

Screen & Default Value	Name / Description	Range	Function																																																
5 F1 AUTO RST=0	G15.5 / Auto reset fault 1 selection	0 to 20	It selects fault no1 for the auto reset mode. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>FAULT</th> <th>FAULT LIST</th> <th>FAULT</th> <th>FAULT LIST</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>NO AUTO RESET</td> <td>11</td> <td>SCR_1 FAULT</td> </tr> <tr> <td>1</td> <td>PHAS MISING</td> <td>12</td> <td>SCR_2 FAULT</td> </tr> <tr> <td>2</td> <td>WRONG PH/SQ</td> <td>13</td> <td>SCR_3 FAULT</td> </tr> <tr> <td>3</td> <td>ASYM CURR</td> <td>14</td> <td>SCR_S FLT</td> </tr> <tr> <td>4</td> <td>OVER LOAD</td> <td>15</td> <td>EXCESIV LS T</td> </tr> <tr> <td>5</td> <td>UNDER LOAD</td> <td>16</td> <td>COMMS T/OUT</td> </tr> <tr> <td>6</td> <td>STARTER OVT</td> <td>17</td> <td>EXTERN TRIP</td> </tr> <tr> <td>7</td> <td>MOTOR PTC</td> <td>18</td> <td>CUR FLT</td> </tr> <tr> <td>8</td> <td>SHEAR PIN</td> <td>19</td> <td>CUR2 FLT</td> </tr> <tr> <td>9</td> <td>OVER VOLT</td> <td>20</td> <td>ALL THE FLTS</td> </tr> <tr> <td>10</td> <td>UNDER VOLT</td> <td></td> <td></td> </tr> </tbody> </table> <p>Note: Option 20 will automatically reset any of the above table faults.</p>	FAULT	FAULT LIST	FAULT	FAULT LIST	0	NO AUTO RESET	11	SCR_1 FAULT	1	PHAS MISING	12	SCR_2 FAULT	2	WRONG PH/SQ	13	SCR_3 FAULT	3	ASYM CURR	14	SCR_S FLT	4	OVER LOAD	15	EXCESIV LS T	5	UNDER LOAD	16	COMMS T/OUT	6	STARTER OVT	17	EXTERN TRIP	7	MOTOR PTC	18	CUR FLT	8	SHEAR PIN	19	CUR2 FLT	9	OVER VOLT	20	ALL THE FLTS	10	UNDER VOLT		
FAULT	FAULT LIST	FAULT		FAULT LIST																																															
0	NO AUTO RESET	11		SCR_1 FAULT																																															
1	PHAS MISING	12		SCR_2 FAULT																																															
2	WRONG PH/SQ	13	SCR_3 FAULT																																																
3	ASYM CURR	14	SCR_S FLT																																																
4	OVER LOAD	15	EXCESIV LS T																																																
5	UNDER LOAD	16	COMMS T/OUT																																																
6	STARTER OVT	17	EXTERN TRIP																																																
7	MOTOR PTC	18	CUR FLT																																																
8	SHEAR PIN	19	CUR2 FLT																																																
9	OVER VOLT	20	ALL THE FLTS																																																
10	UNDER VOLT																																																		
6 F2 AUTO RST=0	G15.6 / Auto reset fault 2 selection	0 to 20																																																	
7 F3 AUTO RST=0	G15.7 / Auto reset fault 3 selection	0 to 20																																																	
8 F4 AUTO RST=0	G15.8 / Auto reset fault 4 selection	0 to 20																																																	

4.13. Group 16 – G16: PUMP CONTROL

Screen & Default Value	Name / Description	Range	Function						
1 SET IT=LOW	G16.1 / Irrigation time adjustment	0.0 to 60.0H, LOW	Sets the time for the system to be irrigating. VS65 irrigation timer can be reset [G16.2] (back to 0Hrs.) by decreasing [G16.1] to the same value than [G16.2].						
2 I TIME=000Hrs	G16.2 / Irrigation time display	0.0 to 60.0H, LOW	Displays the time the system has been irrigating. Note: Read only screen.						
3 START MODE = 0	G16.3 / Start mode selection	0-1	Selects the start mode of the system. <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>OPTION</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>0</td> <td> Display unit: Enables the display unit for start stop control of the VS65. This is the only way in which the VS65 can be started or stopped. Note: only used for the low voltage trial. </td> </tr> <tr> <td>1</td> <td> Wire: (Face Plate stop button is Reset only). Remaining digital inputs are preconfigured as follows: D INPUT 1 High Pressure switch connection (normally closed). D INPUT 2 Low pressure switch connection (normally closed). D INPUT 3 Flow switches connection (normally closed). D INPUT 4 Deep well probe connection (normally closed). D INPUT 5 is configured for remote two wire start/stop. This input acts as a reset command on closing edge. </td> </tr> </tbody> </table>	OPTION	FUNCTION	0	Display unit: Enables the display unit for start stop control of the VS65. This is the only way in which the VS65 can be started or stopped. Note: only used for the low voltage trial.	1	Wire: (Face Plate stop button is Reset only). Remaining digital inputs are preconfigured as follows: D INPUT 1 High Pressure switch connection (normally closed). D INPUT 2 Low pressure switch connection (normally closed). D INPUT 3 Flow switches connection (normally closed). D INPUT 4 Deep well probe connection (normally closed). D INPUT 5 is configured for remote two wire start/stop. This input acts as a reset command on closing edge.
OPTION	FUNCTION								
0	Display unit: Enables the display unit for start stop control of the VS65. This is the only way in which the VS65 can be started or stopped. Note: only used for the low voltage trial.								
1	Wire: (Face Plate stop button is Reset only). Remaining digital inputs are preconfigured as follows: D INPUT 1 High Pressure switch connection (normally closed). D INPUT 2 Low pressure switch connection (normally closed). D INPUT 3 Flow switches connection (normally closed). D INPUT 4 Deep well probe connection (normally closed). D INPUT 5 is configured for remote two wire start/stop. This input acts as a reset command on closing edge.								
4 HI PR DEL=00s	G16.4 / High pressure timeout	0 to 60	This is the time delay before the VS65 trips once the high pressure switch connection opens the D INPUT 1. Note: VS65 ramps down to stop.						
5 L PR DEL=20s	G16.5 / Low pressure timeout	0 to 3600s	This is the time delay before the VS65 trips once the low pressure switch connection opens the D INPUT 2. Note: VS65 ramps down to stop.						
6 L PR BYP=10s	G16.6 / Low pressure start bypass time	1 to 1800s (30 min)	Sets the start bypass time, during which the VS65 starter ignores the Low Pressure input on D INPUT 2.						
7 FLO BYP=10s	G16.7 / No Flow Start Bypass time	0 to 1800s	Sets the time period for which the flow switch input is ignored following a start command on D INPUT 3).						
8 FLO DEB=10s	G16.8 / No Flow Debounce Delay	0 to 60s	Sets the delay period before the starter responds to a no flow signal when in normal run operation. (D INPUT 3). Note: VS65 ramps down to stop.						
9 LO WTR DEL=10s	G16.9 / Deep Well Probe Delay	0 to 60s	Sets the delay period before the starter stops after receiving a valid deep well probe signal. (D INPUT 4). Note: VS65 freewheel stop ramps.						

5. MODBUS COMMUNICATION

5.1. Modbus Protocol

This section explains how to control several VS65 soft starters by using the Modbus communication.

The Modbus Communication series aim is to introduce itself in to a compatible network with the Modbus communications protocol. This is achieved by the use of RS485 communications. The Series Communications Module enables the soft starter to be controlled and /or monitored as slave by a Modbus master from a remote location.

The RS485 network admits the connection of up to 240 equipments within the same network.

The VS65 soft starter operates as a peripheral slave when it is connected to a Modbus system. This means that the soft starter does not start the communication task. However, the master will be the one who starts the task.

Approximately all of the operating modes, parameters and soft starter characteristics are accessible through the communications series. For instance, master may give the start and stop orders, control the soft starter status, read the motor current consumption....Conclusively, operate with every single soft starter option.

The communication series module uses the standard RS485 for the physic level and the industrial Modbus communication for information exchange.

5.2. Modbus Series Communication Installation Ref: E0004 VS65 Series

The communication series module has been inserted in the lower part of the control board, over 2 female connectors with the following dimensions: 1x5 (lower connector) and 2x7 (upper connector).

Note: The series communication module needs an independent power supply, which has been provided by the J1B connector. The supply voltage must be 9Vef@50Hz.

5.3. Supported Modbus Function Codes

The series communication protocol implemented in he Vs65 soft starter adheres itself completely to the standard industrial communication protocol Modbus from Modicon. Of al existing functions in Modbus protocol, the soft starter uses read-write functions. These functions are the following:

FUNCTION	DESCRIPTION	REGISTERS NUMBER
3	READING REGISTERS	10*
16	WRITING REGISTERS	10*

This function implementation code in the soft starter allows the user to read up to 10 registers of the same Parameter Group within the same frame. In case access to consecutive memory registers is needed, belonging to different groups, they must be done by using as many frames as groups involved.

5.3.1. Modbus Function Code n°3. Registers reading.

This function code enables the Modbus controller (master) to read the data content registers shown in the soft starter (slave). This function code allows only unicast addressing and it is not possible to either broadcast or groupcast addressing.

This function code implementation enables the reading of up to 5 soft starter registers within the same frame.

The following example frame shows how the master tries to read the content of 3 registers, which show the current consumption per phase. The information attached in the question frame is the following:

- Slave data access.
- Modbus function code (3 reading registers).
- Starting data address.
- N° registers read.
- CRC- 16 code.

Soft starter (slave) response should contain the following fields:

- Slave data access.
- Modbus function code (3 reading registers).
- N° of bytes to be read.
- N° bytes / 2 registers
- CRC- 16 code.

Each register is composed of 2 bytes (2 x 8 bits = 16 bits). This is the standard length for all of the soft starter registers.

Function Code n°3 operating example (Reading Registers).

In case reading the equipment current value is needed (nameplate) through communications. This data corresponds to parameter [G2.1]. The frame transmitted is shown below:

Modbus Address	Modbus function code	Starting data address (4002)	Registers number	CRC-16
0AH	03H	00H 15H	00H 01H	94 B5

Assuming the equipments current value is 110A. The Slave response would be:

Modbus Address	Modbus function code	Bytes number	Data	CRC-16
0AH	03H	02H	6EH	9CH 69H

5.3.2. Modbus Function Code n° 16. Writing Registers.

This function codes allows the Modbus controller (master) to write the data registers content given by the soft starter (slave); excepting “Only Read” registers. Notice that the register writing carried out by the master does not stop further modifications done by the slave.

The soft starter function code implementation enables the writing of up to 5 registers within the same frame.

The following example shows how to write the equipment current. The list below shows information which must be included:

- Slave data access.
- Modbus function code (16 writing registers).
- Starting data address.
- N° of registers to write.
- N° of bytes to write
- Register content to write
- CRC- 16 code.
- Slave response contents:
- Slave data address.
- Modbus function code (16 writing registers).
- Starting data address.
- N° of written registers.
- CRC-16 code.

Working Example function code n° 16 (Register writing).

Whenever the user wishes to write the equipment current (nameplate) through communications, value found in [G2] parameter group assigning a value of 100A. The frame to transmit should be:

Modbus Slave Address	Modbus function code	Initial Data Address (40022)	Number of Registers	Number of Bytes	Value (= 100)	CRC-16
0AH	10H	00H 15H	00H 01H	02H	00H 64H	D6H 4EH

The slave response will be:

Modbus Slave Address	Modbus function code	Initial Data Address (40022)	Number of Registers	CRC-16
0AH	10H	00H 15H	00H 01H	11H 76H

5.4. Remote Control Functions

HOST START CONTROL

Screen -
 Range 0 – 1
 Modbus address **40198**
 Modbus range 0 to 1
 Read / Write YES

Description It allows giving the start command to the equipment through communications network.

HOST STOP CONTROL

Screen -
 Range 0 – 1
 Modbus address **40199**
 Modbus range 0 to 1
 Read / Write YES

Description It allows giving the stop command to the equipment through communications network.

HOST RESET CONTROL

Screen -
 Range 0 – 1
 Modbus address **40200**
 Modbus range 0 to 1
 Read / Write YES

Description It allows giving the reset command to the equipment through communications network.

5.5. Summary of Modbus Addresses

5.5.1. Modbus Register 'GENERAL STATUS'

This register supplies information about the general status of the soft starter, as the following table shows:

Modbus Address	Bit	Description	Meaning on '0'	Meaning on '1'
40201	1	STOPPED	SS running	SS stopped
	2	ACCELERATING	No acceleration	SS accelerating
	3	RUNNING	SS stopped	SS running
	4	DECELERATING	No decelerating	SS decelerating
	5	FAULT	No Fault	Fault

5.5.2. General Information Screens

Parameter	Screen	Description	Address	Range	Modbus Range
G0.1 L1	800A 800A 800A	Phase Current L1	40185	0-9999	-
G0.1 L2	800A 800A 800A	Phase Current L2	40186	0-9999	-
G0.1 L3	800A 800A 800A	Phase Current L3	40187	0-9999	-
G0.2V12	6000V 6000V 6000V	Line Voltage L12	40188	0-999	-
G0.2V23	6000V 6000V 6000V	Line Voltage L23	40189	0-999	-
G0.2V13	6000V 6000V 6000V	Line Voltage L13	40190	0-999	-
G0.3 ^f	50Hz	Line Frequency	40191	0-99	-
G0.3 ^f	Cos=0.85	Cos fi	40192	0-1	-
G0.4 ^f	Pr=99%	Motor Torque	40193	0-100	-
G0.4 ^f	450kW	Motor Power	40194	0-999	-
G0.5	RELE= 0 0 0	Relay Status	40195	No	-
G0.6	EDG= 0 0 0 0 F	Digital Input Status	40196	No	-
G.07	ESTADO SOB=0%	Motor Overload	40197	0-100% 100% Overload Condition	-
G.08	EA1=0.00mA = 0%	Analogue Input 1 Status		0-10V 4-20mA 0-20mA	-
G.09	EA2=0.00mA = 0%	Analogue Input 2 Status	V ó mA	0-10V 4-20mA 0-20mA	-
G.10	SA1=0.00mA = 0%	Analogue Output 1 Status		0-20mA 4-20mA	-
G.11	S/W 2.1 H/W 0.2	Hardware and Software Revision	-	-	-

[*] These data are visible when the equipment is in RUN and the motor is moving.

5.5.3. Programming Parameters

Parameter	Screen	Description	Address	Range	Modbus Range
G1.1	1 LOCK PARAM=NO	Soft starter parameters lock		Yes No	-
G1.2	2 PASSWORD= 0	Programming Password mode	-	OFF, 0000 to 9999	-
G1.2b	3 WRONG P/W=XXXX	Password Recovery	-	0000 a 9999	-
G1.6	6 COMMISSION=YES	Commissioning	40019	Yes No	0-1
G2.1	1 I STARTER =xxxA	Soft starters Rated Current	40022	7A 17A 30A 45A ... 1600A	1-1600
G2.2	2 I MOTOR=XXX[*]A	Motor Plate Current	40023	1 to 1600	1-1600
G2.3	3 V MOTOR=2	Input Line Voltage	40024	1 to 4	1-4
G2.4	4 P MOTOR =450kW	Motor Power Plate	40025	4 to 999kW	40-9990
G2.5	5. COS PHI M =85%	Motor Phi Cosine	40026	40 to 99%	40-99
G2.6	6 FREQ= 50Hz	Supply Frequency	40027	50Hz 50/60Hz	0-1
G3.1	1 PHASE SEQUEN=2	Phase Sequence at the Soft starters Input	40029	1 to 3	1-3
G3.2	2 OV LOAD=InA	Motor Overload Current	40030	(0.6 to 1.5)·In of the VS65	120-300
G3.3	3 OV/LOAD T=5	Overload Curve	40031	1 to 10	1-10
G3.4	4 OVL FAC=100%	Starting Overload Factor	40032	100 to 500%	100-500
G3.6	6 UNLOAD=0.0A	Underload Current	40034	(0 to 0.9)·In of VS65	0-180
G3.7	7 UNLOAD T=OFF	Underload Delay	40035	0 to 99s, OFF	0-100
G3.8	8 SHEARPIN=OFF	Shearpin Current	40036	(0.6 to 1.2)·In of the VS65, OFF	120-240
G3.9	9 ASYM I ENB=Y	Asymmetrical Protection	40037	Y N	0-1
G3.10	10 UNDER V=-	Under Voltage	40038	-	-
G3.11	UNDERVOLTAGE DELAY	Under voltage Delay	40039	0 to 10s, OFF	0-11
G3.12	12 OVERVOLT=-	Over voltage	40040	-	-
G3.13	13 O/V DELAY=5s	Over voltage Delay	40041	0 to 10s, OFF	0-11

Parameter	Screen	Description	Address	Range	Modbus Range
G3.14	14 START LIMIT=3	Maximum Number of Starts	40042	1 to 10	1-10
G3.15	15 STR/INT=15Min	Start interval	40043	0 to 60Min, OFF	1-61
G4.1	1 STR DELAY=0s	Starting Delay	40045	0 to 600s	0-600
G4.2	2 PULS TORQ =50%	Torque Pulse	40046	50 to 100%	50-100
G4.3	3 PULS TQ T=OFF	Torque Pulse Time	40047	OFF, 0.1 to 0.9s	0-9
G4.4	INIT TORQ=35%	Initial Torque	40048	30 to 99%	35-99
G4.5	5 INIT TQ T=1s	Initial Torque Time	40049	0 to 10s	0-10
G4.6	6 ACCEL TIME=6s	Acceleration Time	40050	0 to 180s	1-180
G4.7	7 I LIMIT=1400A	Current Limit	40051	(1.5 to 5)·In of VS65	300-1000
G5.1	1 FREWEL STP=Y	Freewheel Stop	40053	Y N	0-1
G5.2	2 DECL TIME=12s	Deceleration Time	40054	1 to 180s	1-180
G5.3	3 DEC MD SEL=1	Motor Deceleration Algorithm	40055	1 to 2	1-2
G5.4	4 HAMR FACT=75%	Hammer Factor	40056	1 to 99%	-
G5.5	5 MINI TORQ=1%	Minimum Torque	40057	1 to 60%	-
G6.1	1 OPER MODE=1	Control Mode Source	40059	0 to 5	0-5
G6.2	2 LOCAL RESET=Y	Local Reset Control	40060	Y N	0-1
G6.3	3 DINPUT1 SEL=4	Multifunction 1 input	40061	0 to 10	0-10
G6.4	4 DINPUT2 SEL=0	Multifunction 2 input	40062	0 to 10	0-10
G6.5	5 DINPUT3 SEL=0	Multifunction 3 input	40063	0 to 10	0-10
G6.6	6 DINPUT4 SEL=0	Multifunction 4 input	40064	0 to 10	0-10
G6.7	7 DINPUT5 SEL=0	Multifunction 5 input	40065	0 to 10	0-10
G6.8	8 ANI1 FORMAT =1	Analogue Input 1 Format	40066	0 to 2	0-2
G6.9	9 AI1 RANGE 0_10	Analogue Input 1 Range	40067	0_0 to 0_999	0-999
G6.10	10 AI1 UNITS=OFF	Analogue Input 1 Units	40068	OFF, Bar °C Mtr	0-3
G6.11	11 ANI2 FORMAT =1	Analogue Input 2 Format	40069	0 to 2	0-2
G6.12	12 AI2 RANGE 0_10	Analogue Input 2 Range	40070	0_0 to 0_999	0-999
G6.13	13 AI2 UNITS=OFF	Analogue Input 2 Units	40071	OFF, Bar °C Mtr	0-3
G7.1	1 REL1 SEL ON=14	Relay 1 control Source Selection	40073	0 to 21	0-21
G7.2	2 REL2 SEL ON=15	Relay 2 control Source Selection	40074	0 to 21	0-21
G7.3	3 REL3 SEL ON=9	Relay 3 control Source Selection	40075	0 to 21	0-21
G7.4	4 ANALOG1 SEL=0	Analogue Output 1 Source Selection	40076	0 to 7	0-7
G7.5	5 AO1 FORMAT=0	Analogue Output 1 Format	40077	0 to 1	0-1
G7.6	6 AO1 LOW=0%	Analogue Output 1 Low Set point	40078	0 to 500%	0-100
G7.7	7 AO1 HIGH=100%	Analogue Output 1 High Set point	40079	0 to 500%	100-500
G8.1	1 DUALSETING=N	Dual Setting	40081	Y N	0-1
G8.2	2 PLS TORQ2=50%	Dual setting Torque Pulse	40082	50 to 100%	50-100
G8.3	3 PLS TQ T2=OFF	Dual Setting Pulse Time	40083	OFF, 0.1 to 0.9s	0-9
G8.4	4 INIT TRQ2 =30%	Dual Setting Initial Torque	40084	30 to 99%	30-99
G8.5	5 T PAR INI2=1s	Dual Setting Torque Time	40085	0 to 10s	0-10
G8.6	6 ACC TIME2=12s	Dual Setting Acceleration Time	40086	0 to 180s	1-180
G8.7	7 LTE INT2=2800A	Dual Setting Current Limit	40087	(1.5 a 5)·In del VS65	300-1000
G8.8	8 FREWEL STP2=N	Dual Setting Freewheel Stop	40088	SI NO	0-1
G8.9	9 DEC TIME2=12s	Dual Setting Deceleration Time	40089	0 to 180s	1-180
G8.10	10 DEC MD SEL2= 1	Dual Setting Deceleration Mode Selection	40090	1 to 2	300-1000
G8.11	11 HAMR FAC2=75%	Dual Setting Hammer Factor	40091	1 to 99%	-
G8.12	12 MINI TRQ2=1%	Dual Setting Minimum Torque	40092	1 to 99%	-
G8.13	13 PHASE SEQ2=2	Dual Setting in phase sequence soft starter input	40093	1 to 3	1-3
G8.14	14 OV LOAD2=InA	Dual Setting Overload Motor Current	40094	(0.6 to 1.5)·InVS65	120-300
G8.15	15 OV/LOAD T2=5	Dual Setting Overload Curve	40095	1 to 10	1-10
G8.16	16 OVL FAC2=100%	Dual Setting Starting Overload Factor	40096	100 to 500%	100-500

Parameter	Screen	Description	Address	Range	Modbus Range
G8.17	17 MTR PTC2=N	Dual Setting Motor PTC Option	40097	YES NO	0-1
G8.18	18 UNLOAD2=0.0A	Dual Setting Underload Setting	40098	(0 to 0.9)·In VS65	0-180
G8.19	19 UNLOAD T2=OFF	Dual Setting of Underload Delay	40099	0 to 99s, OFF	0-100
G8.20	20 SHEARP2=OFF	Dual Setting Shearpin Current	40100	0.6 to 1.2)·In VS65, OFF	120-241
G8.21	21 ASYM I ENB2=N	Dual Setting Asymmetrical Current	40101	YES NO	0-1
G8.22	22 I MOTR2=30	Dual Setting Motor Rated Current	40102	1 to 1200A	1-1200
G8.23	23 V MTR2=2	Dual Setting Motor Rated Voltage	40103	1 to 4	1-4
G8.24	24 P MTR 2 =xxxkW	Dual Setting Motor Rated Power	40104	4 to 999kW	40-9990
G8.25	25 COS PHI 2 =85%	Dual Setting Motor Power Factor	40105	40 to 99%	40-99
G8.26	26 FREQ 2= 50/60Hz	Dual Setting Supply Frequency	40106	50Hz 50/60Hz	0-1
G10.1	1 NO FAULT	Register 1 Fault History	40124		-
G10.2	2 NO FAULT	Register 2 Fault History	40125		-
G10.3	3 NO FAULT	Register 3 Fault History	40126		-
G10.4	4 NO FAULT	Register 4 Fault History	40127		-
G10.5	5 NO FAULT	Register 5 Fault History	40128		-
G10.6	6 DELET FAULTS=N	Delete Fault History	40129	YES NO	0-1
G11.1	1 STARTS1 00000	Total Number of Starts 10k	40131	0..9999	-
G11.1	1 STARTS1 00000	Total Number of Starts	40132	0..9999	-
G11.2	2 STARTS2 00000	Partial Number of Starts 10k	40133	0..9999	-
G11.2	2 STARTS2 00000	Partial Number of Starts	40134	0..9999	-
G11.3	3 DEL STARTS2=NO	Delete Number of Starts	40135	YES NO	0-1
G11.4	4 H1 =00000h:00m	Total Number of Hours 10k	40136	0..9999	-
G11.4	4 H1 =00000h:00m	Total Number of Hours	40137	0..9999	-
G11.5	5 H2= 00000h:00m	Working Hours Counter 2 10k	40141	0..9999	-
G11.5	5 H2= 00000h:00m	Working Hours Counter 2	40142	0..9999	-
G11.6	6 DEL HOURS2=NO	Delete Hours Counter 2	40144	YES NO	0-1
G11.7	7 TOTAL FLT=00	Total Faults Counter	40145	0..9999	-
G11.8	8 FAULT 2=0	Total Faults Counter 2	40146	0..9999	-
G11.9	9 DEL FAULT2=NO	Delete Fault Counter 2	40147	YES NO	0-1
G11.10	10 KWH=000000	Total KWH consumption	40148	0..9999	-
G11.11	10 KWH=000000	Total KWH consumption 10k	40149	0..9999	-
G14.1	1 COM TIME 0=OFF	Serial Communication Time Out	40164	OFF, 1 to 25s	0-25
G14.2	2 DIR COMMS=10	Modbus communication address Modbus	40165	1 to 240	1-240
G14.3	3 BAUDIOS=9600	Default communication speed	40167	OFF 1200 2400 4800 9600	-0-4
G14.4	4 EVEN PARITY=N	Modbus Communication Parity	40167	YES NO	0-1
G15.1	1 AUTO RESET=NO	Automatic Reset	40169	YES NO	0-1
G15.2	2 ATTEMP NUMBR=5	Number of Auto Reset Trials before Tripping	40170	1 to 5	1-5
G15.3	3 R STR DEL=5s	Delay before Reset	40171	5 to 120s	5-120
G15.4	4 RS COUNT=15Min	Delay Time after Attempt before Reset	40172	1 to 60Min	1-60
G15.5	5 F1 AUTO RST=0	Auto Reset Fault 1 Configuration	40173	0 to 20	0-20
G15.6	6 F2 AUTO RST=0	Auto Reset Fault 2 Configuration	40174	0 to 20	0-20
G15.7	7 F3 AUTO RST=0	Auto Reset Fault 3 Configuration	40175	0 to 20	0-20
G15.8	8 F4 AUTO RST=0	Auto Reset Fault 4 Configuration	40176	0 to 20	0-20
G16.1	1 SET IT=INF	Irrigation Time Setting	40212	0.0 to 60.0Hrs, INF	0-601
G16.2	2 I TIME=000Hrs	Irrigation Time Display	40213	0.0 to 60.0Hrs, INF	0
G16.3	3 START MODE = 0	Start Mode Selection	40214	0 – 1	0-1
G16.4	4 HI PR DEL=0s	High Pressure Time Out	40215	0 to 60s	0-60
G16.5	5 L PR DEL=20s	Low Pressure Time Out	40216	0 to 3600s	0-3600
G16.6	6 L PR BYP=10s	Low Pressure Bypass Time	40217	1 to 1800s (30min)	1-1800
G16.7	7 FLO BYP=10s	No flow Start Bypass Time	40218	0 to 1800s	0-1800
G16.8	8 FLO DEB=10s	No Flow Debounce Delay	40219	0 to 60s	0-60
G16.9	9 LO WTR DEL=10s	Deep Well Probe Delay	40220	0 to 60s	0-60

6. FAULT MESSAGES. DESCRIPTION AND ACTIONS

FAULT TRIPS

When a fault occurs, the VS65 will stop the motor and will display the fault that caused the trip. The red LED and fault message will remain until the fault has been removed and the soft starter is reset.

Fault Description Possible Cause Action	F0 NO FAULTS No fault detected. Normal operation. None required.
Fault Description Possible Cause Action	F1 PHA MISING Supply phase loss. Loss of phase, fuse failure, cable fault, motor winding fault. Check supply, all cables including thyristors, and motor. If the problem persists, call Power Electronics or an authorised distributor.
Fault Description Possible Cause Action	F2 WRONG PH / SQ Incorrect input supply phase sequence. The mains phase sequence doesn't correspond to G3.1 (1 PHASE SEQUEN=2) Swap two input phase over or change G3.1 Phase Sequence to suit supply phase sequence.
Fault Description Possible Cause Action	F3 ASYM CURR Phase current imbalance. There is a current imbalance higher than 40%. Check the motor; check the load and the coupling between both. Check input power supply is always balanced. Check thyristors. If the problem persists, call Power Electronics or an authorised distributor.
Fault Description Possible Cause Action	F4 OVERLOAD. Calculated motor overload has reached an unacceptable level. Motor overload. If the trip is produced during start, it could be a mechanical problem. If it occurs when the motor is running at nominal speed, probable causes could be a wrong setting at G.3.2. screen or a change of the load conditions. Wrong nameplate values. Check that current from the G3.2 screen is the same as the motor. Check working conditions and connections of motor. Check load. Check nameplates.
Fault Description Possible Cause Action	F5 UNDERLOAD. Motor under load. Motor current draw is lower than that set in G3.6 screen. Soft starter has been working during for longer than the one set in G3.7 screen. Motor working with no load. Wrong setting of under load conditions. Check that mechanical parts coupled to the motor are ok and that the motor is not working unloaded. In case of pump application, check there is no air inside the pipe network and that the pump suction is not obstructed. Wrong adjustment, set again under load settings G3.6 and G3.7.

Fault	F6 PEAK CURR
Description	VS65 peak current output exceeded. The current is higher than six times nominal.
Sense level	(6xIn). VS65 Rated Current.
Possible Cause	Rotor locked. Short circuit in output circuit. VS65 current transformers failure. Torque pulse setting too high.
Action	Check cables and motor. Reduce Torque pulse setting. If the problem persists, call Power Electronics or an authorised distributor.
Fault	F7 STARTER OT
Description	Heat sink too hot (>85°C).
Sense level	(> 85°C).
Possible Cause	Insufficient cooling. Fan failure. Ambient temperature too high (>45°C). The actual current is higher than the nominal.
Action	Check fans and cooling paths. Check the ambient temperature during normal operation doesn't exceed 45°C or 50°C with re-rating. Check that correct re-rating has been applied if higher than 45°C. Check that actual motor current is the same or smaller than the VS65 nominal current.
Fault	F8 MOTOR PTC .
Description	Not used for this soft starter.
Fault	F9 SHEARPIN
Description	Shearpin current trip.
Sense level	G3.8 Shearpin Current.
Possible Cause	The motor has drawn a higher current than Shearpin protection setting at G3.8. Rotor locked due to a mechanical obstruction.
Action	Check if it's possible that motor reaches the Shearpin current under normal operation, and if so, increase the value of that protection. Check motor, cables and load and the reason of the over current.
Fault	F10 OVER VOLT
Description	High supply voltage for too long period.
Sense level	The combination of parameters G3.12 OVERVOLTAGE and G3.13 OVERVOLTAGE DELAY.
Possible Cause	Fluctuating power supply, wrong settings; the input voltage of each phase in parameter G3.12; and the time set in G3.13.
Action	Check supply voltage and set G3.12 and G3.13. Check supply.
Fault	F11 UNDER VOLT
Description	Low voltage supply for too long period.
Sense level	The combination of parameters G3.10 UNDERVOLTAGE and G3.11 UNDERVOLTAGE DELAY.
Possible Cause	Impedance of input power supply is too high. Excess current draw, weak supply. Check the input voltage of each phase is higher than G3.10 parameter and during the time set in G3.11 parameter.
Action	Check supply, check values at G3.10 and G3.11. Check supply.

E
N
G
L
I
S
H

Fault	F12 EXCESIV STR
Description	Maximum number of starts exceeded.
Sense level	Maximum number of starts set at G3.14 START LIMIT during time period set at G3.15 SRT/INT.
Possible Cause	Excessive number of starts/stop during the normal operation. Rotor locked or motor overloaded during the start so the ramp up couldn't be completed.
Action	Check motor and load conditions. Check values of parameters G3.14, G3.15 are coherent with the application.
Fault	F13 MEMORY FLT
Description	Fault reading SRAM.
Possible Cause	Writing error, faulty memory.
Action	Attempt to reinitialise the VS65 (1.5 INITIALISE).
Fault	F14 SCR1 FAULT F15 SCR2 FAULT F16 SCR3 FAULT F17 SCR_S FLT
Description	F14 Thyristor Fault L1, disconnected motor at L1. F15 Thyristor Fault L2, disconnected motor at L2. F16 Thyristor Fault L3, disconnected motor at L3. F17 Thyristors Fault, disconnected motor.
Possible Cause	Thyristor fault, motor disconnected, excessive number of starts, excessive temperature, over voltage.
Action	Check motor, cables and fans. Check thyristors and excessive environmental temperature. Check input supply voltage.
	If the problem persists, call Power Electronics or an authorised distributor.
NOTE:	<i>This fault can only be reset via the display unit.</i>
Fault	F18 EXCES T LS
Description	Not used with this soft starter.
Fault	F19 LS DISABLE
Description	Slow Speed not allowed.
Possible Cause	Slow Speed mode is blocked if one of these 2 options are selected: <ul style="list-style-type: none"> • No phase sequence (G3.1 Phase Sequence) at the input. You need to select L1 L2 L3 or L2 L1 L3 sequence. • DC Brake stop selected (G13.1 DC Brake).
Action	Set phase sequence at the input. Make sure no DC Brake is selected.
Fault	F20 COMS T/OUT
Description	Serial communication Time Out exceeded.
Possible Cause	No communication from the Master for the time specified at G14.1 CommTime Out. RS232/RS485 communication link fault.
Action	Check if the Master is trying to communicate to slave at a rate higher than specified at G14.1 COM TIME O. Check the RS232/RS485 wiring. Check communication parameters.
Fault	F21 EXTRN TRIP
Description	An external fault has occurred through a digital input.
Possible Cause	There is a digital input activated and set as external fault.
Action	Check configuration of digital inputs. Check the status of the digital inputs for correctness.

Fault	F22 CUR FLT
Description	Large current unbalance is occurring among phases.
Possible Cause	Large current unbalance occurs due to a sudden voltage drop in any of the VS65 input phases. Possible disconnection of one phase.
Action	Check input power wiring. Check motor connection. Check supply voltage is correct.
Fault	F23 CUR FLT 2
Description	Large current unbalance is occurring among phases.
Possible Cause	Large current unbalance occurs due to a sudden voltage rise in any of the VS65 input phases.
Action	Check input power wiring. Check supply voltage is correct.
Fault	F24 HIGH PRESSURE
Description	High pressure time protection.
Possible Cause	The VS65 is running and the pressure switch opens for longer than the time entered in screen G16.4. Overpressure.
Action	Check hydraulic installation. Check pressure switch. Check proper wiring from pressure switch to VS65 digital input 1. The VS65 will require resetting on the display or via D INPUT 5 if configured for 2 wire start/stop. Check parameter setting is done according to application requirements.
Fault	F25 LOW PRESSURE
Description	Low pressure protection.
Possible Cause	The VS65 is running and the pressure switch opens for longer than the time entered in screen G16.5.
Action	Check hydraulic installation (broken pipes). Check pump has got water. Check pressure switch. Check proper wiring from pressure switch to VS65 digital input 2. The VS65 will require resetting on the display or via D INPUT 5 if configured for 2 wire start/stop. Check parameter setting is done according to application requirements.
Fault	F26 FLOW SWITCH
Description	No flow protection.
Possible Cause	The flow switch is ignored for the time set in screen G16.7 on receipt of a valid start signal. After this time the VS65 will trip if no flow is indicated for longer than the time set in screen G16.8. No water in the pump.
Action	Check proper pump water supply. Check flow switch. Check proper wiring from flow switch to VS65 digital input 3. The VS65 will require resetting on the display or via D INPUT 5 if configured for 2 wire start/stop. Check parameter setting is done according to application requirements.
Fault	F27 DEEP WELL PROBE
Description	Low level protection
Possible Cause	The well probe controller (or other level controller) detects a lack of water. The tank or pump has no water.
Action	Check water level. Check hydraulic installation. Check level switch. Check proper wiring from deep well probe flow controller to VS65 digital input 4. The VS65 will not reset unless the low water fault has been cleared (D INPUT 4 closed). Check parameter setting is done according to application requirements.

7. TYPICAL CONFIGURATION

7.1. Start

SCREENS	CURRENT LIMIT START	VOLTAGE RAMP AND CURRENT LIMIT START			CONSTANT ACCELE RATION START (DTC)	TORQUE PULSE START (LOCKED ROTOR)
		Light	Medium	Heavy		
G4 1 STR DELAY=	0s	0s	0s	0s	0s	0s
2 PULS TORQ =	35-40%	35%	40%	50%	40- 45%	70 - 80 %
3 PULS TQ T =	OFF	OFF	OFF	OFF	OFF	0,2-0,5
4 INIT TORQ =	35-40%	35%	40%	50-60%	40- 45%	50 - 70 %
5 INIT TQ T =	0 s	0	0	1	1s-2s	0-10
6 ACEL TIME =	1s	4 – 6s	4 – 6s	6 – 8s	10s-30s	1-180
7 I LIMIT =	3.5 -4 x I _n	3 – 3.5 I _n	3.5 – 4 I _n	4 – 5 I _n	2,5 – 3 I _n	3,5 x I _n

7.2. Stop

SCREENS	DEFAULT PARAMETERS	SPIN STOP	VOLTAGE RAMP STOP
G5. 1 FREWEL STP =	Y	YES	NO
2 DECL TIME =	12s	-	f (load)
3 DEC MD SEL =	1*	-	1
4 HAMR FACT =	75%	-	-
5 MINI TORQ=	1%	-	-

8. CONFIGURATION REGISTER

DIGITAL SOFT STARTER:

SERIAL N°:
APPLICATION : SERIE
DATE:
CUSTOMER :

VS65

MODEL:

SCREENS	RANGE	DEFAULT	RECORD 1	RECORD 2
G1 MENU OPTIONS				
1 LOCK PARAM=	Yes/No	N0		
2 PASSWORD=	0000-9999	0		
3 WRONG P/W=	0000-9999	XXXX		
4 LANGUE=	Span., Eng., D	ENGLISH		
5 INITIALISE=	Yes/No	NO		
6 COMMISSION=	Yes/No	YES		
G2 NAMEPLATE				
1 ISTARTER=	9 - 1600	__ _A*		
2 I MOTOR=	1 - 1600	__ _A *		
3 V MOTOR=	1/2/3/4	2*		
4 P MOTOR=	4 - 999	__ _KW		
5 COS PHI M=	40 – 99%	85%		
6 FREQ=	50/60	50Hz		
G3 PROTECTIONS				
1 PHASE SEQUEN=	1/2/3	2*		
2 OV LOAD=	0,5-1,5 I _{VS65}	1 x I		
3 OV/LOAD T=	1-10	5		
4 OVL FAC=	100-500%	100%		
6 UNLOAD=	0-0,8	0.0A		
7 UNLOAD T=	0-99/Off	OFF		
8 SHRPIN=	0,6-1,2/Off	OFF		
9 ASYM I ENB=	Yes/No	YES		
10 UNDER V=	162-450	5052V		
11 U/V DELAY=	0-10/Off	5s		
12 OVERVOLT=	254-575	6947V		
13 O/V DELAY=	0-10/Off	5s		
14 START LIMIT=	1-10	3		
15 STR/ INT=	0-60/Off	15Min		
G4 ACCELERATION				
1 STR DELAY=	0-600	0s		
2 PULS TORQ=	50-99%	50%		
3 PULS TQ T=	0,1-0,9/Off	OFF		
4 INIT TORQ=	0-100%	35%		
5 INIT TQ T=	0-99	1s		

* See section '11 SCREEN DESCRIPTION'.

SCREENS	RANGE	DEFAULT	RECORD 1	RECORD 2
6 ACEL TIME=	0-180	6s		
7 I LIMIT=	1.5 - 5 x In	xxxxA		
G5 DECELERATION				
1 FREWEL STP=	Yes/No	YES		
2 DECL TIME=	0-180	12s		
3 DEC MD SEL=	1/2	1*		
4 HAMR FACT=	0-100%	75%		
5 MINI TORQ=	0-80%	1%		
G6 INPUTS				
1 OPER MODE=	1/2/3/4/5	1*		
2 LOCAL RESET=	Yes/No	Y		
3 DINPUT1 SEL=	0-10	4*		
4 DINPUT2 SEL=	0-10	0*		
5 DINPUT3 SEL=	0-10	0*		
6 DINPUT4 SEL=	0-10	0*		
7 DINPUT5 SEL=	0-10	0*		
8 ANI1 FORMAT=	0/1/2	1		
9 AI1 RANGE=	0-100	0-10		
10 AI1 UNITS=	Off/Bar/°C/m	OFF		
11 ANI2 FORMAT=	0/1/2	1		
12 AI2 RANGE=	0-100	0-10		
13 AI2 UNITS=	Off /Bar/°C/m	OFF		
G7 OUTPUTS				
1 REL1 SEL ON=	1-21	14*		
2 REL2 SEL ON=	1-21	15*		
3 REL3 SEL ON=	1-21	9*		
4 ANLOG1 SEL=	0-7	0*		
5 AO1 FORMAT=	0/1	0*		
6 AO1 LOW=	0-500	0%		
7 AO1 HIGH=	0-500	100%		
G8 DUAL SETTING				
1 DUALSETING=	Yes/No	NO		
2 PLS TORQ2=	50-99%	50%		
3 PLS TQ T2=	0,1-0,9/Off	OFF		
4 INIT TRQ2=	0-100%/Off	30%		
5 INIT TQ T2=	0-99	1s		
6 ACC TIME2=	0-180	12s		
7 I LIMIT2=	1-5 I _{VS65}	xxxxA		
8 FREWEL STP2=	Yes/No	N		
9 DEC TIME2=	0-180	12s		
10 DEC MD SEL2=	1/2	1		
11 HAMR FAC2=	0-99	75		
12 MINI TRQ2=	1-99%	1%		
13 PHASE SEQ2=	1/2/3	2s		

* See section '10 SCREEN DESCRIPTION'.

SCREENS	RANGE	DEFAULT	RECORD 1	RECORD 2
14 OV LOAD2=	0,6-1,5 I _{VS65}	xxxxA		
15 OV/LOAD T2=	1-10	5		
16 OVL FAC2=	100-500%	100%		
17 MTR PTC2=	Yes/No	N		
18 UNLOAD2=	0-0,9	0.0A		
19 UNLOAD T2=	0-99/Off	OFF		
20 SHRPIN2=	0,7-1,2/Off	OFF		
21 ASYM I ENB2=	Yes/No	N		
22 I MTR2=	9-1200	30A		
23 V MTR2=	1/2/3/4	2		
24 P MTR2=	0-999	xxxxKw		
25 COS PHI 2=	40-99%	85%		
26 FREQ 2=	50/60	50Hz		
G10 FAULT HISTORY				
1 LAST FAULT		F0		
2 FOURTH FAULT		F0		
3 THIRD FAULT		F0		
4 SECOND FAULT		F0		
5 FIRST FAULT		F0		
6 DELET FAULTS=		N		
G11 STATIST INFO				
1 STARTS1=	0-9999	00000		
2 STARTS2=	0-9999	00000		
3 DEL STARTS2=	0-1	NO		
4 H1=	0-9999	00000h:00m		
5 H2 =	0-9999	00000h:00m		
6 DEL HOURS2=	0-1	NO		
7 TOTAL FLT=	0-9999	00		
8 FAULT2=	0-9999	0		
9 DEL FAULT2=	0-1	NO		
10 KWH =	0-9999	000000		
G14 SERIAL COMM				
1 COM TIME O=	0-25/ Off	OFF		
2 COM ADRESS=	0-240	0		
3 BAUD COM=	1200/2400/ 4800/9600/ Off	OFF		
4 EVEN PARITY=	Yes/No	NO		
G15 AUTO RESET				
1 AUTO RESET=	Yes/No	NO		
2 ATTEMP NUMBR=	1-5	5		
3 R STR DEL=	5-120	5s		
4 RS COUNT=	1-60	15Min		
5 F1 AUTO RST =	0-20	0		
6 F2 AUTO RST =	0-20	0		
7 F3 AUTO RST =	0-20	0		
8 F4 AUTO RST =	0-20	0		

SCREENS	RANGE	DEFAULT	RECORD 1	RECORD 2
G16 PUMP CONTROL				
1 SET IT =	0-60/INF	000Hrs		
2 I TIME =	0-60/INF	000Hrs		
3 START MODE =	0/1	0		
4 HI PR DEL =	0-60	00s		
5 L PR DEL=	0-3600	0000s		
6 L PR BYP =	1-1800	0000s		
7 FLO BYP =	0-1800	0000s		
8 FLO DEB =	0-60	00s		
9 LO WTR DEL =	0-60	00s		



DECLARATION OF CONFORMITY CE

DECLARACIÓN DE CONFORMIDAD CE

The Company *La empresa:*

Name *Nombre:* POWER ELECTRONICS ESPAÑA, S.L.
Address *Dirección:* C/ Leonardo Da Vinci, 24-26, 46980 Paterna, Valencia, Spain
Telephone *Teléfono:* +34 96 136 65 57
Fax: +34 96 131 82 01

Declares under its own responsibility, that the product:

Declara bajo su propia responsabilidad, que el producto:

Softstarters medium voltage
Arrancador media tensión

Brand *Marca* : Power Electronics

Model *Modelo:* VS65

Is in conformity with the following European Directives:

Se halla en conformidad con las siguientes Directivas Europeas:

Reference <i>Referencia</i>	Title <i>Título</i>
2014/30/UE	Electromagnetic Compatibility <i>Compatibilidad Electromagnética</i>

References of the harmonized technical norms applied under the Electromagnetic Compatibility Directive:

Referencias de las normas técnicas armonizadas aplicadas bajo la Directiva de Compatibilidad Electromagnética:

Reference <i>Referencia</i>	Title <i>Título</i>
EN 61000-6-4:2007	Electromagnetic compatibility (EMC) -- Part 6-4: Generic standards - Emission standard for industrial environments (IEC 61000-6-4:2006). <i>Compatibilidad Electromagnética (CEM) -- Parte 6-4: Normas genéricas. Norma de emisión en entornos industriales</i>
EN 61000-6-2:2005	Electromagnetic compatibility (EMC) -- Part 6-2: Generic standards - Immunity for industrial environments <i>Compatibilidad electromagnética (CEM). --Parte 6-2: Normas genéricas. Inmunidad en entornos industriales</i>

Paterna, 20th of April, 2016

David Salvo
CEO



24h Technical Assistance 365 days a year

Find your nearest delegation: <http://power-electronics.com/contact/>

Follow us on:





24H TECHNICAL ASSISTANCE 365 DAYS A YEAR

FIND YOUR NEAREST DELEGATION
POWER-ELECTRONICS.COM/CONTACT/

@ in   