

SD 500
Series

ACCESSORIES



Profibus Communication
Communication Network

SD500

Series

A C C E S S O R I E S

Communication Network
Profibus Communication

Edition: March 2011

SD50BC01AI Rev. A

SAFETY SYMBOLS

Always follow safety instructions to prevent accidents and potential hazards from occurring.



This symbol means improper operation may result in serious personal injury or death.



Identifies shock hazards under certain conditions. Particular attention should be given because dangerous voltage may be present. Maintenance operation should be done by qualified personnel.



Identifies potential hazards under certain conditions. Read the message and follow the instructions carefully.

E
N
G
L
I
S
H

Edition of March 2011

This publication could present technical imprecision or misprints. The information here included will be periodically modified and updated, and all those modifications will be incorporated in later editions.

To consult the most updated information of this product you might access through our website www.power-electronics.com where the latest version of this manual can be downloaded.

Revisions

Date	Revision	Description
7 / 03 / 2011	A	First edition.

The equipment and technical documentation are periodically updated. Power Electronics se reserves the right to modify all or part of the contents of this manual without previous notice.

INDEX

SAFETY INSTRUCTIONS	7
1. INTRODUCTION.....	12
1.1. Description of Profibus Optional Board.....	12
2. TECHNICAL CHARACTERISTICS	13
2.1. General information.....	13
3. INSTALLATION AND CONNECTION.....	15
3.1. Installation of Profibus Optional Board	15
3.2. Connections of Profibus Optional Board.....	16
4. CONFIGURATION OF PROFIBUS OPTIONAL BOARD	20
4.1. GSD File	20
4.2. Parameter setting of Profibus	21
4.3. Input/Output Data.....	23
5. OPERATION MODES.....	24
6. FAULT DIAGNOSIS	25
6.1. Led DAT_EX (Interface with drive)	25
6.2. Led CPU (Status)	26
6.3. Led ERR (Error)	26
7. GROUP G20.2 (PROFIBUS). PARAMETER LIST	27
8. ADDRESS LIST	30
8.1. Common Area	30
8.2. Programming parameters	34
8.3. Visualization parameters.....	51

E
N
G
L
I
S
H

SAFETY INSTRUCTIONS

!IMPORTANT!

- Safety instructions showed in this manual are useful to teach user how to use the product in a correct and safety way with the purpose of preventing possible personal injuries or property damages.
- Safety messages included here are classified as it follows:



WARNING

Be sure to take ESD (Electrostatic Discharge) protection measures when you touch the board.

Otherwise, the optional board may get damaged due to static charges.

Implement wiring change on the optional board after checking that the power supply is off.

Otherwise, there is a danger of connecting error and damage to the board.

Be sure to connect correctly the optional board to the inverter.

Otherwise, there is a danger of connecting error and damage to the board.

Be sure to install termination resistors (390Ω , 220Ω , 390Ω) in the optional board connected to the last equipment integrated into the network.

Do not remove the cover while the power is applied or the unit is in operation.

Otherwise, electric shock could occur.

Do not run the inverter with the front cover removed.

Otherwise, you may get an electric shock due to the high voltage terminals or exposure of charged capacitors.

E
N
G
L
I
S
H

Do not remove the cover except for periodic inspections or wiring, even if the input power is not applied.

Otherwise, you may access the charged circuits and get an electric shock.

Wiring and periodic inspections should be performed at least 10 minutes after disconnecting the input power and after checking the DC Link voltage is discharged with a meter (below 30VDC).

Otherwise, you may get an electric shock.

Operate the switches with dry hands.

Otherwise, you may get an electric shock.

Do not use cables with damaged insulation.

Otherwise, you may get an electric shock.

Do not subject the cables to the abrasions, excessive stress, heavy loads or pinching.

Otherwise, you may get an electric shock.



CAUTION

Install the inverter on a non-flammable surface. Do not place flammable material nearby.

Otherwise, fire could occur.

Disconnect the input power if the inverter gets damaged.

Otherwise, it could result in a secondary accident or fire.

After the input power is applied or removed, the inverter will remain hot for a couple of minutes.

Touching hot parts may result in skin burns.

Do not apply power to a damaged inverter or to an inverter with parts missing even if the installation is complete.

Otherwise, fire or accident could occur.

Do not allow lint, paper, wood chips, dust, metallic chips or other foreign matter into the drive.

Otherwise, fire or accident could occur.



WARNINGS

RECEPTION

- Material of Power Electronics is carefully tested and perfectly packed before leaving the factory.
- In the even of transport damage, please ensure that you notify the transport agency and POWER ELECTRONICS: 902 40 20 70 (International +34 96 136 65 57) or your nearest agent, within 24hrs from receipt of the goods.

UNPACKING

- Make sure received merchandise corresponds with delivery note, models and serial numbers.
- Each optional board is supplied with a technical manual.

SAFETY

- A Before operating the inverter, read this manual thoroughly to gain and understanding of the unit. If any doubt exists then please contact POWER ELECTRONICS, (902 40 20 70 / +34 96 136 65 57) or your nearest agent.
- Wear safety glasses when operating the inverter with power applied and the front cover is removed.
- Handle the inverter with care according to its weight.
- Install the inverter according to the instructions within this manual.
- Do not place heavy objects on the inverter.
- Ensure that the mounting orientation is correct.
- Do not drop the inverter or subject it to impact.
- The SD500 inverters contain static sensitive printed circuits boards. Use static safety procedures when handling these boards.

E
N
G
L
I
S
H

CONNECTION PRECAUTIONS

- To ensure correct operation of the inverter it is recommended to use a SCREENED CABLE for the control wiring.
- For EMERGENCY STOP, make sure supply circuitry is open.
- Do not disconnect motor cables if input power supply remains connected. The internal circuits of the SD450 Series will be damaged if the incoming power is connected and applied to output terminals (U, V, W).
- It is not recommended to use a 3-wire cable for long distances. Due to increased leakage capacitance between conductors, over-current protective feature may operate malfunction.
- Do not use power factor correction capacitors, surge suppressors, or RFI filters on the output side of the inverter. Doing so may damage these components.
- Always check whether the DC Link LED is OFF before wiring terminals. The charge capacitors may hold high-voltage even after the input power is disconnected. Use caution to prevent the possibility of personal injury.

TRIAL RUN

- Verify all parameters before operating the inverter. Alteration of parameters may be required depending on application and load.
 - Always apply voltage and current signals to each terminal that are within levels indicated within this manual. Otherwise, damage to the optional board may result.
-

EARTH CONNECTION

- The inverter is a high frequency switching device, and leakage current may flow. Ground the inverter to avoid electrical shock. Use caution to prevent the possibility of personal injury.
 - Connect only to the dedicated ground terminal of the inverter. Do not use the case or the chassis screw for grounding.
 - When installing, grounding wire should be connected first and removed last.
 - The earth cable must have a minimal cross sectional area that meets local country electrical regulations.
 - Motor ground must be connected to the drive ground terminal and not to the installation's ground. We recommend that the section of the ground connection cable should be equal or higher than the active conductor.
 - Installation ground must be connected to the inverter ground terminal.
-


E
N
G
L
I
S
H

1. INTRODUCTION

1.1. Description of Profibus Optional Board

The optional board for Profibus communication allows SD450 drive to connect it to a Profibus network. Thanks to this optional board:

- Inverter can be controlled and monitored by PLC sequence program or any master module.
- Multiple inverters can be connected to one communication cable with simple and easy installation, saving wiring, maintenance cost and time.
- Compatible with PC System, PLC and any controllers is available, making Factory Automation more easily.



2. TECHNICAL CHARACTERISTICS

2.1. General Information

2.1.1. Contents of Profibus Optional Board Kit

The Profibus optional board kit consists on:

- 1 Profibus optional board.
- 1 Connector SUB-D 9 pin.
- 3 mounting poles.
- 1 Technical Manual.
- 1 GSD file (see section ‘4.1. GSD File’).

E
N
G
L
I
S
H

2.1.2. Specifications of Profibus Optional Board

- Device Type: Profibus DP Slave.
- Auto Baud Rate Detect: Supported.
- Sync Mode: Supported.
- Freeze Mode: Supported.
- Maximum Input Length: 8 words.
- Maximum Output Length: 8 words.
- Maximum Data Length: 16 words.
- Baud Rate Supported: 9.6K, 19.2K, 93.75K, 187.5K, 500K, 1.5M, 3M, 6M, 12M.
- Modular Station: Supported.
- Max Module: 2.

2.1.3. Communication cable length

Communication cable length depends on the baud rate (set in parameter 'I/O → Baud Rate') as the following table shows:

Baud Rate (kbps)	Maximum Length (1 Segment)	Maximum Extension Length
9.60	1000m	10000m
19.20	1000m	10000m
93.75	1000m	10000m
187.50	1000m	10000m
500.00	400m	4000m
1500.00	200m	2000m
3000.00	100m	1000m
6000.00	100m	1000m
12000.00	100m	1000m

2.1.4. Local indications

The Profibus optional board has 3 leds (DAT_EX, ERR y CPU) that are providing information about the device and Profibus communication status. See section '6. FAULT DIAGNOSIS' to obtain more detailed information about these leds.

3. INSTALLATION AND CONNECTION

3.1. Installation of Profibus Optional Board

The Profibus optional board is connected to the SD500 Series inverters of Power Electronics directly (through a connector) to integrate the equipment into a Profibus communications network. Therefore, it is necessary to use one Profibus optional board for any equipment to connect it to the network.



CAUTION

Motor controllers of Power Electronics operate with a high electric energy.

Make sure the power supply has been disconnected and wait for at least 10 minutes to guarantee that DC Link voltage is discharged, before installing the Profibus optional board. Otherwise, you may get personal injuries or an accident could occur.



Figure 3.1 Installation of Profibus optional board to the inverter

3.2. Connections of Profibus Optional Board

3.2.1. Description of Terminals and Leds

In the Profibus optional board there are two connectors and three leds. One connector is used to connect the board to the SD500 inverter; in the other connector, Profibus specific signals are connected. On the other hand, leds provide with information about the status of the device and the communications.




Figure 3.2 Location of the VFD connector




Figure 3.3 Location of the connector on the Profibus board

E
N
G
L
I
S
H




CONNECTOR / LED	DESCRIPTION																																																				
Profibus Connector (P1)	<p>Connector SUB-D 9 pin for the connections of the specific signals of the Profibus network.</p> <table border="1" data-bbox="431 286 861 705"> <thead> <tr> <th data-bbox="431 286 513 309">Terminal</th><th data-bbox="513 286 635 309">Signal</th><th data-bbox="635 286 861 309">Description</th></tr> </thead> <tbody> <tr> <td data-bbox="431 309 513 362">1</td><td data-bbox="513 309 635 362">Shield (Not used)</td><td data-bbox="635 309 861 362">Protective Ground</td></tr> <tr> <td data-bbox="431 362 513 416">2</td><td data-bbox="513 362 635 416">M24 (Not used)</td><td data-bbox="635 362 861 416">24V Output GND</td></tr> <tr> <td data-bbox="431 416 513 469">3</td><td data-bbox="513 416 635 469">RxD/TxD-P</td><td data-bbox="635 416 861 469">Receive / Transmit Data – Positive</td></tr> <tr> <td data-bbox="431 469 513 523">4</td><td data-bbox="513 469 635 523">CTRL-P (Not used)</td><td data-bbox="635 469 861 523">Control Signal for Repeater</td></tr> <tr> <td data-bbox="431 523 513 560">5</td><td data-bbox="513 523 635 560">DGND</td><td data-bbox="635 523 861 560">Signal GND</td></tr> <tr> <td data-bbox="431 560 513 598">6</td><td data-bbox="513 560 635 598">VP</td><td data-bbox="635 560 861 598">5V for Termination Resistor</td></tr> <tr> <td data-bbox="431 598 513 651">7</td><td data-bbox="513 598 635 651">P24 (Not used)</td><td data-bbox="635 598 861 651">24V Output +</td></tr> <tr> <td data-bbox="431 651 513 705">8</td><td data-bbox="513 651 635 705">RxD/TxD-N</td><td data-bbox="635 651 861 705">Receive / Transmit Data – Negative</td></tr> <tr> <td data-bbox="431 705 513 728">9</td><td data-bbox="513 705 635 728">CTRL-N (Not used)</td><td data-bbox="635 705 861 728">Control Signal for Repeater</td></tr> </tbody> </table> <p>Signals of terminals 3, 5, 6 and 8 are only used.</p> <table data-bbox="428 791 861 1066"> <thead> <tr> <th data-bbox="448 791 489 810">DB9</th> <th data-bbox="643 791 796 810">Connector Signals</th> </tr> </thead> <tbody> <tr> <td data-bbox="428 810 591 1066">  </td> <td data-bbox="643 810 861 1066"> <table border="1"> <tbody> <tr> <td data-bbox="653 839 676 858">1</td> <td data-bbox="704 839 796 858">(Not used)</td> </tr> <tr> <td data-bbox="653 858 676 877">2</td> <td data-bbox="704 858 796 877">(Not used)</td> </tr> <tr> <td data-bbox="653 877 676 895">3</td> <td data-bbox="704 877 796 895">RxD/TxD - P</td> </tr> <tr> <td data-bbox="653 895 676 914">4</td> <td data-bbox="704 895 796 914">(Not used)</td> </tr> <tr> <td data-bbox="653 914 676 933">5</td> <td data-bbox="704 914 796 933">DGND</td> </tr> <tr> <td data-bbox="653 933 676 952">6</td> <td data-bbox="704 933 796 952">VP (+5V)</td> </tr> <tr> <td data-bbox="653 952 676 971">7</td> <td data-bbox="704 952 796 971">(Not used)</td> </tr> <tr> <td data-bbox="653 971 676 989">8</td> <td data-bbox="704 971 796 989">RxD/TxD - N</td> </tr> <tr> <td data-bbox="653 989 676 1008">9</td> <td data-bbox="704 989 796 1008">(Not used)</td> </tr> </tbody> </table> </td> </tr> </tbody> </table> <p>SD45DTR0002AI</p>	Terminal	Signal	Description	1	Shield (Not used)	Protective Ground	2	M24 (Not used)	24V Output GND	3	RxD/TxD-P	Receive / Transmit Data – Positive	4	CTRL-P (Not used)	Control Signal for Repeater	5	DGND	Signal GND	6	VP	5V for Termination Resistor	7	P24 (Not used)	24V Output +	8	RxD/TxD-N	Receive / Transmit Data – Negative	9	CTRL-N (Not used)	Control Signal for Repeater	DB9	Connector Signals		<table border="1"> <tbody> <tr> <td data-bbox="653 839 676 858">1</td> <td data-bbox="704 839 796 858">(Not used)</td> </tr> <tr> <td data-bbox="653 858 676 877">2</td> <td data-bbox="704 858 796 877">(Not used)</td> </tr> <tr> <td data-bbox="653 877 676 895">3</td> <td data-bbox="704 877 796 895">RxD/TxD - P</td> </tr> <tr> <td data-bbox="653 895 676 914">4</td> <td data-bbox="704 895 796 914">(Not used)</td> </tr> <tr> <td data-bbox="653 914 676 933">5</td> <td data-bbox="704 914 796 933">DGND</td> </tr> <tr> <td data-bbox="653 933 676 952">6</td> <td data-bbox="704 933 796 952">VP (+5V)</td> </tr> <tr> <td data-bbox="653 952 676 971">7</td> <td data-bbox="704 952 796 971">(Not used)</td> </tr> <tr> <td data-bbox="653 971 676 989">8</td> <td data-bbox="704 971 796 989">RxD/TxD - N</td> </tr> <tr> <td data-bbox="653 989 676 1008">9</td> <td data-bbox="704 989 796 1008">(Not used)</td> </tr> </tbody> </table>	1	(Not used)	2	(Not used)	3	RxD/TxD - P	4	(Not used)	5	DGND	6	VP (+5V)	7	(Not used)	8	RxD/TxD - N	9	(Not used)
Terminal	Signal	Description																																																			
1	Shield (Not used)	Protective Ground																																																			
2	M24 (Not used)	24V Output GND																																																			
3	RxD/TxD-P	Receive / Transmit Data – Positive																																																			
4	CTRL-P (Not used)	Control Signal for Repeater																																																			
5	DGND	Signal GND																																																			
6	VP	5V for Termination Resistor																																																			
7	P24 (Not used)	24V Output +																																																			
8	RxD/TxD-N	Receive / Transmit Data – Negative																																																			
9	CTRL-N (Not used)	Control Signal for Repeater																																																			
DB9	Connector Signals																																																				
	<table border="1"> <tbody> <tr> <td data-bbox="653 839 676 858">1</td> <td data-bbox="704 839 796 858">(Not used)</td> </tr> <tr> <td data-bbox="653 858 676 877">2</td> <td data-bbox="704 858 796 877">(Not used)</td> </tr> <tr> <td data-bbox="653 877 676 895">3</td> <td data-bbox="704 877 796 895">RxD/TxD - P</td> </tr> <tr> <td data-bbox="653 895 676 914">4</td> <td data-bbox="704 895 796 914">(Not used)</td> </tr> <tr> <td data-bbox="653 914 676 933">5</td> <td data-bbox="704 914 796 933">DGND</td> </tr> <tr> <td data-bbox="653 933 676 952">6</td> <td data-bbox="704 933 796 952">VP (+5V)</td> </tr> <tr> <td data-bbox="653 952 676 971">7</td> <td data-bbox="704 952 796 971">(Not used)</td> </tr> <tr> <td data-bbox="653 971 676 989">8</td> <td data-bbox="704 971 796 989">RxD/TxD - N</td> </tr> <tr> <td data-bbox="653 989 676 1008">9</td> <td data-bbox="704 989 796 1008">(Not used)</td> </tr> </tbody> </table>	1	(Not used)	2	(Not used)	3	RxD/TxD - P	4	(Not used)	5	DGND	6	VP (+5V)	7	(Not used)	8	RxD/TxD - N	9	(Not used)																																		
1	(Not used)																																																				
2	(Not used)																																																				
3	RxD/TxD - P																																																				
4	(Not used)																																																				
5	DGND																																																				
6	VP (+5V)																																																				
7	(Not used)																																																				
8	RxD/TxD - N																																																				
9	(Not used)																																																				


Figure 3.4 Connections of the connector SUB-D 9 Pin

Note: If more detailed information about Profibus connection is required, refer to “*Installation Guide of PROFIBUS DP/FMS*” of the Profibus users group.

CONNECTOR / LED	DESCRIPTION
Inverter connector	By using it, Profibus board is connected to the inverter.
Interface with Inverter Led (DAT_EX)	Active when the communication between the inverter and Profibus optional board is operating correctly. See section '6.1. Led D1 (Interface with Inverter)' to obtain more detailed information.
Status Led (CPU)	Active when Profibus optional board self-diagnostic without any fault. See section '6.2. Led D2 (Status)' to obtain more detailed information.
Error Led (ERR)	Active when Profibus optional board is in a fault status. See section '6.3. Led D3 (Error)' to obtain more detailed information.

Note: Be sure to install termination resistors (390Ω , 220Ω , 390Ω) in the optional board connected to the last equipment integrated into the network, as the following figure shows:

Connector Signals



SD45DTR0003AI

Figure 3.5 Connection of the termination resistors

4. CONFIGURATION OF PROFIBUS OPTIONAL BOARD

Once the board has been connected to the inverter, this one can be configured by using the software PE v1.1 and upper versions.

Board configuration can be divided in two parts. First, installation of the GSD file by using configuration software of Profibus Master; then, parameter setting of the group [G20.2 Profibus] related to Profibus network from the inverter itself.

4.1. GSD File

One GSD file is supplied with the kit of Profibus optional board.

The GSD files are PROFIBUS DP “standard” text files that include the needed configuration of communications for a slave. These files supply all the information necessary for a configuration tool (software) of a standard Profibus Master, to access and modify the parameters of a slave device.

The GSD file contains information about the parameters of a device. Information about each parameter is contained in this file such as minimum, maximum and default parameter values, parameter data format and scaling, and the parameter name and units.

Install the GSD file for the SD500 inverter supplied with the kit, to control the inverter parameters. For this, use configuration software of Profibus Master.

E
N
G
L
I
S
H

4.2. Parameter setting of Profibus

4.2.1. Profibus ID Setting (G20.2.3 → Profibus ID)

It allows assigning the equipment number (station address) to each inverter into a Profibus network. Therefore, this number is unique and for this reason is necessary to be sure that any equipment has a different address.

The setting of this parameter is available from the keypad. Default value is '1'. If any trouble in DPRAM communication between inverter control board and Profibus optional board appears, this parameter must be set to '127'.

4.2.2. Outputs Number Setting (G20.2.4 → Reading Address Nº)

It allows determining the number of outputs to communicate (up to 8 output addresses can be selected). Depending on the value set here, parameters related to the output addresses (from 'G20.2.5 → Reading address 1' to 'G20.2.12 → Reading address 8'). See section '*4.2.4 Output Addresses Setting*'.

4.2.3. Inputs Number Setting (G20.2.13 → Writing Address Nº)

It allows determining the number of inputs to communicate (up to 8 input addresses can be selected). Depending on the value set here, parameters related to the input addresses (from 'G20.2.14 → Writing address 1' to 'G20.2.21 → Writing address 8'). See section '*4.2.5 Input Addresses Setting*'.

4.2.4. Output Addresses Setting (G20.2.5→Reading address 1 – G20.2.12→Reading address 8)

It allows addressing the outputs to communicate. As it is mentioned before, depending on the value set in 'G20.2.4 → Reading address n°' parameters related to the outputs addresses will be accessible.

For example, if outputs number is set to '4' (G20.2.4 → '4'), parameters from 'G20.2.5 → Reading address 1' to 'G20.2.8 → Reading address 8' will be accessible. From this moment on, we will access to these parameters to select an output address in each one of them. In this way, we will communicate with the inverter parameters, the addresses of which are the selected ones in parameters G20.2.5 to G20.2.8.

The value of the output addresses to communicate is set in Hexadecimal format. For additional information, see section '7. GROUP COM (COMMUNICATIONS). PARAMETER LIST'.

4.2.5. Input Addresses Setting (G20.2.14→Writing address 1–G20.2.21→Writing address 8)

It allows addressing the inputs to communicate. As it is mentioned before, depending on the value set in 'G20.2.13 → Writing address n°' parameters related to the inputs addresses will be accessible.

For example, if input number is set to '5' (G20.2.13 → '5'), parameters from 'G20.2.14 → Writing address 1' to 'G20.2.18 → Writing address 5' will be accessible. From this moment on, we will access to these parameters to select an input address in each one of them. In this way, we will communicate with the inverter parameters, the addresses of which are the selected ones in parameters G20.2.14 to G20.2.18.

The value of the input addresses to communicate is set in Hexadecimal format. See section '7. GROUP COM (COMMUNICATIONS). PARAMETER LIST' for additional information.

E
N
G
L
I
S
H

4.3. Input/Output Data

Output data, selected by setting their addresses from keypad, are transmitted to the Profibus Master Module (PLC or PC) through the Profibus optional board. On the other hand, input data, selected by setting their addresses from keypad, are received by the Profibus Master Module (PLC or PC) through the Profibus optional board.

5. OPERATION MODES

During the initialization or reset of the Profibus optional board:

1. After self-testing, Status Led (CPU) blinks when no fault occurs. If any fault is detected, Status Led (CPU) is off or Error Led (ERR) is turned on.
2. After configuring correctly the parameters related to Profibus (Station Address, Outputs Number, Inputs Number, Output Addresses, Input Addresses, all of them via keypad of inverter), configuring Profibus network and starting the communication, Interface Led (DAT_EX) blinks whenever communicating to the inverter.

6. FAULT DIAGNOSIS

6.1. Led DAT_EX (Interface with drive)

LED	Status	Cause	Diagnostic
Off	Interface error	Connection fault.	Check the power of drive. Check if the inverter is in a fault status. Check the inverter connector.
		Incorrect connector wiring.	Check wiring and the pin numeration, and also the connector termination resistor.
		No master in the current network.	Check Master status or Master existence.
		Wrong Address.	Check by keypad if address of Profibus optional board and address which has been assigned in the configuration tool of Profibus Master match. Additionally, this address value must be unique in the network, this is, any device integrated in the network must not have the same address.
		Network configuration problem.	Check the maximum length of segment. Check the number of nodes in the segment, including repeater. Number of nodes must be 32 or below in segment. Check the number of nodes in the network, including repeater. Number of nodes must be 126 or below in the network.
On	Normal	Operating correctly.	-

E
N
G
L
I
S
H

6.2. Led CPU (Status)

LED	Status	Cause	Diagnostic
Off	Power source error	The inverter is not correctly powered or there is a problem in the connection between the inverter and the Profibus board.	Check the power of drive. Check if the inverter is in a fault status. Check the inverter connector.
Blink about 1 sec period	Normal	Operating correctly.	-

6.3. Led ERR (Error)

LED	Status	Cause	Diagnostic
Off	Normal	Operating correctly.	-
Blink about 1 sec period	Communication error	There is an error in the communication between inverter and Profibus board.	Check if there is a connection.

7. GROUP G20.2 (PROFIBUS). PARAMETER LIST

When connecting the Profibus optional board to the inverter, a new group of parameters related to the communications is available. This one is the group 'G20.2 Profibus' and their parameters are described below.

Note: Changes realized in the parameters settings of this group will have any effect until communications are updated through parameter 'G20.2.1 → Comm Update'.

Display / Default value	Name / Description	Range	Function	Set during Run								
1 ComUpdate= NO Comm Update	G20.2.1 / Communication setting update	NO YES	It allows the reconnection of the communications when a parameter is changed, for example the communication speed, etc...	YES								
2 LEDStatus= XXXX LEDs Status	G20.2.2 / Led status	0000 to XXXX	It displays the LED status of the communication board. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>Bit</th> <th>LED</th> </tr> <tr> <td>X00</td> <td>(DAT_EX) Inverter Interface</td> </tr> <tr> <td>OX0</td> <td>(ERR) Error</td> </tr> <tr> <td>00X</td> <td>(CPU) Status</td> </tr> </table> 0: Inactive; X: Active	Bit	LED	X00	(DAT_EX) Inverter Interface	OX0	(ERR) Error	00X	(CPU) Status	NO
Bit	LED											
X00	(DAT_EX) Inverter Interface											
OX0	(ERR) Error											
00X	(CPU) Status											
3 ProfibusID= 1 Dir Com Profibus	G20.2.3 / Profibus communications address	0 to 125	It allows identifying the equipment number into the network assigned to each device in a Profibus network. When the communication is between some equipment, the address of all of them must be different.	NO								

Display / Default value	Name / Description	Range	Function	Set during Run
4 ParamRdNum= 3 Para Read Num	G20.2.4 / Outputs number	0 to 8	It allows determining the number of outputs to communicate. Changing this value, parameters from [G20.2.5] to [G20.2.12], described below will be accessible.	YES
5 ParaRd1=0x000A ^[1] Param Read 1	G20.2.5 / Reading address 1	0x0000 to 0xFFFF	It allows addressing the output 1.	YES
6 ParaRd2=0x000E ^[1] Param Read 2	G20.2.6 / Reading address 2	0x0000 to 0xFFFF	It allows addressing the output 2.	YES
7 ParaRd3=0x000F ^[1] Param Read 3	G20.2.7 / Reading address 3	0x0000 to 0xFFFF	It allows addressing the output 3.	YES
8 ParaRd4=0x0000 ^[1] Param Read 4	G20.2.8 / Reading address 4	0x0000 to 0xFFFF	It allows addressing the output 4.	YES
9 ParaRd5=0x0000 ^[1] Param Read 5	G20.2.9 / Reading address 5	0x0000 to 0xFFFF	It allows addressing the output 5.	YES
10 ParaRd6=0x0000 ^[1] Param Read 6	G20.2.10 / Reading address 6	0x0000 to 0xFFFF	It allows addressing the output 6.	YES
11 ParaRd7=0x0000 ^[1] Param Read 7	G20.2.11 / Reading address 7	0x0000 to 0xFFFF	It allows addressing the output 7.	YES
12 ParaRd8=0x0000 ^[1] Param Read 8	G20.2.12 / Reading address 8	0x0000 to 0xFFFF	It allows addressing the output 8.	YES

^[1] These parameters will be available depending on the value set in [G20.2.4] → Outputs Number'. As parameters as outputs number has been selected will appear available in ascendant order and in a consecutive way.

Display / Default value	Name / Description	Range	Function	Set during Run
13 ParaWrNum= 2 Param Write Num	G20.2.13 / Number of inputs	0 to 8	It allows fixing the input communication number. Changing this value, parameters from [G20.2.14] to [G20.2.21] described below will be accessible.	YES
14 ParWr1=0x0005^[2] Param Write 1	G20.2.14 / Writing address 1	0x0000 to 0xFFFF	It allows addressing the input 1.	YES
15 ParWr2=0x0006^[2] Param Write 2	G20.2.15 / Writing address 2	0x0000 to 0xFFFF	It allows addressing the input 2.	YES
16 ParWr3=0x0000^[2] Param Write 3	G20.2.16 / Writing address 3	0x0000 to 0xFFFF	It allows addressing the input 3.	YES
17 ParWr4=0x0000^[2] Param Write 4	G20.2.17 / Writing address 4	0x0000 to 0xFFFF	It allows addressing the input 4.	YES
18 ParWr5=0x0000^[2] Param Write 5	G20.2.18 / Writing address 5	0x0000 to 0xFFFF	It allows addressing the input 5.	YES
19 ParWr6=0x0000^[2] Param Write 6	G20.2.19 / Writing address 6	0x0000 to 0xFFFF	It allows addressing the input 6.	YES
20 ParWr7=0x0000^[2] Param Write 7	G20.2.20 / Writing address 7	0x0000 to 0xFFFF	It allows addressing the input 7.	YES
21 ParWr8=0x0000^[2] Param Write 8	G20.2.21 / Writing address 8	0x0000 to 0xFFFF	It allows addressing the input 8.	YES

^[2] These parameters will be available depending on the value set in [G20.2.13] → Inputs Number'. As parameters as inputs number has been selected will appear available in ascendant order and in a consecutive way.

8. ADDRESS LIST

8.1. Common Area

Address	Parameter	Scale	Units	R/W	Data value
0x0000	Inverter model			R	B: SD500
0x0001	Inverter capacity			R	0: 0.75kW 1: 1.5kW 2: 2.2kW 3: 3.7kW 4: 5.5kW 5: 7.5kW 6: 11kW 7: 15kW 8: 18.5kW 9: 22kW A: 30kW B: 37kW C: 45kW D: 55kW E: 75kW
0x0002	Inverter input voltage			R	0: 220VAC 1: 400VAC
0x0003	SW Version			R	(Ex) 0x0100: Version 1.0 (Ex) 0x0101: Version 1.1
0x0004	Reserved				
0x0005	Reference frequency	0.01	Hz	R/W	Start freq. to Max. freq.

Address	Parameter	Scale	Units	R/W	Data value
0x0006	Start / stop command			R	Bit 0: Stop
					Bit 1: Forward run
					Bit 2: Reverse run
					Bit 3: Fault reset
					Bit 4: Emergency stop
					- Bit 5: Not used
					Bit 6 – 8: Reference introduction
					0: Local
					1: Start/Stop-1
					2: Start/Stop-2
					3: RS485 integrated
					4: Communications option
					5: PLC option
					Bit 9 – 14: Reference frequency
					0: Local Reference
					1: Not used
					2: Step frequency 1
					3: Step frequency 2
					4: Step frequency 3
					5: Step frequency 4
					6: Step frequency 5
					7: Step frequency 6
					8: Step frequency 7
					9: Step frequency 8
					10: Step frequency 9
					11: Step frequency 10
					12: Step frequency 11
					13: Step frequency 12
					14: Step frequency 13
					15: Step frequency 14
					16: Step frequency 15
					17: Up speed
					18: Down speed
					19: Constant
					20 – 21: Reserved
					22: Analogue V1
					23: Analogue I1
					24: Analogue V2
					25: Analogue I2
					26: Reserved
					27: RS485
					28: Communication option
					29: PLC option
					30: Fix frequency
					31: PID
					Bit 15: Network error

E
N
G
L
I
S
H

Address	Parameter	Scale	Units	R/W	Data value
0x0007	Acceleration time	0.1	sec	R/W	
0x0008	Deceleration time	0.1	sec	R/W	
0x0009	Output current	0.1	A	R	
0x000A	Output frequency	0.01	Hz	R	
0x000B	Output voltage	1	V	R	
0x000C	DC Bus voltage	1	V	R	
0x000D	Output power	0.1	kW	R	
0x000E	Inverter status			R	Bit 0: Stop
					Bit 1: Forward run
					Bit 2: Reverse run
					Bit 3: Fault
					Bit 4: Accelerating
					Bit 5: Decelerating
					Bit 6: Steady status
					Bit 7: DC braking
					Bit 8: Stopping
					Bit 9: Fixed frequency
					Bit 10: Brake open
					Bit 11: Forward run command
					Bit 12: Reverse run command
					Bit 13: Start / Stop by communication
					Bit 14: Reference Frec. by communication
					Bit 15: 0-Remote; 1-Local
0x0010	Digital input status			R	Bit 0: P1
					Bit 1: P2
					Bit 2: P3
					Bit 3: P4
					Bit 4: P5
					Bit 5: P6
					Bit 6: P7
					Bit 7: P8
0x0011	Digital output status			R	Bit 0: Relay 1
					Bit 1: Relay 2
					Bit 2: Digital output 1 (Q1)
					Bit 3: Relay 3 (I/O option)
					Bit 4: Relay 4 (I/O option)
					Bit 5: Relay 5 (I/O option)

Address	Parameter	Scale	Units	R/W	Data value
0x0012	V1			R	Voltage input V1
0x0013	V2			R	Voltage input V2 (I/O option)
0x0014	I			R	Current input I1
0x0015	RPM			R	Output speed
0x001A	Display unit			R	0: Hz 1: rpm
0x001B	Pole number			R	Visualization of the motor poles

Notes:

1. Start / stop command with communications (direction 0x0006)

All bits are enabled when their status changes from 0 to 1. For example, if the VFD is stopped with a fault while it is started, it can't start newly since the fault is reseted and the order given newly.

2. Addresses of 0x0005 and 0x0006

The values of the directions shown before will be deleted if the VFD losses power supply. These addresses will maintain their values while the equipment is powered.

E
N
G
L
I
S
H

8.2. Programming parameters

Parameter	Screen	Description	Address	Range	Modbus Range
G1.1	1 LOCK PARMTRS=0	Parameters lock	-	0 to 2	-
G1.1b	PASSWORD= 0	Access password	-	OFF, 0000 to 9999	-
G1.1c	ERRPWD= XXXX	Unlock recovery clue	-	0000 to 9999	-
G1.2	2 LOCK SCRENS= N	Screen lock	-	N Y	-
G1.2b	PASSWORD= 0	Password	-	OFF, 0000 to 9999	-
G1.2c	ERRORWD= XXXX	Unlock recovery password	-	0000 to 9999	-
G1.3	3 PROG= STANDARD	Program activation	-	STANDARD PID PUMP	-
G1.4	4 LANGUA= ENGLISH	Language display	-	ENGLISH	-
G1.5	5 INITIALIZE= NO	Default values initialization	-	NO YES	-
G1.6	6 UPLOAD= N	Save display parameters	-	N Y	-
G1.6b	Upload STS=	Uploading parameter status	-	0 to 100%	-
G1.7	7 DOWNLOADM= N	Downloading parameters	-	N Y	-
G1.7b	Download Sta=	Downloading parameter status	-	0 to 100%	-
G1.8	8 Changed Para= N	Changed parameter display	-	N Y	-
G1.9	9 ADMIN PW= 0	Software Administration	-	0 to 65535	-
G1.10	10 LCDContra= 60	Set display contrast	-	0 to 63	-
G1.11	11 FAN= Run	Drive fan control	44928	DuringRun Always ON Temp Ctrl	0 1 2

Parameter	Screen	Description	Address	Range	Modbus Range
G2.1.1	ACi/pVolt= 380V	Input Voltage	44366	170 to 230V 320 to 480V	170 to 230V 320 to 480V
G2.1.2	2 I/P Freq= 50Hz	Input frequency	44621	60Hz 50Hz	0 1
G2.1.3	3 TrimPwr%= +100%	Power display setting	44622	70 to 130	70 to 130
G2.1.4	1 MTRPWR= 0.0kW	Motor rated Power	44623	0.2 to 185kW	0 to 21
G2.1.5	2 MTR CUR= 0.0A	Motor rated current	44619	1.0 to 200.0A	10 to 2000
G2.1.6	3 NOLOADC= 0.0A	No load current	44925	0.5 to 200A	5 to 2000
G2.1.7	4 MTR VOLT= 0V	Motor nominal voltage	44624	180 to 480V	180 to 480V
G2.1.8	5 POLE Number= 4	Motor Poles	44370	2 to 48	2 to 48
G2.1.9	6 ADJTSPEED= 100.0%	Fine speed setting	46953	0.1 to 6000%	1 to 60000
G2.2.1	7 EFICIENC= +85%{	Motor Efficiency	44627	70 to 100%	7 to 100
G2.2.2	8 MTR FRC = 50.00Hz	Motor frequency	44618	30 to 400Hz	3000 to 40000
G2.2.3	9 MTRCOOL=SELF	Motor cooling	44626	SELF FORCED	0 1
G3.1	1 REF1 SP= LOCAL	Speed Reference Source 1	44359	LOCAL	0
				AI1	2
				AI2	3
				AI3	4
				AI4	5
				MDBUS	6
				COMMS	8
				PLC	9
G3.2	2 REF2 SP= LOCAL	Speed Reference Source 2	44613	See [G3.1]	See [G3.1]
G3.3	3 LCLSP= 0.50Hz	Local Speed Reference	44353	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G4.1.1	1 CONTROL MODE1= 1	Main Control Mode	44358	LOCAL	0
				REMOTE	1
				MODBUS	3
				COMMS	4
G4.1.2	2 CONTROL MODE2= 1	Alternative Control Mode	44612	PLC	5
				See [G4.1.1]	See [G4.1.1]

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G4.1.3	3 DI1= START (+)	Multifunction Digital Input 1 Configuration	45441	None START (+) START (-) RESET EXT TRIP DIS START INCH 1 SPEED-L SPEED-M SPEED-H SPEED-X XCEL-L XCEL-M 3 WIRE CTR/REF 2 UP DOWN RESERVED POT CLEAR AnalogHLD PIDOPLoop RESERVED START/DC ThermalIn INCH (+) INCH (-)	0 1 2 3 4 5 6 7 8 9 10 11 12 14 15 17 18 20 21 23 34 39 46 47
G4.1.4	4 DI2= START(-)	Multifunction Digital Input 2 Configuration	45442	See [G4.1.3]	See [G4.1.3]
G4.1.5	5 DI3= DIS START	Multifunction Digital Input 3 Configuration	45443	See [G4.1.3]	See [G4.1.3]
G4.1.6	6 DI4= EXT TRIP	Multifunction Digital Input 4 Configuration	45444	See [G4.1.3]	See [G4.1.3]
G4.1.7	7 DI5= SPEED-L	Multifunction Digital Input 5 Configuration	45445	See [G4.1.3]	See [G4.1.3]
G4.1.8	8 DI6= SPEED-M	Multifunction Digital Input 6 Configuration	45446	See [G4.1.3]	See [G4.1.3]
G4.1.9	9 DI7= SPEED-H	Multifunction Digital Input 7 Configuration	45447	See [G4.1.3]	See [G4.1.3]
G4.1.10	10 DI8= INCH 1	Multifunction Digital Input 8 Configuration	45448	See [G4.1.3]	See [G4.1.3]

Parameter	Screen	Description	Address	Range	Modbus Range
G4.1.14	14 DIOnF= 10ms	Digital Input activation delay	45461	0 to 10000ms	0 to 10000
G4.1.15	15 DIOffF= 3ms	Digital Input deactivation delay	45462	0 to 10000ms	0 to 10000ms
G4.1.16	16 DCTy= 00000000	Digital input contact type selection	45463	00000000 to XXXXXXXX	0 to 65535
G4.1.17	17 DiScan= 1ms	Multireference delay time	45465	1 to 5000ms	1 to 5000ms
G4.1.18	18 SaveMot Frq= N	Save operating frequency motorised Potentiometer	44929	N Y	0 1
G4.2.1	1 An1PT= 0-10v	Analog Input Mode Selection	45382	0-10V -/+10V	0 1
G4.2.2	2 Ain1LPF= 10ms	Low Pass Filter for Analog Input 1	45383	0 to 10000ms	0 to 10000
G4.2.3	3 A1MnV= +0.00V	Analog Input 1 Minimum Range	45384	0 to 10V	0 a [G4.2.5]
G4.2.4	4 A1MnRf= +0.00%	Analog Input 1 Minimum Range Speed	45385	0 to 100%	0 a 10000
G4.2.5	5 A1MxV= +10.00V	Analog Input 1 Maximum Range	45386	0 to 10V	[G4.2.3] to 1000
G4.2.6	6 A1MxR= +100.00%	Analog Input 1 Maximum Range Speed	45387	0 to 100%	0 to 10000
G4.2.7	7 An1NgMn=+0.00V	Analog Input 1 Negative Minimum Range	45388	-10 to 0V	[G4.2.9] to 0
G4.2.8	8 A1MnR= +0.00%{	Analog Input 1 Minimum Negative Range	45389	-100 to 0%	-10000 to 0
G4.2.9	9 A1MxR= -10.00V	Analog Input 1 Maximum Negative Range	45390	-10 to 0V	-1000 to [G4.2.7]
G4.2.10	10 A1MxR= -100.00	Analog Input 1 Maximum Negative Range Speed	45391	-100 to 0%	-10000 to 0

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G4.2.11	11 A1DeLi= 0.04	Analog Input 1 Quantification Level	45393	0.04 to 10%	4 to 1000
G4.3.1	1 Ain2LPF= 10ms	Low Pass Filter for Analog Input 2	45398	0 to 10000ms	0 to 10000
G4.3.2	2 A2MnC= 4.00mA	Analog Input 2 Minimum Range	45399	0 to 20mA	0 to [G4.3.4]
G4.3.3	3 A2MnR= +0.00%	Analog Input 1 Minimum Range Speed	45400	0 to 100%	0 to 10000
G4.3.4	4 A2MxC= 20.00mA	Analog Input 2 Maximum Range	45401	4 to 20mA	[G4.3.2] to 20000
G4.3.5	5 A2MxR= +100.00%	Analog Input 2 Maximum Range Speed	45402	0 to 100%	0 to 10000
G4.3.6	6 A2DeLi= 0.04%	Analog Input 2 Quantification level	45408	0.04 to 10%	4 to 1000
G5.1	7 MxFqA=50.00Hz	Maximum frequency at analogue input	44355	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G5.2	1 ACC1= 20.0s	Acceleration Ramp 1	44356	0 to 600.0s	0 a 6000
G5.4	2 DECEL1= 30.0s	Deceleration Ramp 1	44616	0 to 600.0s	0 a 6000
G5.5	4 RmpT= MaxFreq	Type of Acceleration Ramp	44865	MaxFreq FrqDelta	0 1
G5.6	5 AccPn= Linear	Acceleration Pattern	44866	LINEAR S CURVE	0 1
G5.7	6 DecPn= Linear	Deceleration Pattern	44867	LINEAR S CURVE	0 1
G5.8	7 AcSSrt= +40%	S Curve Acceleration Starting Ramp	44868	1 to 100%	1 to 100
G5.9	8 AccSEnd= +40%	S-Curve Acceleration Ending Ramp	44869	1 to 100	1 to 100
G5.10	9 DelSSrt= +40%	S-Curve Deceleration Starting Ramp	44870	1 to 100	1 to 100
G5.11	10 DecSEnd=+40%	S-Curve Decelerating Ending Ramp	44884	1 to 100	1 to 100
G5.12	11 AccDWF= 5.00Hz	Acceleration Frequency Pause	44885	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G5.13	12 AccDWT= 0.0s	Acceleration Time Pause	44886	0 to 60s	0 to 600

Parameter	Screen	Description	Address	Range	Modbus Range
G5.14	14 DecDWT= 0.0s	Deceleration Time	44887	0 to 60.0s	0 to 600
G5.15	15 TDedFII= 3.0s	Fault Deceleration Time	46919	0 to 600.0s	0 to 6000
G5.16.1	1 ACC2= 20.0s	Alternative Acceleration Ramp 2	44678	0 to 600.0s	0 to 6000
G5.16.2	2 DEC2= 20.0s	Alternative Deceleration Ramp 2	44679	0 to 600.0s	0 to 6000
G5.16.3	3 ACC3= 30.0s	Alternative Acceleration Ramp 3	44680	0 to 600.0s	0 to 6000
G5.16.4	4 DEC3= 30.0s	Alternative Deceleration Ramp 3	44681	0 to 600.0s	0 to 6000
G5.16.5	5 ACC4= 40.0s	Alternative Acceleration Ramp 4	44682	0 to 600.0s	0 to 6000
G5.16.6	6 DEC4= 40.0s	Alternative Deceleration Ramp 4	44683	0 to 600.0s	0 to 6000
G6.1	1 SEL REF= MREF	Source Selection to introduce the set point	46164	MREF	0
				AI1	1
				AI2	2
				AI3	3
				AI4	4
				MODBUS	5
				COMMS	7
				PLC	8
G6.2	2 SEL FBK= AI1	Source Selection to Introduce the Feedback Signal	46165	MREF	0
				AI1	1
				AI2	2
				AI3	3
				AI4	4
				MODBUS	6
				COMMS	7
				PLC	
G6.3	3 GainKp= +50.0%	PID Regulator Gain	46166	0 to 1000.0%	0 to 10000
G6.4	4 INTEGRl= 10.0s	PID Regulator Integrating Time	46167	0 to 200.0s	0 to 2000
G6.5	5 T Der= 0ms	PID Regulator Differential Time	46168	0 to 1000ms	0 to 1000
G6.6	6 MxSL= +50.00Hz	PID Upper Frequency Limit	46173	[G6.8] to 300Hz	[G6.8] to 30000
G6.7	7 MnSL= 0.00Hz	PID Lower Frequency Limit	46174	-300 to [G6.7]Hz	-30000 to [G6.7]

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G6.8	8 INVERT PID= N	PID Output Inverting	46175	N Y	0 1
G6.9	9 OutSc= +100.0%	PID Output Scale	46176	0.1 to 1000%	1 to 10000
G7.1	1 START= RAMP	Start Mode	44871	RAMP DCSTART	0 1
G7.2	2 StrDly= 0.00s	Start Delay Time	45464	0 to 100.0s	0 to 10000
				RAMP	0
G7.3	3 STOP= RAMP	Stop Mode 1	44872	DC BRAKE SPIN POW BRKE	1 2 4
G7.4	4 SAFE STOP=N	Safe Stop	45197	N Y	0 1
G7.5	5 SFSStr= 125.0%	Safe Stop Start	45198	110 to 140%	1100 to 1400
G7.6	6 SFSStp = 130.0%	Safe Stop Ending	45199	130 to 145%	[G7.5] to 1450
G7.7	7 SFSGain= 1000	Safe Stop Gain	45200	1 to 2000	1 to 20000
G7.10	10 Run Aft Rst= N	Start after Low Voltage Fault	44874	N Y	0 1
G7.11	11 Str Aft Rst= N	Start after reset due to fault	46920	N Y	0 1
G7.12	12 DCSt T= 0.00s	Dc Start Time	44876	0 to 60.00s	0 to 6000
G7.13	13 DC Curr= 50%!	DC Current Start	44877	0 to 200%	0 to 200
G7.14	14 PreDC T= 0.10s	Previous DC Brake lock -Time	44878	0 to 60.00s	0 to 6000
G7.15	15 DCBrk T= 1.00s	DC Brake Time	44879	0 to 60.00s	0 to 6000
G7.16	16 DCBk Cur= 50%!	DC Brake Level	44880	0 to 200%	0 to 200
G7.17	17 DCBk F= 5.00Hz	DC Brake Frequency	44881	0 to 60.00Hz	0 to 6000
G8.1.1	1 OP FLT RLY= 0X0	Relay Output due to Fault	45662	000 to XXX	0 to 7

Parameter	Screen	Description	Address	Range	Modbus Range
G8.1.2	2 RLY1= Trip	Relay 1 Control Source Selection	45663	NONE FDT-1 FDT-2 FDT-3 FDT-4 OVERLOAD IOL UNDRLLOAD VENTWARN OVERVOLT LOWVOLT OVERHEAT RUN STOP STEADY SPD SRCH READY PUMP TRIP DBOVRLOAD COMPARAT BRCTRL	0 1 2 3 4 5 6 7 8 10 11 12 14 15 16 19 22 25 29 31 34 35
G8.1.3	3 RLE2= Run	Relay 2 Control Source Selection	45664	See [G8.1.2]	See [G8.1.2]
G8.1.4	4 DOP1= FDT-1	Digital Output 1 Control Source Selection	45665	See [G8.1.2]	See [G8.1.2]
G8.1.5	5 T RL ON= 0.00s	OP1 and Relays Connection Delay	45682	0 to 100.00s	0 to 10000
G8.1.6	6 T RL OF= 0.00	OP1 and Relays Disconnection delay	45683	0 to 100.00s	0 to 10000
G8.1.7	7 INV NA/NC= 000	Digital Output and Relay Contact Type Selection	45684	000 to XXX	0 to 65535
G8.2.1	1 A01= Frequency	Analog Output 1 Selection Mode	45633	Frequency O/pCurr O/pVolt DCLinkV O/p Power TargetFq RampFreq PIDRefVal PIDFdbVal PIDO/p Constant	0 1 2 3 5 8 9 12 13 14 15

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G8.2.2	2 AO1Ga= +100.0%	Analog Output 1 Gain	45634	-1000 to 1000%	-10000 to 10000
G8.2.3	3 AO1Ofst= +0.0%	Analog Output 1Offset Level	45635	-100 to 100%	-1000 to 1000
G8.2.4	4 AO1OFil = 5ms	Analog Output 1 Filter Selection	45636	0 to 10000ms	0 to 10000
G8.2.5	5 AO1Con= 0.0%	Analog Output 1Constant Value	45637	0 to 1000%	0 to 1000
G8.2.6	6 AO2= Frequency	Analog Output 2 Mode Selection	45639	See [G8.2.1]	See [G8.2.1]
G8.2.7	7 OA2Ga= +100.0%	Analog Output 2 Gain	45640	-1000 to 1000%	-10000 to 10000
G8.2.8	8 AO2Ofst= +0.0%	Analog Output Offset Level	45641	-100 to 100%	-1000 to 1000
G8.2.9	9 AO2Fil= 5ms	Analog Output 2 Filter Selection	45642	0 to 10000ms	0 to 10000
G8.2.10	10 AO2Con= 0.0%	Analog Output 2 Constant Value	45643	0 to 1000%	0 to 1000
G9.1	1 FDTLvl= 30.00Hz	Transfer Function Level	45689	0 to [G10.1]Hz	0 to [G10.1]
G9.2	2 FDTBnd= 10.00Hz	Transfer Function Bandwidth	45690	0 to [G10.1]Hz	0 to [G10.1]
G9.3	3 SLCOM= None	Comparator Source Selection	44930	None	0
				A1	1
				A12	2
				A13	3
				A14	4
G9.4	4 S C ON= +90.00%	Output Activation Level in Comparator Mode	44931	10 to 100%	[G9.5] to10000
G9.5	5 S C OF= +10.00%	Output Deactivation Level in Comparator Mode	44932	-100 to [G9.4]%	-10000 to [G9.4]
G10.1	1 MxSpL= 50.00Hz	Maximum Speed Limit	44372	40 to 400Hz	4000 to 40000
G10.2	2 FWR/RV= None	Speed Inverting Permission	44873	None FWDPrev RevPrev	0 1 2
G10.3	3 UseFrqLimit=Y	Frequency Limit	44888	N Y	0 1
G10.4	4FqLtLo= 0.50Hz	Lower Frequency Limit	44889	0 to [G10.5]	0 to [G10.5]
G10.5	5 FqLtHi= 50.00Hz	Upper Frequency Limit	44890	0.5 to [G10.1]	[G10.4] to [G10.1]

Parameter	Screen	Description	Address	Range	Modbus Range
G10.6	6 TORQUE LIMIT= N	Torque Limit Activation	46962	N Y	0 1
G10.7	7 LvTrqLt= 180%	Torque Limit Level	46964	30 to 250%	30 to 250
G11.1	1 RIRLs= None	Response in case of a Speed Reference Loss	46917	None FreeRun Dec Hold I/P Hold O/P LostPrst	0 1 2 3 4 5
G11.2	3 RflsDly= 1.0s	Trip Delay Time Due to Speed Reference Loss	46924	0.1 to 120s	1 to 1200
G11.3	4 RefLRf= 0.00Hz	Speed in case of Reference Loss	46925	[G19.2.5] to [G10.1]Hz	[G19.2.5] to [G10.1]
G11.4	5 OLWarnSel= NO	Overload Warning	46926	NO YES	0 1
G11.5	6 OLWrnL= +150%	Overload Warning Level	46929	30 to 200%	30 to [G11.9]
G11.6	7 OLWrnT= 10.0s	Delay Time for Enabling the Overload Warning	46930	0 to 30.0s	0 to 300
G11.7	8 OLTS= FreeRun	Action Selection due to Overload Fault	46931	None FreeRun Dec	0 1 2
G11.8	9 OLLevel= 180%	Trip Level in case of Overload Fault	46932	30 to 200%	30 to 200
G11.9	10 TFIISc= 60.0s	Overload delay time	46933	0 to 60.0s	0 to 600
G11.10	11 SBC1min= +150%	Overcurrent level during 1 minute	46934	120 to 200%	[G11.12] to 200
G11.11	12 SBCCont= 120%	Continuous overcurrent level	46954	50 to 200%	50 to [G11.11]
G11.12	6 TORQUE LIMIT= N	Torque Limit Activation	46955	N Y	0 1

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G11.13	13 ThMM= None	Action Selection in case of Thermo-electronic Fault	46952	None FreeRun Dec	0 1 2
G11.14	14 EnableUL= NO	Enabling Underload Alarm	46937	NO YES	0 1
G11.15	15 ULWnDI= 10.0s	Delay Time Enabling Underload Warning	46938	0 to 600.0s	0 to 6000
G11.16	16 ULFM= None	Action Selection in case of Underload Fault	46939	None FreeRun Dec	0 1 2
G11.17	17 ULFltDI= 30.0s	Delay Time Enabling Underload Fault	46940	0 to 600.0s	0 to 6000
G11.18	18 UIMnL = +30%	Underload Detection Lower Level	46941	10 to [G11.18]	10 to [G11.18]
G11.19	19 ULMxL = +30%	Underload Detection Upper Level	46942	[G11.17] to 100%	[G11.17] to 100
G11.20	20 NoMD= None	Action Selection in case of No Motor Connection Detected Fault	46943	None FreeRun	0 1
G11.21	21 NoMtrLvl= +5%	Trip Level in case of No Motor Detection Fault	46944	1 to 100%	1 to 100
G11.22	22 NoMtrDI= 3.0s	Delay Time due to Lack of motor Fault	46945	0.1 to 10.0s	1 to 100
G11.23	23 OvHM= None	Selection in case of Motor Overheat Fault	46946	None FreeRun Dec	0 1 2
G11.24	24 OvrHtSen= None	Motor Overheat Detection Sensor Selection	46947	None	0
				AI1	1
				AI2	2
				AI3	3
				AI4	4
G11.25	25 OvrHtL= +50.0%	Motor Overheat Detection Fault	46948	0 to 100%	0 to 1000
G11.26	26 OvrHtAr= Low	Trip Area Selection Due to Overheat.	46949	LOW HIGH	0 1

Parameter	Screen	Description	Address	Range	Modbus Range
G11.27	27 FANTrip=Trip	Action Selection in case of Fan Trip	46991	Trip Warn	0 1
G11.28	28 DBWarnED= +0%	Brake Unit Overload Warning Level	46978	0 to 30%	0 to 30
G12.1	29 LSS PH= NONE	Phase loss Detection	46921	NONE OUTPUT INPUT ALL	0 1 2 3
G12.2	30 Ripple V=40V	DC Bus Ripple voltage	46922	1 to 100V	1 a 100
G13.1	1 Retry NUm= 0	Delay Time before Auto Reset	-	0 to 10	0 to 10
G13.1.1	2 Retry Dly= 1.0s	Delay Time before Auto Reset	-	0 to 60.0s	0 to 600
G13.1.2	No Fault	Current Fault status visualization	-	-	-
G13.1.3	FAULT INFO 1	Fault History Register 1	-	-	-
G13.1.4	FAULT INFO 2	Fault History Register 2	-	-	-
G13.1.5	FAULT INFO 3	Fault History Register 3	-	-	-
G13.1.6	FAULT INFO 4	Fault History Register 4	-	-	-
G13.2.1	FAULT INFO 5	Fault History Register 5	-	-	-
G13.2.2	Clr FaultHist= N	Clear Fault History	-	N Y	-
G13.2.3	ENB/DIS LV Flt=D	Low Voltage fault register	-	-	-
G13.2.4	1 MREF 1= 10.00Hz	Multi-Reference 1	-	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G13.2.5	2 MREF 2= 20.00Hz	Multi-Reference 2	-	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.1	27 FANTrip=Trip	Action Selection in case of Fan Trip	44658	Trip Warn	0 1
G14.2	28 DBWarnED= +0%	Brake Unit Overload Warning Level	44659	0 to 30%	0 to 30

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G14.3	3 MREF 3= 30.00	Multi-Reference 3	44660	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.4	4 MREF 4= 40.00H	Multi-Reference 4	44661	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.5	5 MREF 5= 50.00Hz	Multi-Reference 5	44662	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.6	6 MREF 6= 50.00Hz	Multi-Reference 6	44663	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.7	7 MREF 7= 50.00Hz	Multi-Reference 7	44664	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.8	8 MREF 8= 50.00Hz	Multi-Reference 8	44665	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.9	9 MREF 9= 50.00Hz	Multi-Reference 9	44666	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.10	10 MRF 10= 45.00Hz	Multi-Reference 10	44667	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.11	11 MRF 11= 40.00Hz	Multi-Reference 11	44668	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.12	12 MRF 12= 35.00Hz	Multi-Reference 12	44669	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.13	13 MRF 13= 25.00Hz	Multi-Reference 13	44670	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.14	14 MRF 14= 15.00Hz	Multi-Reference 14	44671	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G14.15	15 MRF 15= 5.00Hz	Multi-Reference 15	44672	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G15.1	1 InchFq= 10.00Hz	Inch Frequency	44363	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G15.2	2 InchAcT= 20.0s	Inch Frequency Accelerating Time	44364	0 to 600.0s	0 to 6000
G15.3	3 InchDeT= 30.0s	Inch Frequency Decelerating Time	44365	0 to 600.0s	0 to 6000
G16.1	1 Jmp Freq= NO	Enabling Frequency Jumps	44891	NO YES	0 1
G16.2	2 Sal1 B= 10.00Hz	Frequency Jump 1 Lower Limit	44892	0 to [G16.3]	0 to [G16.3]
G16.3	3 Sal1 A= 15.00Hz	Frequency Jump 1 Upper Limit	44893	[G16.2] to [G10.1]	[G16.2] to [G10.1]
G16.4	4 Sal2 B= 20.00Hz	Frequency Jump 2 Lower Limit	44894	0 to [G16.5]	0 to [G16.5]
G16.5	5 Sal2 A= 25.00Hz	Frequency Jump 2 Upper Limit	44895	[G16.4] to [G10.1]	[G16.4] to [G10.1]
G16.6	6 Sal3 B= 30.00Hz	Frequency Jump 3 Lower Limit	44896	0 to [G16.7]	0 to [G16.7]

Parameter	Screen	Description	Address	Range	Modbus Range
G16.7	7 Sal3 A= 35.00Hz	Frequency Jump 3 Upper Limit	44897	[G16.6] to [G10.1]	[G16.6] to [G10.1]
G17.1	1 RlsCurr= 50.0%	Opening Brake Current	44905	0 to 180.0%	0 to 1800
G17.2	2 RlsDly= 1.00s	Opening Brake Delay	44906	0 to 10.0s	0 to 1000
G17.3	3 FwdFrq= 1.00Hz	Opening Brake Frequency (Forward)	44908	0 to 400.0Hz	0 to 40000
G17.4	4 RevFrq= 1.00Hz	Opening Brake Frequency (Reverse)	44909	0 to 400.0Hz	0 to 40000
G17.5	5 BrEngFr= 1.00s	Closed Brake Delay	44910	0 to 10.0s	0 to 1000
G17.6	6 BrEngFr= 2.00Hz	Closed Brake Frequency	44911	0 to 400.0Hz	0 to 40000
G19.1.1	1 CTRL T.= V/Hz	Control Type Selection	44361	V/Hz SlipCom S-less1	0 2 3
G19.1.2	2 FREQ= 2.0kHz	Modulation Frequency	45124	0.7 to 15kHz	7 to 150
G19.1.3	3 V/FPn= Linear	V/F Pattern	44615	Linear Square V/F Us	0 1 2
G19.1.4.1	1 UsFrq1= 15.00Hz	User Frequency 1	44649	0 to [G10.1]	0 to [G10.1]
G19.1.4.2	2 User V1= 25%	User Voltage 1	44650	0 to 100%	0 to 100
G19.1.4.3	3 UsFrq2= 30.00Hz	User Frequency 2	44651	0 to [G10.1]	0 to [G10.1]
G19.1.4.4	4 User V2= 50%	User Voltage 2	44652	0 to 100%	0 to 100
G19.1.4.5	5 Us Frq3= 45.00Hz	User Frequency 3	44653	0 to [G10.1]	0 to [G10.1]
G19.1.4.6	6 User V3= 75%	User Voltage 3	44654	0 to 100%	0 to 100
G19.1.4.7	7 Us Frq4= 60.00Hz	User Frequency 4	44655	0 to [G10.1]	0 to [G10.1]
G19.1.4.8	8 User V4= 100%	User Voltage 4	44656	0 to 100%	0 to 100
19.2.1	1 InertiaRate= 0	Inertia Range	44625	0 to 8	0 to 8
G19.2.2	2 T Boost= Manual	Initial Voltage	44367	MANUAL AUTO	0 1
G19.2.3	3 FWBoost= +20%	Starting Torque (Forward Direction)	44368	0 to 150%	0 to 150
G19.2.4	4 RVBoost= +20%	Starting Torque (Reverse Direction)	44369	0 to 150%	0 to 150
G19.2.5	5 STR FRQ= 0.50Hz	Starting Frequency	44371	0.01 to 10Hz	1 to 1000

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G19.2.6	6 RtSlip= 45rpm	Slip Compensation	44620	0 to 3000rpm	0 to 3000
G19.2.7	7 FLUX MIN= NONE	Minimum Flux	44914	NONE MANU AUTO	0 1 2
G19.2.8	8 FLUX LVEL= +0%	Manual Mode Minimum Flux Value	44915	0 to 30%	0 to 30
G19.2.9	9 Load Duty= Hevy	Load Type Definition	46916	NRML HEVY	0 1
G19.3.1	1 Rs=	Stator Resistor (Rs)	44629	-	-
G19.3.2	2 LSigma=	Leak Inductor	44630	-	-
G19.3.3	3 Ls=	Stator Inductor	44631	-	-
G19.3.4	4 Tr=	Rotor Time Constant	44632	25 to 5000ms	25 to 5000
G20.1.1	1 ComUpdate= NO	Communication Update	45982	NO YES	0 1
G20.1.2	2 Slave Addr= 1	Communication Address	45889	1 to 250	1 to 250
G20.1.3	3 Prot= ModBus	Int485 Communication Protocol	45890	MODBUS	0
G20.1.4	4 BaudR= 9600 bps	Communication Speed	45891	1200	0
				2400	1
				4800	2
				9600	3
				19200	4
				38400	5
G20.1.5	5 Mode= D8/PN/S1	Communication Frame Definition	45892	D8/PN/S1	0
				D8/PN/S2	1
				D8/PE/S1	2
				D8/PO/S1	3
G20.1.6	6 RespDly= 5ms	Transfer Delay After Reception	45893	0 to 1000ms	0 to 1000
G20.1.7	7 ParamSave= NO	Saving Communication Parameters	40992	NO YES	0 1
G25.1.1	1 MREF1= 10.00%	PID Local Reference 1	44658	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G25.1.2	2 MREF2= +20.00%	PID Local Reference 2	44659	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G25.1.3	3 MREF3= +30.00%	PID Local Reference 3	44660	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G25.1.4	4 MREF4= +40.00%	PID Local Reference 4	44661	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G25.1.5	5 MREF5= +50.00%	PID Local Reference 5	44662	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]

Parameter	Screen	Description	Address	Range	Modbus Range
G25.1.6	6 MREF6= +50.00%	PID Local Reference 6	44663	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
G25.1.7	7 MREF7= +50.00%	PID Local Reference 7	44664	[G19.2.5] to [G10.1]	[G19.2.5] to [G10.1]
				MREF	0
				AI1	1
				AI2	2
G25.2.1	1 PIDSetup= MREF	PID Setpoint Source	46164	AI3	3
				AI4	4
				MODBUS	5
				COMMS	7
				PLC	8
				MREF	0
				AI1	1
				AI2	2
G25.2.2	2 PID Fbk= AI2	PID Feedback Source	46165	AI3	3
				AI4	4
				MODBUS	6
				COMMS	7
				PLC	
G25.2.3	3 PID Kc= +50.0%	PID Regulator Proportional Gain	46166	0 to 1000%	0 to 10000
G25.2.4	4 PID It= 10.0s	PID Regulator Integrating Time	46167	0 to 200s	0 to 2000
G25.2.5	5 PID Dt= 0.0s	Pid Regulator Differential Time	46168	0.0 to 1000ms	0 to 1000
G25.2.6	6 MxSL= +50.00Hz	PID Frequency Upper Limit	46173	[G25.2.7] to 300Hz	[G25.2.7] to 30000
G25.2.7	7 MnSL= 0.00Hz	PID Frequency Lower Limit	46174	-300 to [G25.2.6] Hz	-30000 to [G25.2.6]
G25.2.8	8 InvertPID= N	PID Output Inverting	46175	NO	0
				SI	1
G25.2.9	9 Out Sc= +100.0%	PID Output Scale	46176	0.1 to 1000%	1 to 10000
G25.3.1	1 LP Pon= 35%	Awakening Level	46183	0 to 100%	0 to 100
G25.3.2	2 FP1 Son= 49.99Hz	Fix Pump 1 Starting Speed	46679	0 to [G10.1]Hz	0 to [G10.1]
G25.3.3	3 FP2 Son = 49.99Hz	Fix Pump 2 Starting Speed	46680	0 to [G10.1]Hz	0 to [G10.1]
G25.3.4	4 FP3 Son = 49.99Hz	Fix Pump 3 Starting Speed	46681	0 to [G10.1]Hz	0 to [G10.1]

E
N
G
L
I
S
H

Parameter	Screen	Description	Address	Range	Modbus Range
G25.3.5	5 FP4 Son = 49.99Hz	Fix Pump 4 Starting Speed	46682	0 to [G10.1]Hz	0 to [G10.1]
G25.3.6	6 FP Ton= 60.0s	Fix Pumps Starting Delay	46687	0 to 3600s	0 to 36000
G25.4.1	1 LP T Slpr= 60.0s	Delay Before Enabling Sleep Mode	46181	0 to 999.0s	0 to 9999
G25.4.2	2 Slp Spd= 0.00Hz	Enabling Sleep Mode Speed	46182	0 to [G10.1]	0 to [G10.1]
G25.4.3	3 SPD1of= 15.0H	Fix Pump 1 Stopping Speed	46683	0 to [G10.1]Hz	0 to [G10.1]
G25.4.4	4 SPD2of = 15.0Hz	Fix Pump 2 Stopping Speed	46684	0 to [G10.1]Hz	0 to [G10.1]
G25.4.5	5 SPD3of = 15.0Hz	Fix Pump 3 Stopping Speed	46685	0 to [G10.1]Hz	0 to [G10.1]
G25.4.6	6 SPD4of = 15.0Hz	Fix Pump 4 Stopping Speed	46686	0 to [G10.1]Hz	0 to [G10.1]
G25.4.7	7 Fp Tof= 60.0s	Stopping Fix Pump Delay	46688	0 to 3600s	0 to 36000
G25.4.8	8 FP Error= 2%	PID Maximum Error Stopping Fix Pumps	46696	0 to 100%	0 to 100
G25.5.1	1 AccTime= 2.0s	Main Motor Accelerating Time after Fix Pump Stop	46697	0 to 600s	0 to 6000
G25.5.2	2 Dec Timel= 2.0s	Main Motor Accelerating Time after Fix Pump Activation	46698	0 to 600s	0 to 6000
G25.7.1	1 Fill Sp= 0.00Hz	Filling Pipes Speed	46178	0 to [G10.1]	0 to [G10.1]
G25.7.2	2 Fill P= 0.0%	Filling Pipes Pressure	46179	0 to 100%	0 to 1000
G25.7.3	3 Fill Tim= 600s	Filling Pipes Delay	46180	0 to 9999s	0 to 9999
G25.9.1	1 First FP= 1	First Fixed Pump Selection	46677	1 to 4	1 to 4
G25.9.2	2 FP number= 0	Number of Fixed Pumps Selection	46689	0 to 4	0 to 4

8.3. Visualization parameters

Parameter	Screen	Description	Address	Modbus Range
STATUS LINE	OFF 0.0A +0.0Hz	Present drive status. Modbus value for the status of the drive and for the fault and warning messages.	40014	0 to 201

Modbus Value → STATUS MESSAGE

0 →	FLT	4 →	ACL
1 →	DCB	5 →	RUN
2 →	STP	6 →	RDY
3 →	DCL		

Note: See status messages description in section 'Status Messages'.

STATUS LINE	OFF 0.0A +0.0Hz	Motor output current (Corresponds to SV1.1)	40784	Real Value = (Modbus Value / 10)
STATUS LINE	OFF 0.0A +0.0Hz	Motor output speed (in %). (Corresponds to SV1.2)	40785	Real Value = (Modbus Value / 100)

Parameter	Screen	Description	Address	Modbus Range
SV1.1	Mtr I out=0.0	Shows the current running through the motor, corresponding to the second field of the status line → OFF 0.0A +0.0Hz	40784	Real Value = (Modbus Value / 10)
SV1.2	Mtr Freq= 0.00Hz	Shows the motor frequency	40785	Real Value = (Modbus Value / 100)
SV1.3	Mtr Sp= 0rpm	Shows the motor speed in rpm	40786	Real Value = Modbus Value
SV1.4	Mtr FBSp=+0rpm	Motor feedback speed	40787	Real Value = Modbus Value
SV1.5	Mtr Vout=0V	Shows the motor voltage.	40788	Real Value = Modbus Value

Parameter	Screen	Description	Address	Modbus Range
SV1.6	Mtr Pow = 0.00kW	Shows the motor instantaneous power consumption	40790	Real Value = (Modbus Value / 10)
SV1.7	Mtr Torqe = 0.0%	Shows the torque applied to the motor.	40791	Real Value = (Modbus Value / 10)
SV2.1	Bus vol= 528V	Shows the DC voltage measured in the driver bus.	40789	Real Value = Modbus Value
SV3.1	ANLG IN1 = +0.0V	Shows the Analogue Input 1 mean value	45381	Real Value = Modbus Value
SV3.2	ANLG IN2 = +0.0mA	Shows the Analogue Input 2 mean value	45396	Real Value = (Modbus Value / 100)
SV3.3	Digl= 00000000	Shows the activation or rest status of the Digital Inputs, from left to right ED8 to ED1.	40016	Real Value = (Modbus Value / 100)
SV3.4	ANL OUT1 = 0.0%	Shows the value of the Analogue Output 1	45638	Real Value = Modbus Value
SV3.5	ANLG IN2 = +0.0mA	Shows the Analogue Input 2 mean value.	45644	Real Value = (Modbus Value / 10)
SV3.6	DOstatus= 0-00	Shows the status of the digital outputs in the following order: SD1-Relay2 Relay1	45673	Real Value = (Modbus Value / 10)
SV4.1	Inv.Power=	Shows the drive capacity in kW	40769	Real Value = Modbus Value
SV4.2	Inv. S/W	Shows the last software version installed	40771	Real Value = Modbus Value
SV4.3	SW Disp=	Last software version installed in the display.	-	Real Value = Modbus Value
SV5.1	S=0.0% F=0.0%	Shows PID Setpoint and Feedback.	40792-40793	-
SV5.2	PID Out=+0.00%	Shows the t PID Output	46160	Real Value = (Modbus Value / 10)
SV8.1	S=0.0% F=0.0%	Shows PID Setpoint and Feedback.	40792-40793	Real Value = (Modbus Value / 100)
SV8.2	Sal PID=+0.00%	Shows the PID output	46160	Real Value = (Modbus Value / 10)
SV8.3	No Bmb Ma=0	Shows the number of pumps running	46676	Real Value = (Modbus Value / 100)
SV8.4.1	1 MREF1= +10.00%	PID Local Reference 1	44658	Real Value = Modbus Value

Parameter	Screen	Description	Address	Modbus Range
SV8.4.2	2 MREF2= +20.00%	PID Local Reference 2	44659	[G19.2.5] to [G10.1]
SV8.4.3	3 MREF3= +30.00%	PID Local Reference 3	44660	[G19.2.5] to [G10.1]
SV8.4.4	4 MREF4= +40.00%	PID Local Reference 4	44661	[G19.2.5] to [G10.1]
SV8.4.5	5 MREF5= +50.00%	PID Local Reference 5	44662	[G19.2.5] to [G10.1]
SV8.4.6	6 MREF6= +50.00%	PID Local Reference 6	44663	[G19.2.5] to [G10.1]
SV8.4.7	7 MREF7= +50.00%	PID Local Reference 7	44664	[G19.2.5] to [G10.1]

E
N
G
L
I
S
H

E
N
G
L
I
S
H



POWER ELECTRONICS®

www.powerelectronics.es | www.power-electronics.com

24 Hours Technical Assistance 365 days a year

+34 96 136 65 57

HEADQUARTER • VALENCIA • SPAIN

C/ Leonardo da Vinci, 24 – 26 • Parque Tecnológico • 46980 – PATERNA • VALENCIA • ESPAÑA
Tel. 902 40 20 70 • Tel. (+34) 96 136 65 57 • Fax (+34) 96 131 82 01

BRANCHES

CATALUÑA	BARCELONA • Avda. de la Ferrería, 86-88 • 08110 • MONTCADA I REIXAC Tel. (+34) 96 136 65 57 • Fax (+34) 93 564 47 52
	LLEIDA • C/ Terrasa, 13 - Bajo • 25005 • LLEIDA Tel. (+34) 97 372 59 52 • Fax (+34) 97 372 59 52
CANARIAS	LAS PALMAS • C/ Juan de la Cierva, 4 • 35200 • TELDE Tel. (+34) 928 68 26 47 • Fax (+34) 928 68 26 47
	VALENCIA • Leonardo da Vinci, 24-26 • 46980 • PATERNA Tel. (+34) 96 136 65 57 • Fax (+34) 96 131 82 01
LEVANTE	CASTELLÓN • C/ Juan Bautista Poeta • 2º Piso - Puerta 4 • 12006 • CASTELLÓN Tel. (+34) 96 434 03 78 • Tel. (+34) 96 136 65 57 • Fax (+34) 96 434 14 95
	MURCIA • Prol. Residencial Santa Ana • Avda. Venecia, 17 • 30319 • CARTAGENA Tel. (+34) 96 853 51 94 • Fax (+34) 96 812 66 23
NORTE	VIZCAYA • Parque de Actividades • Empresariales Asuarán • Edificio Asúa, 1º B • Ctra. Bilbao - Plencia • 48950 • ERANDIO • Tel. (+34) 96 136 65 57 • Fax (+34) 94 431 79 08
CENTRO	MADRID • Avda. Rey Juan Carlos I, 98, 4º C • 28916 • LEGANÉS Tel. (+34) 96 136 65 57 • Fax (+34) 91 687 53 84
SUR	SEVILLA • C/ Averroes, 6 • Edificio Eurosevilla • 41020 • SEVILLA Tel. (+34) 96 136 65 57 • Fax (+34) 95 451 57 73
GALICIA	LA CORUÑA • Plaza Agramar, 5 - Bajo - Perillo - Oleiros • 15172 • LA CORUÑA Tel. (+34) 96 136 65 57 • Fax (+34) 98 163 45 83
INTERNATIONAL SUBSIDIARIES	
GERMANY	Power Electronics Deutschland GmbH • Dieselstrasse, 77 • D-90441 • NÜRNBERG • GERMANY Tel. (+49) 911 99 43 99 0 • Fax (+49) 911 99 43 99 8
AUSTRALIA	Power Electronics Australia Pty Ltd • U6, 30-34 Octal St, Yatala, • BRISBANE, QUEENSLAND 4207 • P.O. Box 3166, Browns Plains, Queensland 4118 • AUSTRALIA Tel. (+61) 7 3386 1993 • Fax (+61) 7 3386 1997
BRAZIL	Power Electronics Brazil Ltda • Av. Guido Caló, 1985-Galpão 09 • CEP 05802-140 • SÃO PAULO • BRASIL Tel. (+55) 11 5891 9612 • Tel. (+55) 11 5891 9762
CHILE	Power Electronics Chile Ltda • Los Productores # 4439 – Huechuraba • SANTIAGO • CHILE Tel. (+56) (2) 244 0308 - 0327 - 0335 • Fax (+56) (2) 244 0395
	Oficina Petronila # 246, Casa 19 • ANTOFAGASTA • CHILE Tel. (+56) (55) 793 965
CHINA	Power Electronics Beijing • Room 509, Yiheng Building • No 28 East Road, Beisanhuan • 100013, Chaoyang District • BEIJING • R.P. CHINA Tel. (+86 10) 6437 9197 • Fax (+86 10) 6437 9181 Power Electronics Asia Ltd • 20/F Winbase Centre • 208 Queen's Road Central • HONG KONG • R.P. CHINA
KOREA	Power Electronics Asia HQ Co • Room #305, SK Hub Primo Building • 953-1, Dokok-dong, Gangnam-gu • 135-270 • SEOUL • KOREA Tel. (+82) 2 3462 4656 • Fax (+82) 2 3462 4657
INDIA	Power Electronics India • No 26 3rd Cross, • Vishwanathapuram • 625014 • MADURAI Tel. (+91) 452 434 7348 • Fax (+91) 452 434 7348
MEXICO	P.E. Internacional Mexico S de RL • Calle Cerrada José Vasconcelos, 9 • Colonia Tlalnepantla Centro • Tlalnepantla de Baz • CP 54000 • MEXICO DF Tel. (+52) 55 5390 8818 • Tel. (+52) 55 5390 8363 • Tel. (+52) 55 5390 8195
NEW ZEALAND	Power Electronics Nueva Zelanda Ltd • 12A Opawa Road, Waltham • CHRISTCHURCH 8023 • P.O. Box 1269 CHRISTCHURCH 8041 Tel. (+64 3) 379 98 26 • Fax. (+64 3) 379 98 27



www.power-electronics.com