

**V6**

# **ACCESSORIES MANUAL**

## **PROFINET BOARD**



**DIGITAL SOFTSTARTER**



**V6**

*DIGITAL SOFTSTARTER*

---

# Programming and Software Manual

**Edition: June 2023**

Rev. A

# ABOUT THIS DOCUMENT

## COMPATIBILITY

This manual is suitable for Profinet Card with Ground Fault.

The Profinet Card is suitable for use with V6 soft starters.

The available features may vary according to the model and version of the starter.

## DISCLAIMER

The examples and diagrams in this manual are included solely for illustrative purposes. The information contained in this manual is subject to change at any time and without prior notice. In no event will responsibility or liability be accepted for direct, indirect or consequential damages resulting from the use or application of this equipment.

Failure to follow the information and instructions in this manual will void the warranty.

EN

## POWER ELECTRONICS CONTACT INFORMATION

Power Electronics USA Inc.

1510 N. Hobson Street, Gilbert,

Phoenix

AZ 85233

UNITED STATES OF AMERICA

US Sales: 602-354-4890 / (480) 519-5977

Power Electronics España, S.L.

Polígono Industrial Carrases

Ronda del Camp d'Aviació nº 4

46160, Llíria (Valencia)

SPAIN

Telephone: (+34) 96 136 65 57

Website: [www.power-electronics.com](http://www.power-electronics.com)

**REVISIONS CONTROL**

---

DATE	REVISION	DESCRIPTION
30/06/2023	A	First edition.

---

---

The equipment and technical documentation are periodically updated. Power Electronics reserves the right to modify all or part of the contents of this manual without previous notice. To consult the most updated information of this product, you may access our website [www.power-electronics.com](http://www.power-electronics.com), where the latest version of this manual can be downloaded. The reproduction or distribution of the present manual is strictly forbidden, unless express authorization from Power Electronics.

# SAFETY SYMBOLS

Always follow safety instructions to prevent accidents and potential hazards from occurring.

In this manual, safety messages are classified as follows:



## NOTICE

Indicates a hazard that may cause personal injury or death.



## CAUTION

Indicates a hazard that may damage the equipment or installation.



## WARNING

Provides helpful information.

Other symbols used in this manual for safety messages are the following:



Hot surface. Be careful and follow the instructions to avoid burns and personal injuries.



Risk of fire. Be careful and follow the instructions to prevent causing an unintentional fire.



Energy storage timed discharge. Wait for the indicated time to avoid electrical hazards.



Caution, risk of hearing damage. Wear hearing protection.

## Warnings

It is the installer's responsibility to follow all instructions in this manual and to follow correct electrical practice.



## WARNING

For your safety, isolate the soft starter completely from mains voltage before attaching or removing accessories.



## WARNING

Inserting foreign objects or touching the inside of the starter while the expansion port cover is open may endanger personnel, and can damage the starter.

# TABLE OF CONTENTS

1	INTRODUCTION.....	6
2	INSTALLATION.....	8
3	DEVICE CONFIGURATION .....	10
4	MASTER CONFIGURATION.....	15
5	GROUND FAULT PROTECTION.....	16
6	OPERATION.....	18
7	PACKET STRUCTURES.....	19
8	NETWORK DESIGN.....	28
9	SPECIFICATIONS.....	31

# 1 INTRODUCTION


# 1

## Product design

The Profinet Card allows the soft starter to connect to an Ethernet network and be controlled or monitored using an Ethernet communication model.

Familiarity with Ethernet protocols and networks is required to operate the device successfully. For difficulties using this device with third party products, including PLCs, scanners and commissioning tools, contact the relevant supplier.

### 1.1 Connections




1	2 x RJ45 ethernet ports, supporting line, star, ring and loop network topologies
2	2 pin connector for ground fault CT (selected models)
3	DB9 connector for optional remote keypad

## Network connection

The Profinet Card supports the following protocols:

Profinet	Industrial ethernet via Profinet
MQTT	Message Queue Telemetry Transport
OPC UA	Open Platform Communications Unified Architecture



1	Soft starter
2	Network switch
3	IoT connection (MQTT/OPC UA)
4	Industrial ethernet connection to programmable logic controller


EN

## 2 INSTALLATION

# 2

### Installing the expansion card

1. Push a small flat-bladed screwdriver into the slot in the centre of the expansion port cover, and ease the cover away from the starter.
2. Line up the card with the expansion port. Gently push the card along the guide rails until it clicks into the starter.



EN

### Network connection

#### Ethernet ports

The device has two Ethernet ports. If only one connection is required, either port can be used.

#### Cables

Use Category 5, 5e, 6 or 6e cable to connect to the device.

#### EMC precautions

To minimise electromagnetic interference, Ethernet cables should be separated from motor and mains cables by 200 mm.

If the Ethernet cable must cross motor or mains cables, the crossing should be at an angle of 90°.

### Network establishment

The controller must establish communications directly with each device before the device can participate in the network.

## Addressing

Each device in a network is addressed using a MAC address and a device name. The MAC address is fixed within the device and is printed on a label on the front of the device.

**EN**

## 3 DEVICE CONFIGURATION


# 3

### Configure the device name


Use the Ethernet Device Configuration Tool to configure the device. The Ethernet Device Configuration Tool is available from your local supplier.

To identify the device using the Ethernet Device Configuration Tool:

1. Start the Ethernet Device Configuration Tool.
2. Click on Search Devices. The software will search for connected devices.



3. To configure a device name, click Configure then select Device Name.



#### NOTICE

The Error LED is on if the device is not configured. If the device is configured but is not passing I/O data, the Error LED will flash. The Error LED will be active during the configuration process.



#### NOTICE

If your PC has a firewall enabled, you must add the tool to the list of authorised programs.

## Enabling network control

The soft starter will only accept commands from the Profinet Card if parameter 1A *Command Source* is set to 'Network'.



### NOTICE

If the reset input is active, the starter will not operate. If a reset switch is not required, use parameter 7I to set the reset input to normally open or fit a link across terminals 10, 11 on the soft starter.


## On-board web server

Settings in the Profinet Card can be configured via the card's web server.

### Connect to the device

To configure settings using the on-board web server, the card must be installed in a soft starter, control power must be available, and the card and computer must both be connected to the Ethernet network.

The computer must use a fixed IP address (not DHCP) and the same subnet mask as the card. The default IP address for the card is 192.168.0.2. The default subnet mask is 255.255.255.0.



20543.A

Once connected, the web server reports basic information about the card and the soft starter.

EN

Home Configuration IP Setting Administration

### Profinet Adapter with TCP/IP Socket and IoT

Configuration and diagnostic information.

Module Info	
Parameter	Value
Protocol	Profinet Adapter
Protocol Stack Version	V2.13.0.22
Starter Name	SoftStart
Starter Serial Number	558891-027
Starter Rating String	0024BP-V5-C-H
Starter Interface Version	V3.0
Starter Motor Version	V3.0

NetX-52 Info	
Parameter	Value
Serial Number	37130
Production Date	2018-12-09T00:00:00Z
Quality Assurance Date	2018-12-09T00:00:00Z
Production Location	
Mac Address	00:02:A2:50:F9:3A

22533.A

EN

## Manage users and passwords



### NOTICE

For security reasons, we recommend that you define a custom administrator ID and password.

The default username and password are:  
 username: admin  
 password: 1978



### NOTICE


Version 2.x of the Profinet Card does not support custom users.

The Profinet Card supports multiple users and levels of privilege.

- Users can view the home screen and IP address settings
- Supervisors can view the home screen and IP settings and can change configuration settings
- Administrators can view the home screen, change configuration settings and add or delete users

To add a new user:

1. Connect to the web server then click Administration.
2. Click Create new user.
3. Enter the new username and password then click Create an account.
4. Set privileges (user, supervisor, administrator) as appropriate.
5. Click Save changes.



To delete a user:

1. Connect to the web server then click Administration.
2. Click the required entry in the user list then click Delete user. Click Delete again to confirm the action.

## Configure IoT settings

The Profinet Card supports soft starter status monitoring over IoT. The card cannot control or program the soft starter.



### NOTICE

Version 2.x of the Profinet Card does not support IoT operation.

- **Configure MQTT settings**

1. Connect to the web server then click Configuration > MQTT Client.
2. Tick the Enable checkbox to enable MQTT client operation. The MQTT client is enabled by default.
3. Click Connection then configure the settings as required.
4. Use Connection > Actions to select which information the card will publish.
5. Click Submit to save all settings in the card.

Home Configuration IP Setting Administration

### MQTT Client

MQTT Client - Connection Configuration

Parameter	Value
Client ID	1
Broker address	192.168.0.100
Broker port	1883
Flags	Clean session <input checked="" type="checkbox"/> Reliable <input type="checkbox"/> Will <input type="checkbox"/> Prefix will <input checked="" type="checkbox"/> Secure <input type="checkbox"/> Verify Certificate <input type="checkbox"/>
Topic prefix	F014000
User name	
Password	
Will topic	
Connection Timeout (s)	10
Connection idle timeout (s)	0
MQTT keep alive interval (s)	30

Reload Submit

192.168.0.2/superv/mqtt\_br.htm# 22512.A

### • Configure OPC UA settings

1. Connect to the web server then click Configuration > OPC UA Server.
2. Tick the Enable checkbox to enable OPC UA client operation. The OPC UA client is enabled by default.
3. Click Server Configuration then configure the settings as required.
4. Use Actions to select the actions for different object instances.
5. Click Submit to save all settings in the card.

Home IP Setting Configuration Administration

### OPC UA Server

OPC UA Server - Configuration

Parameter	Value
Server port	102
Maximum allowed nodes	2000
Maximum sessions	2
Maximum session lifetime (ms)	1200000
OPC UA trace output IP	
Options	Allow anonymous <input checked="" type="checkbox"/> Allow User/Password access <input checked="" type="checkbox"/> Support Authorization <input type="checkbox"/>
UA services	Write service <input checked="" type="checkbox"/>

Reload Submit

192.168.0.2/superv/opcu.htm# 22526.A

## 4 MASTER CONFIGURATION



Import the latest GSDML file into your Master configuration tool. This file is available from your supplier.

If your Master uses on-screen icons, two graphic bitmap files are available from the website. SSPM\_N.bmp indicates normal mode. SSPM\_D.bmp indicates diagnostic mode.

EN

# 5 GROUND FAULT PROTECTION

## 5



### NOTICE

Ground fault protection is only available on ground fault enabled cards, with soft starters running a compatible version of software. Contact your supplier for assistance.

## 5.1 Overview

The Profinet Card can detect ground current and trip before the equipment is damaged.

Ground fault protection requires a 1000:1 or 2000:1 current transformer (not supplied). The CT should be rated 1 VA or 5 VA. The soft starter can be configured to trip at 1 A~50 A. If ground fault current rises above 50 A, the soft starter will trip immediately.

Parameter 40C *Ground Fault Trip Active* selects when ground fault protection is active.

## 5.2 Connect the CT to the ground fault inputs

To use ground fault protection, a common mode current transformer (CT) must be installed around all three phases. Use a 1000:1 or 2000:1 CT with rating of 1 VA or 5 VA and set parameter 40E *Ground Fault CT Ratio* to match. Connect the CT to the ground fault terminals (G1, G2, G3).

For maximum protection, the CT should be installed on the input side of the soft starter.

### 5.3 Configure ground fault protection settings

Ground fault protection settings must be set in the soft starter.

Parameter	Parameter name	Description
40A	<i>Ground Fault Level</i>	Sets the trip point for ground fault protection.
40B	<i>Ground Fault Delay</i>	Slows the Profinet Card's response to ground fault variation, avoiding trips due to momentary fluctuations.
40C	<i>Ground Fault Trip Active</i>	Selects when a ground fault trip can occur.
40D	<i>Ground Fault Action</i>	Selects the soft starter's response to the protection event.
40E	<i>Ground Fault CT Ratio</i>	Set to match the ratio of the ground current measuring CT.

## 6 OPERATION

# 6

The device has been designed for use in a system complying with the Profinet standard. For successful operation, the controller must also support all functions and interfaces described in this document.

### Device classification

The Profinet Card is a Profinet IO-Device and must be managed by an IO-Controller over Ethernet.


EN

### Ensuring safe and successful control

Data written to the device will remain in its registers until the data is overwritten or the device is reinitialised.

If the soft starter may be controlled via Command Override (parameter 7A) or may be disabled via the reset input (terminals 10, 11) fieldbus commands should be cleared from the registers. If a command is not cleared, it will be re-sent to the starter once fieldbus control resumes.

### Feedback LEDs



LED name	LED Status	Description
Power	Off	Device is not powered up.
	On	Device is receiving power.
Error	Off	No error.
	Flashing	Connection not established.
	On	No physical link or slow physical link. No configuration.
Status	Off	No error.
	Flashing	DCP signal service initiated via the bus.
Link x	Off	No network connection.
	On	Connected to a network.
TX/RX x	Flashing	Transmitting or receiving data.

# 7 PACKET STRUCTURES



## NOTICE

The available features and parameter details may vary according to the model and software version of the starter. Refer to the soft starter user manual for details of parameters and supported features.

## Control commands (controller to device)

Use output bytes 0-1 to send a control command to the soft starter.

Byte	Bits	Details
0	0 to 1	<i>Reserved</i>
	2 to 3	0 = Use soft starter remote input to select motor set 1 = Use primary motor set when starting 2 = Use secondary motor set when starting 3 = <i>Reserved</i>
	4	0 = stop action will be as selected in the soft starter 1 = stop action will be a coast to stop
	5 to 7	<i>Reserved</i>
1	0	0 = Stop 1 = Start
	1 to 2	<i>Reserved</i>
	3	1 = Reset
	4 to 7	<i>Reserved</i>
2 to 5		Parameter management (see <i>Parameter Management</i> on page 24)

EN

## Status information (device to controller)

Starter status information is always available when the device is active.

### Bytes 0-1: Control status

Bits	Details
0 to 5	Current (% motor FLC)
6	Command source 0 = Network, Timer 1 = Remote Keypad, Digital Input, Clock
7	1 = Ramping (starting or stopping)
8	1 = Ready
9	1 = Starting, running or stopping

Bits	Details
10	1 = Tripped
11	1 = Warning
12 to 15	<i>Reserved</i>

### Bytes 2-3: Starter state

Bits	Details
0 to 3	The decimal value of bits 0~3 indicates the starter's state: 0 = Communication error between device and soft starter 1 = Ready 2 = Starting 3 = Running 4 = Stopping 5 = Not ready (restart delay, restart temperature check, run simulation, reset input is open) 6 = Tripped 7 = Menu open (cannot start) 8 = Jog forward 9 = Jog reverse
4	0 = Negative phase sequence 1 = Positive phase sequence
5	1 = Current exceeds FLC
6	0 = Uninitialised 1 = Initialised
7	1 = Communication error between device and soft starter
8 to 15	<i>Reserved</i>

EN

### Bytes 4-5: Trip code

Bits	Details
0 to 15	See <i>Trip Codes</i> on page 25

### Bytes 6-7: Motor current

Bits	Details
0 to 15	Average rms current across all three phases

### Bytes 8-9: Motor temperature

Bits	Details
0 to 15	Motor thermal model (%)

## Bytes 10-63: Extended information

Bytes 10~63 report information from the soft starter's internal registers.

Byte	Description	Bits	Details
10-11	Version	0 to 8	<i>Reserved</i>
		9 to 15	Product type code: 12 = n/a 13 = V6
12-13	Model number	0 to 7	<i>Reserved</i>
		8 to 15	Soft starter model ID
14-15	<i>Reserved</i>		
16-17	<i>Reserved</i>		
18-19	Starter state	0 to 4	0 = <i>Reserved</i> 1 = Ready 2 = Starting 3 = Running 4 = Stopping 5 = Not ready (restart delay, restart temperature check, run simulation, reset input is open) 6 = Tripped 7 = Programming mode 8 = Jog forward 9 = Jog reverse
		5	1 = Warning
		6	0 = Uninitialised 1 = Initialised
		7	Command source 0 = Network, Timer 1 = Remote Keypad, Digital Input, Clock
		8	<i>Reserved</i>
		9	0 = Negative phase sequence 1 = Positive phase sequence
		10 to 15	See <i>Trip Codes</i> on page 25
20-21	Current	0 to 13	Average rms current across all three phases
		14 to 15	<i>Reserved</i>
22-23	Current	0 to 9	Current (% motor FLC)
		10 to 15	<i>Reserved</i>
24-25	Motor temperature	0 to 7	Motor thermal model (%)
		8 to 15	<i>Reserved</i>

Byte	Description	Bits	Details
26-27	Power	0 to 11	Power
		12 to 13	Power scale 0 = Multiply power by 10 to get W 1 = Multiply power by 100 to get W 2 = Power (kW) 3 = Multiply power by 10 to get kW
		14 to 15	<i>Reserved</i>
28-29	% Power factor	0 to 7	100% = power factor of 1
		8 to 15	<i>Reserved</i>
30-31	Voltage	0 to 13	Average rms voltage across all three phases
		14 to 15	<i>Reserved</i>
32-33	Current	0 to 13	Phase 1 current (rms)
		14 to 15	<i>Reserved</i>
34-35	Current	0 to 13	Phase 2 current (rms)
		14 to 15	<i>Reserved</i>
36-37	Current	0 to 13	Phase 3 current (rms)
		14 to 15	<i>Reserved</i>
38-39	Voltage	0 to 13	Phase 1 voltage (rms)
		14 to 15	<i>Reserved</i>
40-41	Voltage	0 to 13	Phase 2 voltage (rms)
		14 to 15	<i>Reserved</i>
42-43	Voltage	0 to 13	Phase 3 voltage (rms)
		14 to 15	<i>Reserved</i>
44-45	Parameter list version number	0 to 7	Parameter list minor revision
		8 to 15	Parameter list major version
46-47	Digital input state	For all inputs, 0 = open, 1 = closed (shorted)	
		0	Start/Stop
		1	<i>Reserved</i>
		2	Reset (Refer to note)
		3	Input A
		4	Input B
5 to 15	<i>Reserved</i>		
48-49	Trip code	0 to 15	See <i>Trip Codes</i> on page 25
50-51	<i>Reserved</i>		
52-53	Frequency	0 to 15	Frequency (Hz)
54-55	Ground current	0 to 15	Ground current (A)
56-59	<i>Reserved</i>		
60-63	Parameter management		See <i>Parameter Management</i> on page 24

**NOTICE**

The reset input is normally closed by default. If parameter 7I *Reset/Enable Logic* is set to normally open, the reported state will be inverted (0 = closed, 1 = open).

**NOTICE**

For models 0064B and smaller, current reported via communications is 10 times greater than the actual value (displayed on the keypad).

**NOTICE**

Frequency reported via communications is 10 times greater than the actual value.

## Parameter management

The Profinet Card can read parameter values from and write parameter values to the soft starter. The card handles one parameter at a time.

The device references parameters according to their position in the starter's parameter list.



### NOTICE

Parameter lists vary according to the model and version of soft starter. Refer to the relevant soft starter manual for a complete parameter list.



### CAUTION

Changing the values of the Advanced parameters (parameter group 20) may cause unpredictable behaviour in the soft starter. Consult your local supplier before adjusting the Advanced parameters.

EN

## Output

Use output bytes 2-5 to read or write a parameter to the soft starter.

Controller > device output bytes are structured as follows.

Byte	Bits	Details
2	0 to 7	Parameter number to read/write
3	0	<i>Reserved</i>
	1	1 = Read parameter
	2	1 = Write parameter
	3 to 7	<i>Reserved</i>
4	0 to 7	Low byte parameter value to write to soft starter/ zero data values for read
5	0 to 7	High byte parameter value to write to soft starter/ zero data values for read

## Input

Parameter data from the starter is reported in input bytes 60-63.

Device > controller input bytes are structured as follows.

Byte	Bits	Details
60	0 to 7	Echo parameter number
61	0	1 = Invalid parameter number
	1	1 = Invalid parameter value
	2 to 7	<i>Reserved</i>
62	0 to 7	Low byte parameter value read from soft starter
63	0 to 7	High byte parameter value read from soft starter

## Trip codes

Trip code	Description
255	No trip
1	Excess start time
2	Motor overload
3	Motor thermistor
4	Current imbalance
5	Frequency
6	Phase sequence
7	Overcurrent
8	Power loss
9	Undercurrent
10	Heatsink overtemperature
11	Motor connection
12	Input A trip
13	FLC too high
14	Unsupported option (function not available in inside delta)
15	Communications card fault
16	Network communications
18	Overvoltage
19	Undervoltage
20	Ground fault
23	Parameter out of range
24	Input B trip
26	L1 phase loss
27	L2 phase loss
28	L3 phase loss
29	L1-T1 shorted
30	L2-T2 shorted
31	L3-T3 shorted
33	Time-overcurrent (Bypass overload)
34	SCR overtemperature
35	Battery/clock
36	Thermistor circuit
47	Overpower
48	Underpower
56	Keypad disconnected
57	Zero Speed Detect
58	SCR Itsm
59	Instantaneous overcurrent

Trip code	Description
60	Rating Capacity
70	Current Read Err L1
71	Current Read Err L2
72	Current Read Err L3
74	Motor Connection T1
75	Motor Connection T2
76	Motor Connection T3
77	Firing Fail P1
78	Firing Fail P2
79	Firing Fail P3
80	VZC Fail P1
81	VZC Fail P2
82	VZC Fail P3
83	Low Control Volts
84~96	Internal fault x. Contact your local supplier with the fault code (X).

EN

## Examples

### Control commands (controller to device)

Start the motor using parameter set 1							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
4	1						
Start the motor, select via remote input							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0	1						
Stop the motor using the programmed soft stop for motor set 2							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
8	0						
Quick stop the motor							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
16	0						
Reset a trip							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
≤ 28	8						

### Status information (device to controller)

Read control status - Ready							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
0	1						

<b>Read control status - Running</b>							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
		3	0				
<b>Read control status - Tripped, trip code 4 (Current imbalance)</b>							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
		6	0	4	0		

## Parameter management

<b>Write parameter to starter: parameter number 2, 1B Motor Full Load Current = 55</b>							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
		2	4	55	0		
<b>Parameter write response</b>							
Byte 56	Byte 57	Byte 58	Byte 59	Byte 60	Byte 61	Byte 62	Byte 63
				2	0	55	0
<b>Read parameter number 16, 2I Stop Mode</b>							
Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
		16	2	0	0		
<b>Parameter read response: parameter 2I Stop Mode = 1 (TVR Soft Stop)</b>							
Byte 56	Byte 57	Byte 58	Byte 59	Byte 60	Byte 61	Byte 62	Byte 63
				12	0	1	0

EN


## 8 NETWORK DESIGN

# 8

The device supports star, line and ring topologies.

### Star topology


In a star network, all controllers and devices connect to a central network switch.



EN

### Line topology

In a line network, the controller connects directly to one port of the first card. The second Ethernet port connects to another card, which in turn connects to another device until all devices are connected.



#### NOTICE

The device has an integrated switch to allow data to pass through in line topology. The device must be receiving control power from the soft starter for the switch to operate.

**NOTICE**

If the connection between two devices is interrupted, the controller cannot communicate with devices after the interruption point.


**NOTICE**

Each connection adds a delay to communication with the next device. The maximum number of devices in a line network is 32. Exceeding this number may reduce the reliability of the network.

## Ring topology

In a ring topology network, the controller connects to the first card, via a network switch. The second Ethernet port of the card connects to another device, which in turn connects to another device until all devices are connected. The final device connects back to the switch.


The device supports beacon based ring node configuration with MRP (media redundancy protocol).

**NOTICE**

The network switch must support loss of line detection.

## Combined topologies

A single network can include both star and line components.



EN

## 9 SPECIFICATIONS



### Connections

Soft starter ..... 16-way pin assembly  
 Contacts ..... Gold flash  
 Network ..... RJ45

### Settings

IP Address ..... Automatically assigned  
 Device name ..... Automatically assigned, configurable

### Network

Link speed ..... 10 Mbps, 100 Mbps (auto-detect)  
 Full duplex  
 Auto crossover

### Power

Consumption (steady state, maximum) ..... 35 mA @ 24 VDC  
 Reverse polarity protected  
 Galvanically isolated

### Certification

CE ..... EN 60947-4-2

Profibus & Profinet International .....  PROFIBUS · PROFINET







**24H TECHNICAL ASSISTANCE 365 DAYS A YEAR**

FIND YOUR NEAREST DELEGATION  
**[POWER-ELECTRONICS.COM/CONTACT/](http://POWER-ELECTRONICS.COM/CONTACT/)**

**@ in   **