



SD750 PTC INPUT CONFIGURATION



Document SD750-11

Jason Curtis- Support Engineer
Power Electronics NZ Ltd
8TH October 2020
jcurtis@power-electronics.co.nz

Contents

Contents 1

Parameters 2

Connection Diagram 3

Terminal Numbers 3

Notes explanations of parameters 3

Position of control card jumper J20 4



Parameters


Group 4: Inputs

This group of programming parameters is divided into different subgroups.

Subgroup 4.1: Digital Inputs

G4.1.10 Digital Input 6/PTC = Not used	28	LCL Regenerative fb	Not available
	29	PTC	To generate the fault 'F79 PT100'. Only valid for Digital Input 6.
	32	Speed / Torque	Allows changing the control mode by Speed (input = 0) or by Torque (input = 1)
	33	Output 1 Feedback 1	If the status of the input is different during the time set in G4.1.27 to the state of the corresponding output, fault "F55: contactor feedback"
	34	Output 1 Feedback 2	
	35	Output 1 Feedback 3	
	36	Output 4 Feedback 4	
	37	Output 5 Feedback 5	
	38	Output 6 Feedback 6	
	39	Output 7 Feedback 7	
	40	Output 8 Feedback 8	
	41	Universal Stop	It stops the drive regardless of control mode & program selection configured (NO).
	43	Output 9 Feedback 9	If the status of the input is different during the time set in G4.1.27 to the state of the corresponding output, fault "F55: contactor feedback"
	44	Output 10 Feedback 10	
	45	Output 11 Feedback 11	
46	Output 12 Feedback 12		
47	Output 13 Feedback 13		
48	Torque limit 2	Allows selecting the alternative torque limit reference as programmed in G10.2.8	

Connection Diagram



Terminal Numbers

Terminals 7 : +24V_User
Terminals 13 : DI6 PTC

NOTE: the remote I/O control cables must be screened


Notes explanations of parameters

DI6 (PIN13) PTC sensor input mode.

It is possible to connect a PTC sensor in the digital input 6 (DI6) so that the equipment acts from a temperatura (resistance) value associated to motor's temperature and to allow enabling cooling or stop motor running. It must be considered that sensor resistance does not exceed trigger point (pass from 1 to 0) of the DI6 when motor is under normal conditions of operation temperature. Cable ground screening must be connected only in one end.



Position of control card jumper J20



<p>J20 (DI6)</p>	<p>Configures the AI6 as Digital Input or PTC.</p>	
------------------	--	--

DI Input mode



PTC Input Mode

