



Sinexcel
Static Var Generator (SVG)
Installation Guide

Static Var Generator (SVG) – installation guide

Revision B

Created: **B Sheridan**
Position: **Technical Director**
Date: **20/07/17**

Reviewed: **M Duncan**
Position: **Sales and Marketing
Director**
Date: **20/07/17**

Static Var Generator (SVG) – installation guide

TABLE OF CONTENTS

1.0	System Overview	3
2.0	SVG Plain English 4.3” Touchscreen	4
2.1	What If The SVG 4.3” Touchscreen Comes Up In The Wrong Language	4
2.2	SVG 4.3” Touchscreen Layout	5
3.0	SVG Plain English 7” Touchscreen	6
3.1	Powering Up the SVG 7” Touchscreen For The First Time	6
3.2	What If The SVG 7.0” Touchscreen Comes Up In The Wrong Language	8
3.3	SVG 7.0” Touchscreen Layout	9
4.0	Modes Of Operation	10
5.0	Supply MCCB Sizing	10
6.0	Heat Dissipation And Airflow	10
7.0	CT Sizing	11
8.0	Basic Commissioning Settings For Plain English 4.3” Touchscreen	12
9.0	Basic Commissioning Settings For Plain English 7” Touchscreen	14
10.0	Wiring Connections And Terminal Layout For Wallmount Modules	15
11.0	Wiring Connections And Terminal Layout For Pluggable Cabinets	17
12.0	Tips for the Sinexcel Plug In Cabinets	19
12.1	Enabling The Plug In Module Before Insertion Into The Cabinet	19
12.2	CT Shorting Blocks	20
12.3	Incoming Phase Orientation	21

Static Var Generator (SVG) – installation guide



1.0 System Overview

Automatic power factor correction equipment is broadly applied in NZ industry to ensure the electrical network is utilised to its best capacity. The usual form of such power factor correction is an automatic controller that monitors one incoming phase to a plant and switches banks of capacitors to try and maintain a target power factor.

The problems with capacitor based automatic power factor correction are vast and varied. It is slow to react to load changes so the system is constantly in a state of over compensation or under compensation. In today's harmonic rich environments the capacitors suffer with overload.

System resonance is a risk and the life expectancy of the system is reduced. Contactors regularly fail and overloaded capacitors leak, presenting a real fire risk.


Sinexcel's SVG is an entirely new approach to power factor correction. The SVG utilises a high speed three level inverter that reacts to changes in reactive power, exchanging corrective reactive power into the system. Full correction is made in 3/4 of a cycle. This rapid response provides stable accurate real-time power factor correction without the drawbacks of traditional capacitor based systems. The SVG can continuously adjust reactive power dynamically and bi-directionally (leading or lagging). There is no chance of system resonance and even under low voltage conditions SVG will provide full reactive power compensation. The Sinexcel SVG is 100% inverter based so there are no AC capacitors to fail

Static Var Generator (SVG) – installation guide

2.0 SVG Plain English Touchscreen 4.3” (Wallmount Only)

2.1 What If The SVG 4.3” Touchscreen Comes Up In The Wrong Language


On rare occasions the 4.3” colour touchscreen may not have been configured for the English language prior to dispatch from the factory (example below). This can be easily remedied.



Press 3rd button on left, then select the bottom left of the four options that appear.




Press the bottom user field and select “English” and the following display will appear.



Static Var Generator (SVG) – installation guide

2.2 SVG 4.3” Touchscreen Layout



The 4.3” colour touchscreen is available on all wallmount variants of the SVG and ASVG. Commissioning is undertaken via this display with the password to access all user settings set at default to “080808”.

Navigation through the screen groups is achieved by touching one of the four main screen groupings as listed on the left hand side of the display. Touching the appropriate group will bring all the appropriate subgroups or settings for that group to the screen. Adjustment of the groups is achieved by touching the screen group that is required to be adjusted. A drop down box or number keypad will appear to allow the user to amend the setting. Exiting the setting ensures all changed parameters are saved.

Please note the 4.3” Touchscreen and 7.0” Touchscreen cannot be used together.


Static Var Generator (SVG) – installation guide

3.0 SVG Plain English Touchscreen 7.0” (Cabinet or Rackmount Only)

3.1 Powering Up The SVG 7.0” Touchscreen For The First Time


The 7.0” colour touchscreen is available on all variants of the SVG, ASVG, and AHF (ZAPF) not fitted with a 4.3” Touchscreen. It is supplied as standard on all Sinexcel Plug In or Flexi cabinets but is also available as a loose item for custom built systems.

On initial power up the touchscreen should be configured to ensure that it is set to suit the device that it is connected to. This is a simple process.



Pressing this icon will unfold the ‘settings’ option. Pressing the settings option will bring up the password screen.


The screen above will be shown on power up if the touchscreen has come pre-configured as an AHF display. If the touchscreen has come pre-configured as an SVG or ASVG then the screen below will be shown.



Pressing this icon will unfold the ‘settings’ option. Pressing the settings option will bring up the password screen.

In either case select the vertical three dotted icon (top right). Select ‘settings’ and enter the super password “**654321**”.


Static Var Generator (SVG) – installation guide



Select the 'Prefer' tab

Monitor Model setting must be configured to SVG

Select 'Prefer' and ensure monitor model is set to SVG. The HMI will now reboot if the configuration is changed.




To continue normal commissioning select this icon again, then settings, then open the systems tab

Select the vertical three dotted icon again and select 'Settings', then 'System'. Unit commissioning can now be commenced.

Static Var Generator (SVG) – installation guide

3.2 What If The SVG 7.0” Touchscreen Comes Up In The Wrong Language?

On rare occasions the 7.0” colour touchscreen may not have been configured for the English language prior to dispatch from the factory (example below). This can be easily remedied.



After clicking on the three dotted icon a drop down box will appear containing the character shown below



Select the vertical three dotted icon (top right) then click on the option  (with Chinese text next to it) that appears in the drop down box and the display below will appear.




Static Var Generator (SVG) – installation guide



Open this tab first
Change this screen to English

Press the tab shown highlighted in blue, and the screen will show as above. Opening the top right user field will allow you to change the language to English. The display will reconfigure to the main screen and the displayed text should now be in English. Check the monitor model is set to SVG as described in section 3.1 – Powering Up The SVG 7.0” Touchscreen For The First Time.

3.3 SVG 7.0” Touchscreen Layout



Commissioning is undertaken via this display with the password to access all user settings set at default to “080808”.

Navigation through the screen groups is achieved by touching one of the six main screen groupings across the top of the display. Touching the appropriate group will bring all the appropriate subgroups and settings for that group to the screen. Adjustment of the groups is achieved by touching the screen group that is required to be adjusted. A drop down box or number keypad will appear to allow the user to amend the setting. Exiting the setting ensures all changed parameters are saved.

Please note the 4.3” Touchscreen and 7.0” Touchscreen cannot be used together.

Static Var Generator (SVG) – installation guide

4.0 Modes Of Operation

The principal purpose of the SVG is to provide reactive power in order to improve power factor. The SVG can also be configured to use its capacity to provide current balancing, voltage regulation (on request only), and in the case of the ASVG harmonic correction.

This installation guide has been prepared to assist with the installation and configuration for operation in reactive power mode. For applications requiring the SVG or ASVG to use the additional functionality described above please contact your local Power Electronics office for assistance.

5.0 MCCB Sizing

SVG Model (KVAR)	MCCB Size (Amps)
50	100
100	200
Cabinet or Custom Systems	System Current Rating x 1.25 (1KVAR = 1.5Amp)

6.0 Heat Dissipation And Airflow

SVG Model (KVAR)	Heat Losses Max (W)	Airflow (l/s)
50	1384	220
100	2786	405

PLEASE NOTE ALL SINEXCEL PROPRIETARY CABINETS MUST BE INSTALLED WITH 300MM CLEARANCE AT THE REAR OF THE CABINET FOR CORRECT AIRFLOW

Static Var Generator (SVG) – installation guide

7.0 CT Sizing


Traditional power factor correction has monitored power factor in one phase only and has connected reactive power on the basis that the two unmonitored phases will have exactly the same power factor as the monitored phase. In reality this condition very rarely exists. It is typical of the power factor on all three phases to be completely different.

The SVG will monitor and provide reactive power for all three phases individually. Thus a minimum of three CTs (one per phase) are required to be installed for the SVG to operate correctly. The CTs should be of 0.5 accuracy class or better.

The ratio of CT to be fitted is 1.75 x, to 4 x, the rated full load current supply to the switchboard. For example – a 100A supply requiring power factor correction would require a CT ratio of between 175/5 to 400/5. The secondary of the CT must always be rated 5A.




Positioning of the CTs is critical. Separate detail is available in this document showing CT positioning for various installations. Some applications may require multiple CTs. If multiple CTs per phase are required – the CT ratio for all CTs must be the same.

Sinexcel CT List		
CT Ratio	Outer Diameter (mm)	Inner Diameter (mm)
150/5	110*90	30*20
200/5	145*114	80*50
300/5	145*114	80*50
500/5	145*114	80*50
600/5	145*114	80*50
1000/5	185*144	120*80
1500/5	185*144	120*80
2000/5	185*144	120*80
2500/5	193*144	125*55
3000/5	193*144	125*55
4000/5	185*144	120*80
5000/5	245*174	160*80
6000/5	245*175	160*80



Static Var Generator (SVG) – installation guide

8.0 Basic Commissioning Settings For Plain English 4.3” Touchscreen



Static Var Generator (SVG) – installation guide




Leave set to series. This relates to internal CTs within the SVG cabinet only

Set required power factor

Static Var Generator (SVG) – installation guide

9.0 Basic Commissioning Settings For Plain English 7” Touchscreen



BASIC		HARMO.	POWER	WAVES	I/O	SYSTEM			
Grid Curr.	RMS (A)	PF	THDI(%)	Grid Volt.	Vol. (V)	Fre. (Hz)	THDI(%)		
	L1	200.0	0.000		0.0	L1	220.0	53.0	0.0
	L2	200.0	0.000		0.0	L2	220.0	53.0	0.0
	L3	200.0	0.000		0.0	L3	220.0	53.0	0.0
	N	0.2							
Load Curr.	RMS (A)	PF	THDI(%)	Comp. Curr.	RMS (A)	Load Rate (%)			
	L1	300.0	0.000		0.0	L1	40.0	100.00	
	L2	300.0	0.000		0.0	L2	40.0	100.00	
	L3	300.0	0.000		0.0	L3	40.0	100.00	
	N	0.1							


Select System Menu. When prompted enter 080808 as the password

Settin.	SYSTEM	COMM.	HARMO.	PREFER.	DEBUG
General Setting					
Operation Mode	Auto-ageing	Target Power Factor	1.0		
Comp. Rate	0.8	Total Capacity	90.0		
Comp. Mode	Intelligent	CT Ratio	600.0		
More					
Power On Mode	Manual	Slave Module Quantity	1.0		

- Ensure set to Reactive mode
- Set required power factor
- Set to total current rating of all SVG modules combined. Setting is in Amps. Use 100KVAR = 150Amps
- Set correct CT ratio
- Set to Intelligent mode
- Set to total number of modules connected to display
- Power On mode to Automatic

SCROLL DOWN THE SCREEN

Static Var Generator (SVG) – installation guide




Set to Line or Load as per CT location shown in config drawings

Leave set to series. This relates to internal CTs within the SVG cabinet only


10.0 Wiring Connections And Terminal Layout For Wallmount Modules

PLEASE NOTE THE SVG PROVIDES OPTIMAL PERFORMANCE WHEN A NEUTRAL CONNECTION IS PROVIDED TO THE UNIT. POWER ELECTRONICS WOULD RECOMMEND THE CONNECTION OF A NEUTRAL CONDUCTOR THE SAME CROSS SECTIONAL AREA AS THE PHASE CONDUCTORS



SVG single module load side

Static Var Generator (SVG) – installation guide




SVG single module supply side

Static Var Generator (SVG) – installation guide


11.0 Wiring Connections And Terminal Layout For Pluggable Cabinets

PLEASE NOTE THE SVG PROVIDES OPTIMAL PERFORMANCE WHEN A NEUTRAL CONNECTION IS PROVIDED TO THE UNIT. POWER ELECTRONICS WOULD RECOMMEND THE CONNECTION OF A NEUTRAL CONDUCTOR THE SAME CROSS SECTIONAL AREA AS THE PHASE CONDUCTORS



SVG Cabinet 3 CT Option

Static Var Generator (SVG) – installation guide



SVG Cabinet 6 CT Option

Static Var Generator (SVG) – installation guide

12.0 Tips for the Sinexcel Plug In Cabinets

12.1 Enabling The Plug In Module Before Insertion Into The Cabinet

On the backplane within the Sinexcel plug in cabinet the jumper plug must be shifted from the right position to the left position to enable the SVG module. Should the jumper plug remain in the right position then that slot will be ignored.



J13-module in place LEFT



J12-no module in place RIGHT

Static Var Generator (SVG) – installation guide

12.2 CT Shorting Blocks

At any time the CTs are be connected, removed, or their associated circuits are being worked on the CTs should be shorted out. This can be done at the CT shorting block by changing the positions of links 3, 8, and 13.




CT terminal block with CTs shorted out.



CT terminal block with the links on 3, 8, and 13 open. This is the correct operating position.

Static Var Generator (SVG) – installation guide

12.3 Incoming Phase Orientation



Please note the input bars at the bottom of the 1000Amp isolator are L3 (Blue), L2 (White), Line1 (Red) from left to right. This makes the orientation on the modules L1, L2, L3 from the rear which is correct for operation.



sales@power-electronics.co.nz

www.power-electronics.co.nz

Christchurch Head Office
(Southern Region)
14B Opawa Road
P.O. Box 1269
Christchurch
New Zealand

Napier
(Central Region)
Unit 1, 105 Ford Rd
Ford Road Business Park
Onekawa
Napier

Auckland
(Northern Region)
16 Aranui Rd
Mt Wellington
Auckland

Phone: 03 379 9826
Fax: 03 379 9827

Phone: 06 845 9067
Fax: 06 845 9046

Phone: 09 527 8523
Fax: 03 379 9827