

SD 100

Series

VARIABLE SPEED DRIVE



Variable Speed Drive User's Manual

SD 100

Series

VARIABLE SPEED DRIVE

VARIABLE SPEED DRIVE

User's Manual SD10MT01BI Rev. B

POWER ELECTRONICS ESPAÑA

C/ Leonardo da Vinci, 24 - 26
PARQUE TECNOLÓGICO
46980 · PATERNA · VALENCIA · ESPAÑA
Atención al Cliente. 902 40 20 70
Tel. +34 96 136 65 57 · Fax. +34 96 131 82 01
www.power-electronics.com
power@power-electronics.com



IMPORTANT NOTES

RECEPTION

The SD100 are carefully tested and perfectly packed before leaving the factory. In case of transport damage, notify it to transport agency and to **POWER ELECTRONICS** Tf. International +34 96 136 65 57, not later than 24hrs from delivery date.

UNPACKING

Make sure model and serial number of the variable speed drive are the same in the box, delivery note and unit.

Each variable speed drive is supplied with el SD100 Technical manual in spanish, german and english.

SAFETY

It's electrician's responsibility to ensure the configuration and installation of the SD-100 SERIES meets the requirements of any site specific, local and national electrical regulations.

The SD100 Series operates from HIGH VOLTAGE, HIGH ENERGY ELECTRICAL SUPPLIES. Always isolate before servicing.

Service only by qualified personnel. For any question or enquiry please contact POWER ELECTRONICS Technical Department or with your local distributor.

The SDRIVE100 Series contains static sensitive printed circuit boards. Use static safe procedures when handling these boards.

REVISIONS

| Date | Revision | Description |
|-------------|-----------------|--------------------|
|-------------|-----------------|--------------------|

May 2003


A

INDEX


| | |
|---|-----------|
| 1. DESCRIPTION SD100..... | 6 |
| 1.1. Product details.Appearance. | |
| 1.2. View without the front cover. | |
| 2. MOUNTING AND WIRING..... | 7 |
| 2.1. Installation precautions. | |
| 2.2. Wiring terminals. | |
| 2.3. Power terminals. | |
| 2.4. Specifications for control terminals. | |
| 2.5. Specifications for power terminals. | |
| 3. ELECTRICAL SPECIFICATIONS..... | 10 |
| 4. DIMMENSIONS AND STANDARD RATINGS..... | 12 |
| 5. PROGRAMMING KEYPAD..... | 13 |
| 5.1. Keypad features. | |
| 5.2. Parameter groups in SD100. | |
| 5.3. Moving between groups. | |
| 5.4. Moving to other groups from any codes other than the first code. | |
| 5.5. Parameter setting method. | |
| 5.6. Monitoring of operation status. | |
| 5.7. Monitoring of Motor rpm. | |
| 5.8. Parameter initialize. | |
| 6. FAULT MESSAGES..... | 18 |
| 6.1. Monitor fault. | |
| 6.2. Fault display and information. | |
| 7. FUNCTION LIST..... | 20 |
| 7.1. Drive group. | |
| 7.2. Function group 1. | |
| 7.3. Function group 2. | |
| 7.4. I / O group. | |
| 8. BASIC OPERATION..... | 37 |
| 8.1. Frequency Setting via keypad & operating via terminals. | |
| 8.2. Frequency Setting via potentiometer & operating via terminals. | |
| 8.3. Frequency Setting via potentiometer & operating via the Run key. | |
| 8.4. Multi-peed control via terminals P3, P4, P5. | |
| 8.5. PID for pressure control configuration. | |

1. DESCRIPTION SD100

1.1. Product details.



1.2. View without the front cover.




2. MOUNTING AND WIRING

2.1 Installation precautions

Handle the inverter with care to prevent damage to the plastic components. Do not hold the inverter by the front cover. It may fall off.


Install the inverter in a place where it is immune to vibration (**5.9 m/s² or less**).

The inverter is under great influence of ambient temperature. Install in a location where temperature is within the permissible range (**-10~50°C**).



Ambient Temp Checking Location.


The inverter will be very hot during operation. Install it on a non-combustible surface. Mount the inverter on a flat, vertical and level surface. Inverter orientation must be vertical (top up) for proper heat dissipation. Also leave sufficient clearances around the inverter.




Protect from moisture and direct sunlight.

Do not install the inverter in any environment where it is exposed to waterdrops, oil mist, dust, etc. Install the inverter in a clean place or inside a "totally enclosed" panel which does not accept any suspended matter.


2.2 WIRING TERMINALS



2.3 POWER TERMINALS



2.4 SPECIFICATIONS FOR CONTROL TERMINALS



| Terminal | Terminal Description | Wire size | Torque (Nm) |
|-------------------|---|-----------------------------|-------------|
| P1/P2/P3 P4/P5 | Multi-function input T/M P1-P5 | 22 AWG, 0.3 mm ² | 0.4 |
| CM | Common Terminal for P1-P5, AM, P24 | 22 AWG, 0.3 mm ² | 0.4 |
| VR | 12V power supply for external potentiometer | 22 AWG, 0.3 mm ² | 0.4 |
| V1 | 0-10V Analog Voltage input | 22 AWG, 0.3 mm ² | 0.4 |
| I | 0-20mA Analog Current input | 22 AWG, 0.3 mm ² | 0.4 |
| AM | Multi-function Analog output | 22 AWG, 0.3 mm ² | 0.4 |
| MO | Multi-function open collector output T/M | 20 AWG, 0.5 mm ² | 0.4 |
| EXTG | Ground T/M for MO | 20 AWG, 0.5 mm ² | 0.4 |
| P24 | 24V Power Supply for P1-P5 | 20 AWG, 0.5 mm ² | 0.4 |
| 30A | Fault relay A/B contact output | 20 AWG, 0.5 mm ² | 0.4 |
| 30B | | 20 AWG, 0.5 mm ² | 0.4 |
| 30C | | 20 AWG, 0.5 mm ² | 0.4 |

NOTE: Tie the control wires more than 15cm away from the control terminals. Otherwise, it interferes front cover reinstallation.

When you use external power supply for multi-function input terminal (P1~P5), apply voltage more than 12V to activate.

2.5 SPECIFICATIONS FOR POWER TERMINALS

| | SD1103 | SD1105 | SD1108 | SD1112 |
|-------------------|--------------------------|--------------------------|----------------------------|----------------------------|
| | | | | |
| Input wire size | 2mm ² | 2mm ² | 3.5mm ² | 3.5mm ² |
| Out wire | 2mm ² | 2mm ² | 3.5mm ² | 3.5mm ² |
| Ground Wire | 2mm ² | 2mm ² | 3.5mm ² | 3.5mm ² |
| Terminal Lug | 2mm ² , 3.5 φ | 2mm ² , 3.5 φ | 3.5mm ² , 3.5 φ | 3.5mm ² , 3.5 φ |
| Tightening Torque | 13kqf/cm | 13kqf/cm | 15kqf/cm | 15kqf/m |

3. ELECTRICAL SPECIFICATIONS

INPUT

| | |
|----------------------|---|
| Voltage supply | 200 to 230V/AC ± 10 single phase 0,4KW - 2,2KW. |
| Input frequency | 50 - 60 Hz. $\pm 5\%$ |
| Input power factor | > 0,98 (over fundamental frequency) |
| Momentary power loss | < 15 mS (continuous operation). > 15 mS (autoreset). |

OUTPUT

| | |
|---------------------------|--|
| Motor output voltage | 0 to input voltage |
| Current overload capacity | 150% during 60sec. 200% during 1 sec. |
| Frequency range | 0 to ± 400 Hz |
| Efficiency (full load) | > 98% |
| Modulation method | Vector space modulation |
| Modulation frequency | 15 kHz maximum |

ENVIRONMENT CONDITIONS

| | |
|-------------------------------|--|
| Degree of protection | IP20 |
| Operation temperature | -10°C to 50°C |
| Storage temperature | -20°C to +65°C |
| Relative humidity | < 90%, no condensation |
| Altitude | 1000m |
| Altitude loss factor (>1000m) | -1% per 100m; max. 3000m. |
| Vibration | Max. 5.9m/sec ² (0.6G) |
| Application site | Protected from corrosive gas, combustible gas, oil mist or dust. |


PROTECTIONS SD100

| | |
|-----------------|---|
| Drive trip | Over-voltage. Under-voltage. Over-current. Ground fault current detection. Over-temperature of inverter and motor. Output phase open. Overload. Communication error. Loss of frequency command. H / W fault. |
| Alarm condition | Stall prevention Overload |

CONTROL

| | |
|---------------------|--|
| Control method | V /Hz, Vector sensorless |
| Analogue inputs | 1 input 0 - 10Vcc and 1 input 0- 20mA. |
| Digital inputs | 5 multifunction inputs |
| Analogue outputs | 1 output 0 - 10V |
| Digital output | 1 multifunction output, open collector. |
| Relay output | 1 fault relay 2A 30Vdc 0.5A 125Vac |
| Communications port | RS485 and Modbus RTU protocol (as accessory) |
| Operation features | PID control, 3-wire, up-down operation. |
| Standards | CE, ISO9001and ISO14000 |

4. DIMENSIONS AND STANDARD RATINGS




DT0079A

| REFERENCE | STANDARD RATINGS | | | | DIMENSIONS | | | WEIGHT (Kg.) |
|-----------|------------------|------|-----|-------|------------|-----|-----|-----------------|
| | I (A) | kW | HP | V | W | H | D | |
| SD1103 | 3 | 0,4 | 0,5 | 230II | 79 | 143 | 143 | 0,87 |
| SD1103F | 3 | 0,4 | 0,5 | 230II | 79 | 143 | 143 | 0,95 |
| SD1105 | 5 | 0,75 | 1 | 230II | 79 | 143 | 143 | 0,89 |
| SD1105F | 5 | 0,75 | 1 | 230II | 79 | 143 | 143 | 0,97 |
| SD1108 | 8 | 1,5 | 2 | 230II | 156 | 143 | 143 | 1,79 |
| SD1108F | 8 | 1,5 | 2 | 230II | 156 | 143 | 143 | 1,94 |
| SD1112 | 12 | 2 | 3 | 230II | 156 | 143 | 143 | 1,85 |
| SD1112F | 12 | 2 | 3 | 230II | 156 | 143 | 143 | 2 |

5. PROGRAMMING KEYPAD

5.1 KEYPAD FEATURES



Display

- FWD/REV LED
- 7 Segment LED

Buttons

- RUN
- STOP/RST
- 4-Way Button
- Potentiometer

Display


| | | |
|----------------------------|--|----------------------------|
| FWD | Lit during forward run | Blinks when a fault occurs |
| REV | Lit during reverse run | |
| 7-Segment (LED Display) | Displays operation status and parameter information. | |

Keys

| | | |
|--------------|--|--|
| RUN | Used to give a run command | |
| STOP/RST | STOP: Stop the operation RST: Reset faults | |
| 4-Way button | Programming keys: (Up/Down/Left/Right arrow and Prog/Ent keys) | |
| ▲ | Up | Used to scroll through codes or increase parameter value |
| ▼ | Down | Used to scroll through codes or decrease parameter value |
| ◀ | Left | Used to jump to other parameter groups or move a cursor to the left to change the parameter |
| ▶ | Right | Used to jump to other parameter groups or move a cursor to the right to change the parameter |
| ● | Prog/Ent Key | Used to set the parameter value or save the changed parameter value |
| Poten. meter | Used to change the value of run frequency | |



5.2 PARAMETER GROUPS IN SD100

There are 4 different parameter groups in SD100 series as shown below.




| | |
|------------------|--|
| Drive group | Basic parameters necessary for the inverter to run. Parameters such as Target frequency, Accel/Decel time are settable |
| Function group 1 | Basic function parameters to adjust output frequency and voltage |
| Function group 2 | Advanced function parameters to set parameters for such as PID Operation and second motor operation |
| I / O Group | Parameters necessary to make up a sequence using Multi-function input/output terminal |

5.3 MOVING BETWEEN GROUPS




DT0100A

5.4 MOVING TO OTHER GROUPS FROM ANY CODES OTHER THAN THE FIRST CODE




5.5 PARAMETER SETTING METHOD

Changing parameter value in Drive group.




5.6 MONITORING OF OPERATION STATUS



| | | |
|---|-----|--|
| 1 | 0.0 | - In [0.0], continue pressing the Up (▲) or Down (▼) key until [Cur] is displayed |
| 2 | Cur | - Monitoring output current is provided in this parameter. - Press the Prog/Ent (●) key once to check the current |
| 3 | 5.0 | - Present output current is 5.0 A - Press the Prog/Ent (●) key once to return to the parameter name |
| 4 | Cur | - Return to the output current monitoring code |

Other parameters in Drive group such as dCL (Inverter DC link current) or vOL (Inverter output voltage) can be monitored via the same method


5.7 MONITORING OF MOTOR RPM.



| | | |
|---|------|---|
| 1 | 57.6 | - Present run frequency can be monitored in the first code of Function group 1. The preset frequency is 57.6Hz. - Continue pressing the Up (▲)/Down (▼) key until rPm is displayed |
| 2 | rPM | - Motor rpm can be monitored in this code. - Press the Prog/Ent (●) key once |
| 3 | 730 | - Last three digits 730 in 1730 rpm is shown on the LED. - Press the Left (◀) key once |
| 4 | 173 | - First three digits 173 in 1730 rpm are shown on the LED. - Press the Prog/Ent (●) key once |
| 5 | rPM | - Return to the rPM code |

5.8 PARAMETER INITIALIZE


How to initialize parameters of all four groups in H93



| | | |
|----|------|---|
| 1 | H 0 | - In H0, press the Prog/Ent (●) key once. |
| 2 | 1 | - Code number of H0 is displayed. - Increase the value to 3 by pressing the Up (▲) key |
| 3 | 3 | - In 3, press the Left (◀) key once to move the cursor to the left. |
| 4 | 03 | - 03 is displayed. 0 in 03 is active. - Increase the value to 9 by pressing the Up (▲) key |
| 5 | 93 | - 93 is set. - Press the Prog/Ent (●) key once |
| 6 | H 93 | - The parameter number is displayed. - Press the Prog/Ent (●) key once |
| 7 | 0 | - Present setting is 0. - Press the Up (▲) key once to set to 1 to activate parameter initialize |
| 8 | 1 | - Press the Prog/Ent (●) key once |
| 9 | H 93 | - Return to the parameter number after blinking. Parameter initialize has been complete. - Press the either Left (◀) or Right (▶) key |
| 10 | H 0 | - Return to H0. |

6. FAULT MESSAGES

6.1 MONITOR FAULTS



| | | |
|---|------|---|
| 1 | OCt | - This message appears when an Overcurrent fault occurs. - Press the Prog/Ent (●) key once |
| 2 | 30.0 | - The run frequency at the time of fault (30.0) is displayed. - Press the Up (▲) key once |
| 3 | 5.0 | - The output current at the time of fault is displayed. - Press the Up (▲) key once |
| 4 | ACC | - Operating status is displayed. A fault occurred during acceleration. - Press the STOP/RST key once |
| 5 | nOn | - A fault condition is cleared and "nOn" is displayed. |

6.2 FAULT DISPLAY AND INFORMATION

| Display | Fault | Description |
|---------|----------------------|---|
| Oct | Over current | The inverter turns off its output when the output current of the inverter flows more than 200% of the inverter rated current |
| Oft | Ground fault current | The inverter turns off its output when a ground fault occurs and the ground fault current is more than the internal setting value of the inverter |
| IOL | Inverter Overload | The inverter turns off its output when the output current of the inverter flows more than the rated level (150% for 1 minute) |
| OL t | Overload trip | The inverter turns off its output if the output current of the inverter flows at 150% of the inverter rated current for more than the current limit time (1 min). |

| Display | Fault | Description |
|---------|---|--|
| OH t | Heat sink overheat | The inverter turns off its output if the heat sink overheats due to a damaged cooling fan or an alien substance in the cooling fan by detecting the temperature of the heat sink. |
| COL | DC link capacitor overload | The inverter turns off its output when it is time to replace the old DC link capacitor to a new one. |
| Pot | Output Phase loss | The inverter turns off its output when the one or more of the output (U, V, W) phase is open. The inverter detects the output current to check the phase loss of the output. |
| Out | Over voltage | The inverter turns off its output if the DC voltage of the main circuit increases higher than 400 V when the motor decelerates. This fault can also occur due to a surge voltage generated at the power supply system. |
| Out | Low voltage | The inverter turns off its output if the DC voltage is below 200V because insufficient torque or overheating of the motor can occur when the input voltage of the inverter drops. |
| E t H | Electronic Thermal | The internal electronic thermal of the inverter determines the overheating of the motor. If the motor is overloaded the inverter turns off the output. The inverter cannot protect the motor when driving a motor having more than 4 poles or multi motors. |
| EEP | Parameter save error | This fault message is displayed when user-setting parameters fails to be entered into memory. |
| HWE | Inverter hardware fault | This fault message is displayed when an error occurs in the control circuitry of the inverter. |
| Err | Communication Error | This fault message is displayed when the inverter cannot communicate with the keypad. |
| FAn | Cooling fan fault | This fault message is displayed when a fault condition occurs in the inverter cooling fan. |
| ES t | Instant cut off | Used for the emergency stop of the inverter. The inverter instantly turns off the output when the EST terminal is turned on. Caution : The inverter starts to regular operation when turning off the BX terminal while FX or RX terminal is ON. |
| EtA | External fault A contact input | When multi-function input terminal (I20-I24) is set to 18 (External fault signal input : A (Normal Open Contact)), the inverter turns off the output. |
| EtB | External fault B contact input | When multi-function input terminal (I20-I24) is set to 18 (External fault signal input : B (Normal Close Contact)), the inverter turns off the output. |
| _ _ L | Operating method when the frequency command is lost | When inverter operation is set via Analog input (0-10V or 0-20mA input) or option (RS485) and no signal is applied, operation is done according to the method set in I62 (Operating method when the frequency reference is lost). |

7. FUNCTION LIST

7.1 DRIVE GROUP

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | | |
|-------------|----------------------------|---------------|--|---|-----------------------|---|---|
| 0.0 | Frequency command | 0/400 [Hz] | This parameter sets the frequency that the inverter is commanded to output. During Stop: Frequency Command During Run: Output Frequency During Multi-step operation: Multi-step frequency 0. It cannot be set greater than F21 - [Max frequency] | 0.0 | 0 | | |
| ACC | Accel time | 0/6000 [s] | During Multi-Accel/Decel operation, this parameter serves as Accel/Decel time 0 | 5.0 | 0 | | |
| dEC | Decel time | | | 10.0 | 0 | | |
| Drv | Drive mode (Run/Stop mode) | 0/3 | 0 | Run/Stop via Run/Stop key on the keypad | 1 | X | |
| | | | 1 | Run/Stop via control terminal | | | FX : Motor forward run RX : Motor reverse run |
| | | | 2 | Run/Stop via control terminal | | | FX : Run/Stop enable RX : Motor reverse rotation |
| | | | 3 | Operation via Communication Option | | | |
| Frq | Frequency mode | 0/8 | 0 | Digital | 0 | X | |
| | | | 1 | Digital | | | Setting via Keypad 1 |
| | | | 2 | Analog | | | Setting via potentiometer on the keypad (V0) |
| | | | 3 | | | | Setting via V1 terminal |
| | | | 4 | | | | Setting via I terminal |
| | | | 5 | | | | Setting via potentiometer on the keypad + I terminal |
| | | | 6 | | | | Setting via V1 + I terminal |
| | | | 7 | | | | Setting via potentiometer on the keypad + V1 terminal |
| 8 | Modbus-RTU Communication | | | | | | |
| St1 | Multi-Step frequency 1 | 0/400 [Hz] | This parameter sets Multi-Step frequency 1 during Multi-step operation | 10.0 | 0 | | |
| St2 | Multi-Step frequency 2 | | This parameter sets Multi-Step frequency 2 during Multi-step operation | 20.0 | 0 | | |
| St3 | Multi-Step frequency 3 | | This parameter sets Multi-Step frequency 3 during Multi-step operation | 30.0 | 0 | | |
| CUr | Output current | | This parameter displays the output current to the motor | - | - | | |
| rPM | Motor RPM | | This parameter displays the number of Motor RPM | - | - | | |
| dCL | Inverter DC link voltage | | This parameter displays DC link voltage inside the inverter | - | - | | |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | |
|-------------|------------------------------------|---------------|--|------------------|-----------------------|----------------|
| vOL | User display select | | This parameter displays the item selected at H73- [Monitoring item select] | vOL | - | |
| | | | vOl | | | Output voltage |
| | | | POr | | | Output power |
| | | | tOr | | | Torque |
| nOn | Fault Display | | This parameter displays the types of faults, frequency and operating status at the time of the fault | - | - | |
| drC | Direction of motor rotation select | F/r | This parameter sets the direction of motor rotation when drv - [Drive mode] is set to either 0 or 1. | F | O | |
| | | | F | | | Forward |
| | | | r | | | Reverse |

7.2 FUNCTION GROUP 1

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | |
|-------------|----------------------------------|---------------|---|------------------------|-----------------------|---|
| F 0 | Jump code | 0/60 | This parameter sets the parameter code number to jump | 1 | O | |
| F 1 | Forward/ Reverse run disable] | 0/2 | 0 | Fwd and rev run enable | 0 | X |
| | | | 1 | Forward run disable | | |
| | | | 2 | Reverse run disable | | |
| F 2 | Accel pattern | 0/1 | 0 | Linear | 0 | X |
| F 3 | Decel pattern | | 1 | S-curve | | |
| F 4 | Stop mode select | 0/2 | 0 | Decelerate to stop | 0 | X |
| | | | 1 | Stop via DC brake | | |
| | | | 2 | Free run to stop | | |
| F 8 | DC Brake start frequency | 0/60 [Hz] | This parameter sets DC brake start frequency. It cannot be set below F23 - [Start frequency]. | 5.0 | X | |
| F 9 | DC Brake wait time | 0/60 [s] | When DC brake frequency is reached, the inverter holds the output for the setting time before starting DC brake | 1.0 | X | |
| F10 | DCB rake voltage | 0/200 [%] | This parameter sets the amount of DC voltage applied to a motor. It is set in percent of H33 - [Motor rated current]. | 50 | X | |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|---------------------------------|---------------|--|------------------|-----------------------|
| F11 | DC Brake time | 0/60 [s] | This parameter sets the time taken to apply DC current to a motor while motor is at a stop. | 1.0 | X |
| F12 | DC Brake start voltage | 0/200 [%] | This parameter sets the amount of DC voltage before a motor starts to run. It is set in percent of H33 – [Motor rated current] | 50 | X |
| F13 | DC Brake start time | 0/60 [s] | DC voltage is applied to the motor for DC Brake start time before motor accelerates. | 0 | X |
| F14 | Time for magnetizing a motor | 0/60 [s] | This parameter applies the current to a motor for the set time before motor accelerates during Sensorless vector control. | 1.0 | X |
| F20 | Jog frequency | 0/400 [Hz] | This parameter sets the frequency for Jog operation. It cannot be set above F21 – [Max frequency]. | 10.0 | O |
| F21 | Max frequency | 40/400 * [Hz] | This parameter sets the highest frequency the inverter can output. It is frequency reference for Accel/Decel (See H70) If H40 is set to 3(Sensorless vector), it can be settable up to 300Hz * Caution : Any frequency cannot be set above Max frequency | 60.0 | X |
| F22 | Base frequency | 30/400 [Hz] | The inverter outputs its rated voltage to the motor at this frequency (see motor nameplate). In case of using a 50Hz motor, set this to 50Hz. | 60.0 | X |
| F23 | Start frequency | 0/10 [Hz] | The inverter starts to output its voltage at this frequency. It is the frequency low limit. | 0.5 | X |
| F24 | Frequency high/low limit select | 0/1 | This parameter sets high and low limit of run frequency. | 0 | X |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|-----------------------------------|---------------|---|------------------|-----------------------|
| F25 | Frequency high limit | 0/400 [Hz] | This parameter sets high limit of the run frequency. It cannot be set above F21 – [Max frequency]. | 60.0 | X |
| F26 | Frequency low limit | 0/400 [Hz] | This parameter sets low limit of the run frequency. It cannot be set above F25 - [Frequency high limit] and below F23 – [Start frequency]. | 0.5 | X |
| F27 | Torque Boost select | 0/1 | 0 Manual torque boost | 0 | X |
| | | | 1 Auto torque boost | | |
| F28 | Torque boost in forward direction | 0/15 [%] | This parameter sets the amount of torque boost applied to a motor during forward run. It is set in percent of Max output voltage. | 5 | X |
| F29 | Torque boost in reverse direction | 0/15 [%] | This parameter sets the amount of torque boost applied to a motor during reverse run. It is set as a percent of Max output voltage. | 5 | X |
| F30 | V/F pattern | 0/2 | 0 Linear | 0 | X |
| | | | 1 Square | | |
| | | | 2 User V/F | | |
| F31 | User V/F frequency 1 | 0/400 [Hz] | This parameter is active when F30 – [V/F pattern] is set to 2 (User V/F). It cannot be set above F21 – [Max frequency]. The value of voltage is set in percent of H70 – [Motor rated voltage]. The values of the lower-numbered parameters cannot be set above those of higher-numbered. | 15.0 | X |
| F32 | User V/F voltage 1 | 0/100 [%] | | 25 | X |
| F33 | User V/F frequency 2 | 0/400 [Hz] | | 30.0 | X |
| F34 | User V/F voltage 2 | 0/100 [%] | | 50 | X |
| F35 | User V/F frequency 3 | 0/400 [Hz] | | 45.0 | X |
| F36 | User V/F voltage 3 | 0/100 [%] | | 75 | X |
| F37 | User V/F frequency 4 | 0/400 [Hz] | | 60.0 | X |
| F38 | User V/F voltage 4 | 0/100 [%] | | 100 | X |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|---|---------------|--|------------------|-----------------------|
| F39 | Output voltage adjustment | 40/110 [%] | This parameter adjusts the amount of output voltage. The set value is the percentage of input voltage. | 100 | X |
| F40 | Energy-saving level | 0/30 [%] | This parameter decreases output voltage according to load status. | 0 | 0 |
| F50 | Electronic thermal select | 0/1 | This parameter is activated when the motor is overheated (time-inverse). | 0 | 0 |
| F51 | Electronic thermal level for 1 minute | 50/200 [%] | This parameter sets max current capable of flowing to the motor continuously for 1 minute. The set value is the percentage of H33 – [Motor rated current]. It cannot be set below F52 – [Electronic thermal level for continuous]. | 150 | 0 |
| F52 | Electronic thermal level for continuous | | This parameter sets the amount of current to keep the motor running continuously. It cannot be set higher than F51 – [Electronic thermal level for 1 minute]. | 100 | 0 |
| F53 | Motor cooling method | 0/1 | 0 Standard motor having cooling fan directly connected to the shaft | 0 | 0 |
| | | | 1 A motor using a separate motor to power a cooling fan | | |
| F54 | Overload warning level | 30/150 [%] | This parameter sets the amount of current to issue an alarm signal at a relay or multi-function output terminal (see I54, I55). The set value is the percentage of H33 - [Motor rated current]. | 150 | 0 |
| F55 | Overload warning time | 0/30 [s] | This parameter issues an alarm signal when the current greater than F54- [Overload warning level] flows to the motor for F55- [Overload warning time]. | 10 | 0 |
| F56 | Overload trip select | 0/1 | This parameter turns off the inverter output when motor is overloaded. | 1 | 0 |
| F57 | Overload trip level | 30/200 [%] | This parameter sets the amount of overload current. The value is the percentage of H33- [Motor rated current]. | 180 | 0 |
| F58 | Overload trip time | 0/60 [s] | This parameter turns off the inverter output when the F57- [Overload trip level] of current flows to the motor for F58- [Overload trip time]. | 60 | 0 |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | | |
|-------------|-------------------------|---------------|---|------------------|-----------------------|-----------------------|---------------------|
| F59 | Stall prevention select | 0/7 | This parameter stops accelerating during acceleration, decelerating during constant speed run and stops decelerating during deceleration. | 0 | X | | |
| | | | During Deceleration | | | During constant speed | During Acceleration |
| | | | Bit 2 | | | Bit 1 | Bit 0 |
| | | 0 | - | | | - | - |
| | | 1 | - | | | - | ✓ |
| | | 2 | - | | | ✓ | - |
| | | 3 | - | | | ✓ | ✓ |
| | | 4 | ✓ | | | - | - |
| | | 5 | ✓ | | | - | ✓ |
| 6 | ✓ | ✓ | - | | | | |
| 7 | ✓ | ✓ | ✓ | | | | |
| F60 | Stall prevention level | 30/150 [%] | This parameter sets the amount of current to activate stall prevention function during Accel, constant or Decel run. The set value is the percentage of the H33 - [Motor rated current]. | 150 | X | | |

7.3 FUNCTION GROUP 2

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|---------------------|---------------|---|------------------|-----------------------|
| H 0 | Jump code | 1/95 | This parameter sets the code number jump. | 1 | 0 |
| H 1 | Fault history 1 | - | This parameter stores information on the types of faults, the frequency, the current and the Accel/Decel condition at the time of fault. The last fault is automatically stored in the H 1 - [Fault history 1]. | nOn | - |
| H 2 | Fault history 2 | - | | nOn | - |
| H 3 | Fault history 3 | - | | nOn | - |
| H 4 | Fault history 4 | - | | nOn | - |
| H 5 | Fault history 5 | - | | nOn | - |
| H 6 | Reset fault history | 0/1 | This parameter clears the fault history saved in H 1-5. | 0 | 0 |
| H 7 | Dwell frequency | F23/400 [Hz] | When run frequency is issued, motor starts to accelerate after dwell frequency is applied to the motor during H8 - [Dwell time]. [Dwell frequency] can be set within the range of F21 - [Max frequency] and F23 - [Start frequency]. | 5.0 | X |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|-------------------------------------|---------------|--|------------------|-----------------------|
| H 8 | Dwell time | 0/10 [s] | This parameter sets the time for dwell operation. | 0.0 | X |
| H10 | Skip frequency select | 0/1 | This parameter sets the frequency range to skip to prevent undesirable resonance and vibration on the structure of the machine. | 0 | X |
| H11 | Skip frequency low limit 1 | 0/400 [Hz] | Run frequency cannot be set within the range of H11 thru H16. The frequency values of the low numbered parameters cannot be set above those of the high numbered ones. | 10.0 | X |
| H12 | Skip frequency high limit 1 | | | 15.0 | X |
| H13 | Skip frequency low limit 2 | | | 20.0 | X |
| H14 | Skip frequency high limit 2 | | | 25.0 | X |
| H15 | Skip frequency low limit 3 | | | 30.0 | X |
| H16 | Skip frequency high limit 3 | | | 35.0 | X |
| H17 | S-Curve accel/decel start side | 1/100 [%] | Set the speed reference value to form a curve at the start during accel/decel. If it is set higher, linear zone gets smaller. | 40 | X |
| H18 | S-Curve accel/decel end side | 1/100 [%] | Set the speed reference value to form a curve at the end during accel/decel. If it is set higher, linear zone gets smaller. | 40 | X |
| H19 | Output phase loss protection select | 0/1 | Inverter turns off the output when the phase of the inverter output (U, V, W) is not properly connected. | 0 | O |
| H20 | Power On Start select | 0/1 | This parameter is activated when drv is set to 1 or 2 (Run/Stop via Control terminal). Motor starts acceleration after AC power is applied while FX or RX terminal is ON. | 0 | O |
| H21 | Restart after fault reset | | This parameter is active when drv is set to 1 or 2 (Run/Stop via Control terminal). Motor accelerates after the fault condition is reset while the FX or RX terminal is ON. | | |

| LED display | Parameter name | Min/Max range | Description | | | | Factory defaults | Adjustable during run | |
|-------------|-----------------------------------|---------------|---|------------------------|--|-----------------------------------|------------------|-----------------------|------------------------|
| H22 | Speed Search Select | 0/15 | This parameter is active to prevent any possible fault when the inverter outputs its voltage to the running motor. | | | | 0 | 0 | |
| | | | | 1. H20- Power On start | 2. Restart after instant power failure | 3. Operation after fault occurred | | | 4. Normal acceleration |
| | | | | Bit 3 | Bit 2 | Bit 1 | | | Bit 0 |
| | | | 0 | - | - | - | | | - |
| | | | 1 | - | - | - | | | ✓ |
| | | | 2 | - | - | ✓ | | | - |
| | | | 3 | - | - | ✓ | | | ✓ |
| | | | 4 | - | ✓ | - | | | - |
| | | | 5 | - | ✓ | - | | | ✓ |
| | | | 6 | - | ✓ | ✓ | | | - |
| | | | 7 | - | ✓ | ✓ | | | ✓ |
| | | | 8 | ✓ | - | - | | | - |
| | | | 9 | ✓ | - | - | | | ✓ |
| | | | 10 | ✓ | - | ✓ | | | - |
| | | | 11 | ✓ | - | ✓ | | | ✓ |
| | | | 12 | ✓ | ✓ | - | | | - |
| 13 | ✓ | ✓ | - | ✓ | | | | | |
| 14 | ✓ | ✓ | ✓ | - | | | | | |
| 15 | ✓ | ✓ | ✓ | ✓ | | | | | |
| H23 | Current level during Speed search | 80/200 [%] | This parameter limits the amount of current during speed search. The set value is the percentage of the H33- [Motor rated current] | | | | 100 | 0 | |
| H24 | P gain during Speed search | 0/9999 | It is the Proportional gain used for Speed Search PI controller. | | | | 100 | 0 | |
| H25 | I gain during speed search | 0/9999 | It is the Integral gain used for Speed search PI controller. | | | | 1000 | 0 | |
| H26 | Number of Auto Restart try | 0/10 | This parameter sets the number of restart tries after a fault occurs. Auto Restart is deactivated if the fault outnumbers the restart tries. This function is active when [drv] is set to 1 or 2 (Run/Stop via control terminal). Deactivated during active protection function (OHT, LVT, EXT, HWT etc.) | | | | 0 | 0 | |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | |
|-------------|-----------------------|---------------|--|--|-----------------------|--|
| H27 | Auto Restart time | 0/60 [s] | This parameter sets the time between restart tries. | 1.0 | 0 | |
| H30 | Motor type select | 0.2/2.2 | 0.2 | 0.2 kW | 0.4 | X |
| | | | 0.4 | 0.4 kW | | |
| | | | 0.75 | 0.75 kW | | |
| | | | 1.5 | 1.5 kW | | |
| | | | 2.2 | 2.2 kW | | |
| H31 | Number of motor poles | 2/12 | This setting is displayed via rpm in drive group. | 4 | X | |
| H32 | Rated slip frequency | 0/10 [Hz] | $f_s = f_r - \left(\frac{rpm \times P}{120} \right)$ $f_s = \text{Rated slip frequency}$ $f_r = \text{Rated frequency}$ $rpm = \text{Motor nameplate RPM}$ $P = \text{Number of Motor poles}$ | 3.0 | X | |
| H33 | Motor rated current | 1.0/20 [A] | Enter motor rated current on the nameplate. | 1.8 | X | |
| H34 | No Load Motor Current | 0.1/12 [A] | Enter the current value detected when the motor is rotating in rated rpm after the load connected to the motor shaft is removed. Enter the 50% of the rated current value when it is difficult to measure H34 - [No Load Motor Current] | 0.9 | X | |
| H36 | Motor efficiency | 50/100 [%] | Enter the motor efficiency (see motor nameplate). | 72 | X | |
| H37 | Load inertia rate | 0/2 | Select one of the following according to motor inertia. | 0 | X | |
| | | | 0 | | | Less than 10 times that of motor inertia |
| | | | 1 | | | About 10 times that of motor inertia |
| | | | 2 | More than 10 times that of motor inertia | | |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run | |
|-------------|---|--------------------|---|---|-----------------------|---|
| H39 | Carrier frequency select | 1/15 [kHz] | This parameter affects the audible sound of the motor, noise emission from the inverter, inverter temp, and leakage current. If the value is set higher, the inverter sound is quieter but the noise from the inverter and leakage current will become greater. | 3 | O | |
| H40 | Control mode select | 0/3 | 0 | (Volts/frequency Control) | 0 | X |
| | | | 1 | (Slip compensation control) | | |
| | | | 2 | (PID Feedback control) | | |
| | | | 3 | (Sensorless vector control) | | |
| H41 | Auto tuning | 0/1 | If this parameter is set to 1, it automatically measures parameters of the H42 and H43. | 0 | X | |
| H42 | [Stator resistance (Rs)] | 0/5.0 [Ω] | This is the value of the motor stator resistance. | - | X | |
| H44 | [Leakage inductance (σ)] | 0/300.0 [mH] | This is leakage inductance of the stator and rotor of the motor. | - | X | |
| H45 | Sensorless P gain | 0/32767 | P gain for Sensorless control | 1000 | O | |
| H46 | Sensorless I gain | | I gain for Sensorless control | 100 | O | |
| H50 | PID Feedback select | 0/1 | 0 | Terminal I input (0 ~ 20 mA) | 0 | X |
| | | | 1 | Terminal V1 input (0 ~ 10 V) | | |
| H51 | [P gain for PID controller] | 0/999.9 [%] | This parameter sets the gains for the PID controller. | 300.0 | O | |
| H52 | [Integral time for PID controller (I gain)] | 0.1/32.0 [sec] | | 1.0 | O | |
| H53 | Differential time for PID controller (D gain) | 0.0/30.0 [sec] | | 0.0 | O | |
| H54 | F gain for PID controller | 0/999.9 [%] | | This is the Feed forward gain for the PID controller. | 0.0 | O |

| LED display | Parameter name | Min/Max range | Description | | Factory defaults | Adjustable during run |
|-------------|-------------------------------------|---------------|---|---|------------------|-----------------------|
| H70 | Frequency Reference for Accel/Decel | 0/1 | 0 | The Accel/Decel time is the time that takes to reach the F21 – [Max frequency] from 0 Hz. | 0 | X |
| | | | 1 | The Accel/Decel time is the time that takes to reach a target frequency from the run frequency. | | |
| H71 | Accel/Decel time scale | 0/2 | 0 | Settable unit: 0.01 second. | 1 | 0 |
| | | | 1 | Settable unit: 0.1 second. | | |
| | | | 2 | Settable unit: 1 second. | | |
| H72 | Power on display | 0/13 | This parameter selects the parameter to be displayed on the keypad when the input power is first applied. | | 0 | 0 |
| | | | 0 | Frequency command | | |
| | | | 1 | Accel time | | |
| | | | 2 | Decel time | | |
| | | | 3 | Drive mode | | |
| | | | 4 | Frequency mode | | |
| | | | 5 | Multi-Step frequency 1 | | |
| | | | 6 | Multi-Step frequency 2 | | |
| | | | 7 | Multi-Step frequency 3 | | |
| | | | 8 | Output current | | |
| | | | 9 | Motor rpm | | |
| | | | 10 | Inverter DC link voltage | | |
| | | | 11 | User display select | | |
| | | | 12 | Fault display | | |
| 13 | Direction of motor rotation select | | | | | |
| H73 | Monitoring item select | 0/2 | One of the following can be monitored via v(O) – [User display select] | | 0 | 0 |
| | | | 0 | Output voltage [V] | | |
| | | | 1 | Output power [kW] | | |
| | | | 2 | Torque [kgf·m] | | |
| H74 | Gain for Motor rpm display | 1/1000 [%] | $RPM = \left(\frac{120 \times f}{H31} \right) \times \frac{H74}{100}$ This parameter is used to change the motor speed display to rotating speed (r/min) or mechanical speed (m/mi). | | | |
| H79 | Software version | 0/10.0 | This parameter displays the inverter software version. | | 1.0 | X |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|--|---|---------------|--|------------------|-----------------------|
| H81 | Software version | 0/6000 [s] | This parameter is active when the selected terminal is ON after I20-I24 is set to 12 {2 nd motor select}. | 5.0 | O |
| H82 | 2 nd motor Accel time | | | 10.0 | O |
| H83 | 2 nd motor Decel time | 30/400 [Hz] | | 60.0 | X |
| H84 | 2 nd motor base frequency | 0/2 | | 0 | X |
| H85 | 2 nd motor V/F pattern | 0/15 [%] | | 5 | X |
| H86 | 2 nd motor forward torque boost | | | 5 | X |
| H87 | 2 nd motor reverse torque boost | 30/150 [%] | | 150 | X |
| H88 | 2 nd motor stal prevention level | 50/200 [%] | | 150 | O |
| H89 | 2 nd motor Electronic thermal level for 1 min | | | 100 | O |
| H90 | 2 nd motor Electronic thermal level for continuous | 0.1/20 [A] | | 1.8 | X |
| H93 | Parameter initialize | 0/5 | This parameter is used to initialize parameters back to the factory default values. | 0 | X |
| | | | 0 | | |
| | | | 1 All parameter groups are initialized to factory default value | | |
| | | | 2 Only Drive group is initialized | | |
| | | | 3 Only Function group 1 is initialized | | |
| 4 Only Function group 2 is initialized | | | | | |
| H94 | Password register | 0/FFF | Password for H95-[Parameter lock]. | 0 | O |
| H95 | Parameter lock | 0/FFF | This parameter is able to lock or unlock parameters by typing password registered in H94 | 0 | O |
| | | | U (Unlock) Parameter change enable | | |
| | | | L (Lock) Parameter change disable | | |

7.4 I / O GROUP

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|-----------------------------------|---------------|--|------------------|-----------------------|
| I 0 | Jump code | 0/63 | This parameter sets the code number to jump | 1 | 0 |
| I 1 | Filter time constant for V0 input | 0/9999 | This is used to adjust the analog voltage input signal via keypad potentiometer. | 10 | 0 |
| I 2 | V0 input Min voltage | 0/10 [V] | Set the minimum voltage of the V0 input. | 0 | 0 |
| I 3 | Frequency corresponding to I 2 | 0/400 [Hz] | Set the inverter output minimum frequency at minimum voltage of the V0 input. | 0.0 | 0 |
| I 4 | V0 input Max voltage | 0/10 [V] | Set the maximum voltage of the V0 input. | 10 | 0 |
| I 5 | Frequency corresponding to I 4 | 0/400 [Hz] | Set the inverter output maximum frequency at maximum voltage of the V0 input | 60.0 | 0 |
| I 6 | Filter time constant for V1 input | 0/9999 | Set the input section's internal filter constant for V1 input. | 10 | 0 |
| I 7 | V1 input Min voltage | 0/10 [V] | Set the minimum voltage of the V1 input. | 0 | 0 |
| I 8 | Frequency corresponding to I 7 | 0/400 [Hz] | Set the inverter output minimum frequency at minimum voltage of the V1 input. | 0.0 | 0 |
| I 9 | V1 input max voltage | 0/10 [V] | Set the maximum voltage of the V1 input. | 10 | 0 |
| I 10 | Frequency corresponding to I 9 | 0/400 [Hz] | Set the inverter output maximum frequency at maximum voltage of the V1 input | 60.0 | 0 |
| I 11 | Filter time constant for I input | 0/9999 | Set the input section's internal filter constant for I input. | 10 | 0 |
| I 12 | I input minimum current | 0/20 [mA] | Set the Minimum Current of I input. | 4 | 0 |
| I 13 | Frequency corresponding to I 12 | 0/400 [Hz] | Set the inverter output minimum frequency at minimum current of I input. | 0.0 | 0 |
| I 14 | I input max current | 0/20 [mA] | Set the Maximum Current of I input. | 20 | 0 |
| I 15 | Frequency corresponding to I 14 | 0/400 [Hz] | Set the inverter output maximum frequency at maximum current of I input. | 60.0 | 0 |

| LED display | Parameter name | Min/Max range | Description | | | | | Factory defaults | Adjustable during run | | |
|-------------|---|---------------|-------------|--|-----------------------------------|------|------|------------------|-----------------------|---|--|
| I16 | Criteria for Analog Input Signal loss | 0/2 | 0 | Disabled | | | | | 0 | 0 | |
| | | | 1 | Less than half the value set in I 2/7/12 entered | | | | | | | |
| | | | 2 | Below the value set in I 2/7/12 entered | | | | | | | |
| I20 | Multi-function input terminal P1 define | | 0 | Forward run command {FX} | | | | | 0 | 0 | |
| | | | 1 | Reverse run command {RX} | | | | | | | |
| I21 | Multi-function input terminal P2 define | | 2 | Emergency Stop Trip {EST} | | | | | 1 | 0 | |
| | | | 3 | Reset when a fault occurs {RST} | | | | | | | |
| I22 | Multi-function input terminal P3 define | | 4 | Log operation command {LOG} | | | | | 2 | 0 | |
| | | | 5 | Multi-Step frequency – Low | | | | | | | |
| I23 | Multi-function input terminal P4 define | | 6 | Multi-Step frequency – Mid | | | | | 3 | 0 | |
| | | | 7 | Multi-Step frequency – High | | | | | | | |
| I24 | Multi-function input terminal P5 define | 0/24 | 8 | Multi Accel/Decel – Low | | | | | 4 | 0 | |
| | | | 9 | Multi Accel/Decel – Mid | | | | | | | |
| | | | 10 | Multi Accel/Decel – High | | | | | | | |
| | | | 11 | DC brake during stop | | | | | | | |
| | | | 12 | 2 nd motor select | | | | | | | |
| | | | 13 | - | | | | | | | |
| | | | 14 | - | | | | | | | |
| | | | 15 | Up-down operation | Frequency increase command (UP) | | | | | | |
| | | | 16 | | Frequency decrease command (DOWN) | | | | | | |
| | | | 17 | 3-wire operation | | | | | | | |
| | | | 18 | External trip: A Contact (EtA) | | | | | | | |
| | | | 19 | External trip: B Contact (EtB) | | | | | | | |
| | | | 20 | - | | | | | | | |
| | | | 21 | Exchange between PID operation and V/F operation | | | | | | | |
| 22 | Exchange between option and Inverter | | | | | | | | | | |
| 23 | Analog Hold | | | | | | | | | | |
| 24 | Accel/Decel Disable | | | | | | | | | | |
| I25 | Input terminal status display | | BIT4 | BIT3 | BIT2 | BIT1 | BIT0 | - | - | | |
| | | | P5 | P4 | P3 | P2 | P1 | | | | |
| I26 | Output terminal status display | | | | | BIT1 | BIT0 | | | | |
| | | | | | | 30AC | MO | | | | |

| LED display | Parameter name | Min/Max range | Description | Factory defaults | Adjustable during run |
|-------------|---|---------------|---|------------------|-----------------------|
| I27 | Filtering time constant for Multi-function Input terminal | 2/50 | If the value is set higher, the response of the Input terminal is getting slower. | 15 | 0 |
| I30 | Multi-Step frequency 4 | 0/400 [Hz] | It cannot be set greater than F21 – [Max frequency]. | 30.0 | 0 |
| I31 | Multi-Step frequency 5 | | | 25.0 | 0 |
| I32 | Multi-Step frequency 6 | | | 20.0 | 0 |
| I33 | Multi-Step frequency 7 | | | 15.0 | 0 |
| I34 | Multi-Accel time 1 | 0/6000 [s] | | 3.0 | 0 |
| I35 | Multi-Decel time 1 | | | 3.0 | |
| I36 | Multi-Accel time 2 | | | 4.0 | |
| I37 | Multi-Decel time 2 | | | 4.0 | |
| I38 | Multi-Accel time 3 | | | 5.0 | |
| I39 | Multi-Decel time 3 | | | 5.0 | |
| I40 | Multi-Accel time 4 | | | 6.0 | |
| I41 | Multi-Decel time 4 | | | 6.0 | |
| I42 | Multi-Accel time 5 | | | 7.0 | |
| I43 | Multi-Decel time 5 | | | 7.0 | |
| I44 | Multi-Accel time 6 | | | 8.0 | |
| I45 | Multi-Decel time 6 | | | 8.0 | |
| I46 | Multi-Accel time 7 | | | 9.0 | |
| I47 | Multi-Decel time 7 | | | 9.0 | |

| LED display | Parameter name | Min/Max range | Description | | | Factory defaults | Adjustable during run |
|-------------|---------------------------------------|---------------|--|------------------------------------|---------------|------------------|-----------------------|
| I50 | Analog output item select | 0/3 | 10[V] Output | | | 0 | 0 |
| | | | 0 | Max frequency | Max frequency | | |
| | | | 1 | 150 % | 150 % | | |
| | | | 2 | 282 V | 282 V | | |
| | | | 3 | DC400V | 400V/DC | | |
| I51 | Analog output level adjustment | 10/200 [%] | | | | 100 | 0 |
| I52 | Frequency detection level | 0/400 [Hz] | · This parameter is used when I54 – [Multi-function output terminal select] or I55 – [Multi-function relay select] are set to 0-4. | | | 30.0 | 0 |
| I53 | Frequency detection bandwidth | | · It cannot be set greater than F21 – [Max frequency]. | | | 10.0 | 0 |
| I54 | Multi-function output terminal select | 0/17 | 0 | FDT-1 | | 12 | |
| | | | 1 | FDT-2 | | | |
| I55 | Multi-function relay select | 0/17 | 2 | FDT-3 | | 17 | |
| | | | 3 | FDT-4 | | | |
| | | | 4 | FDT-5 | | | |
| | | | 5 | Overload (OL) | | | |
| | | | 6 | Inverter Overbad (IOI) | | | |
| | | | 7 | Motor stall (STALL) | | | |
| | | | 8 | Over voltage trip (OV) | | | |
| | | | 9 | Low voltage trip (LV) | | | |
| | | | 10 | Inverter cooling fan overheat (OH) | | | |
| | | | 11 | Command loss | | | |
| | | | 12 | During run | | | |
| | | | 13 | During stop | | | |
| | | | 14 | During constant run | | | |
| | | | 15 | During speed searching | | | |
| | | | 16 | Wait time for run signal input | | | |
| | | | 17 | Fault relay output | | | |
| | | | I56 | Fault relay output | 0/7 | | |
| | Bit 2 | Bit 1 | | | | Bit 0 | |
| 0 | - | - | | | | - | |
| 1 | - | - | | | | ✓ | |
| | | | 2 | - | ✓ | - | |


| LED display | Parameter name | Min/Max range | Description | | | | Factory defaults | Adjustable during run |
|-------------|---|---------------|---|-------------------------------|---|---|------------------|-----------------------|
| I56 | Fault relay output | 0/7 | 3 | - | ✓ | ✓ | 2 | 0 |
| | | | 4 | ✓ | - | - | | |
| | | | 5 | ✓ | - | ✓ | | |
| | | | 6 | ✓ | ✓ | - | | |
| | | | 7 | ✓ | ✓ | ✓ | | |
| I60 | Inverter station number | 1/32 | This parameter is set when the inverter uses RS485 communication option. | | | | 1 | 0 |
| I61 | Baud rate | 0/4 | Select the Baud rate of the RS485 | | | | 3 | 0 |
| | | | 0 | 1200 bps | | | | |
| | | | 1 | 2400 bps | | | | |
| | | | 2 | 4800 bps | | | | |
| | | | 3 | 9600 bps | | | | |
| I62 | Drive mode select after loss of frequency command | 0/2 | It is used when frequency command is given via V1 and I terminal or communication option | | | | 0 | 0 |
| | | | 0 | Continuous operation | | | | |
| | | | 1 | Free Run stop (Coast to stop) | | | | |
| | | | 2 | Decel to stop | | | | |
| I63 | Wait time after loss of frequency command | 0.1/12 [sec] | This is the time inverter determines whether there is the input frequency command or not. If there is no frequency command input during this time, inverter starts operation via the mode selected at I62 | | | | 1.0 | - |

8. BASIC OPERATION


Caution : The following instructions are given based on the fact that all parameters are set to factory defaults. Results could be different if parameter values are changed. In this case, initialize parameter values (see page 10-17) back to factory defaults and follow the instructions below.

8.1 FREQUENCY SETTING VIA KEYPAD & OPERATING VIA TERMINALS.

| | | |
|---|-------|--|
| 1 | 0.0 | - Apply AC input power to the inverter. |
| 2 | 0.0 | - When 0.0 appears, press the Prog/Ent (●) key once. |
| 3 | 00.0 | - The second digit in 0.0 is lit as shown left. - Press the Left (◀) key twice. |
| 4 | 10.0 | - 00.0 is displayed and the first 0 is lit. - Press the Up (▲) key. |
| 5 | 10.0 | - 10.0 is set. Press the Prog/Ent (●) key once. - 10.0 is blinking. Press the Prog/Ent (●) key once. |
| 6 | :10.0 | - Run frequency is set to 10.0 Hz when the blinking stops. - Turn on the switch between P1 (FX) and CM terminals. |
| 7 | :10.0 | - FWD (Forward run) lamp begins to blink and accelerating frequency is displayed on the LED. - When target run frequency 10Hz is reached, 10.0 is displayed. - Turn off the switch between P1 (FX) and CM terminals. |
| 8 | 0.0 | - FWD lamp begins to blink and decelerating frequency is displayed on the LED. - When run frequency is reached to 0Hz, FWD lamp is turned off and 10.0 is displayed. |




Wiring




Operating pattern

8.2 FREQUENCY SETTING VIA POTENTIOMETER & OPERATING VIA TERMINALS .

| | | |
|---|--------|---|
| 1 | | - Apply AC input power to the inverter. |
| 2 | 0.0 | - When 0.0 appears Press the Up (▲) key four times. |
| 3 | Frq | - Frq is displayed. Frequency setting mode is selectable. - Press the Prog/Ent (●) key once. |
| 4 | 0 | - Present setting method is set to 0 (frequency setting via keypad). - Press the Up (▲) key twice. |
| 5 | 2 | - After 2 (Frequency setting via potentiometer) is set, press the Prog/Ent (●) key once. |
| 6 | Frq | - Frq is redisplayed after 2 stops blinking. - Turn the potentiometer to set to 10.0 Hz in either Max or Min direction. |
| 7 | : 10.0 | - Turn on the switch between P1 (FX) and CM (See Wiring below). - FWD lamp begins to blink and the accelerating frequency is displayed on the LED. - When run frequency 10Hz is reached, the value is displayed as shown left. - Turn off the switch between P1 (FX) and CM terminals. |
| 8 | : 10.0 | - FWD lamp begins to blink and the decelerating frequency is displayed on the LED. - When the run frequency is reached to 0 Hz, FWD lamp is turned off and 10.0 is displayed as shown left. |





Wiring



Operating pattern

8.3 FREQUENCY SETTING VIA POTENTIOMETER & OPERATING VIA THE RUN KEY.


| | | |
|--|-------|---|
| 1 | | - Apply AC input power to the inverter. |
| 2 | 0.0 | - When 0.0 is displayed, press the Up (▲) key three times. |
| 3 | Drv | - drv is displayed. Operating method is selectable. - Press the Prog/Ent (●) key. |
| 4 | 1 | - Check the present operating method ("1" is run via control terminal) - Press the Prog/Ent (●) key and then Down (▼) key once. |
| 5 | 0 | - After setting "0", press the Prog/Ent (●) key. |
| 6 | Drv | - "drv" is displayed after "0" is blinking. Operation method is set via the Run key on the keypad. - Press the Up (▲) key once. |
| 7 | Frq | - Different frequency setting method is selectable in this code. - Press the Prog/Ent (●) key. |
| 8 | 0 | - Check the present frequency setting method ("0" is run via keypad). - Press the Up (▲) key twice. |
| 9 | 2 | - After checking "2" (frequency setting via potentiometer), press the Prog/Ent (●) key. |
| 10 | Frq | - "Frq" is displayed after "2" is blinking. Frequency setting is set via the potentiometer on the keypad. - Turn the potentiometer to set to 10.0 Hz in either Max or Min direction. |
| 11 | :10.0 | - Press the Run key on the keypad. - FWD lamp begins to blink and accelerating frequency is displayed on the LED. - When run frequency 10Hz is reached, 10.0 is displayed as shown left. - Press the STOP/RST key. |
| 12 | :10.0 | - FWD lamp begins to blink and decelerating frequency is displayed on the LED. - When run frequency is reached to 0Hz, FWD lamp is turned off and 10.0 is displayed as shown left. |
|  | |  |
| Wiring | | Operating pattern |

8.4 MULTI-SPEED CONTROL VIA TERMINALS P3, P4, P5.

| Screen | Description | Setting | |
|--------|----------------------------|--------------------------|------------------------------------|
| 00.0 | Frequency command | 50Hz | |
| acc | Accel time | 10s | |
| dec | Decel time | 10s | |
| drv | Drive mode (Run/stop mode) | 0 | Run/Stop via equipad |
| | | 1 | Run stop via terminal RX_EX |
| | | 2 | Operation via communication option |
| Frq | Frequency mode | 0 | Setting via keypad 1 |
| ST 1 | Multi-step frequency 1 | 30 Hz (Multivelocidad 1) | |
| ST 2 | Multi-step frequency 2 | 35 Hz (Multivelocidad 2) | |
| ST 3 | Multi-step frequency 3 | 40 Hz (Multivelocidad 3) | |
| F 21 | Max frequency | 50 Hz | Velocidad límite del equipo. |
| F 22 | Base frequency | 50 Hz | |
| F 23 | Start frequency | 0.1 Hz | Velocidad mínima en el arranque |
| H 30 | Motor type select | 0.4 | 0.37Kw |
| | | 0.8 | 0.75Kw |
| | | 1.5 | 1.50Kw |
| | | 2.2 | 2.2Kw |
| | | 3.7 | 3.7Kw |
| H 33 | Motor rated current | 1.0/20A | |
| I 20 | Terminal P1 configuration | Configurables | |
| I 21 | Terminal P2 configuration | Configurables | |
| I 22 | Terminal P3 configuration | 5 – Speed – L | |
| I 23 | Terminal P4 configuration | 6 – Speed – M | |
| I 24 | Terminal P5 configuration | 7 – Speed – H | |
| I 30 | Multi-Step frequency 4 | 42 Hz | |
| I 31 | Multi-Step frequency 5 | 43 Hz | |
| I 32 | Multi-Step frequency 6 | 44 Hz | |
| I 33 | Multi-Step frequency 7 | 45 Hz | |

Depending P3, P4, P5 digital input status the following preset different frequencies can be selected:

| Screen | Preset frequency | Fx / Rx | P5 | P4 | P3 |
|--------|------------------|---------|----|----|----|
| 0.00 | 50Hz | 1 | 0 | 0 | 0 |
| St1 | 30Hz | 1 | 0 | 0 | 1 |
| St2 | 35Hz | 1 | 0 | 1 | 0 |
| St3 | 40Hz | 1 | 0 | 1 | 1 |
| L30 | 45Hz | 1 | 1 | 0 | 0 |
| L31 | 50Hz | 1 | 1 | 0 | 1 |
| L32 | 47Hz | 1 | 1 | 1 | 0 |
| L33 | 42Hz | 1 | 1 | 1 | 1 |




Multi-speed control wiring configuration.

8.5 PID FOR PRESSURE CONTROL CONFIGURATION.

| Screen | Description | Setting | |
|--------|--------------------------------------|---------|------------------------------------|
| 00.0 | Frequency command | 50Hz | |
| ACC | Accel time | 10s | |
| DEC | Decel time | 10s | |
| DRV | Drive mode (Run/stop mode) | 0 | Run/Stop via equipad |
| | | 1 | Run stop via terminal BX_EX |
| | | 2 | Operation via communication option |
| FRQ | Frequency mode | 0 | Setting via keypad 1 |
| | | 8 | Modbus-RTU communication |
| F 21 | Max frequency | 50 Hz | |
| F 22 | Base frequency | 50 Hz | |
| F 23 | Start frequency | 0.1 Hz | |
| F 24 | Frequency high/low limit select | 0 | NO (Limits are set by F21 and F23) |
| | | 1 | YES (Limits are set by F25 and 26) |
| F 25 | Erquency high limit | 0Hz | |
| F 26 | Frequency low limit | 50Hz | |
| H 30 | Motor type select | 0.2 | 0.2Kw |
| | | 0.4 | 0.4Kw |
| | | 0.75 | 0.75Kw |
| | | 1.5 | 1.5Kw |
| | | 2.2 | 2.2Kw |
| H 33 | Motor rated current | A | |
| H 40 | Control mode select | 2 | PID feedback control |
| H 50 | PID feedback select | 0 | Terminal input I (0-20mA) |
| | | 1 | Terminal input V1 (0-10V) |
| H 51 | P gain for PID controller | 300.0 | |
| H 52 | Integral time for PID controller | 1.0 | |
| H 53 | Differential time for PID controller | 0 | |
| H 79 | Software version | 1.3 | |
| I 6 | Filter time constant for V1 input | 10ms | |
| I 7 | V1 input Min voltage | 0.00V | |
| I 8 | Frequency corresponding to I7 | 0Hz | |
| I 9 | V1 input Max voltage | 10.0V | |
| I 10 | Frequency corresponding to I9 | 50Hz | |
| I 11 | Filter time constant for I input | 10ms | |
| I 12 | I input minimum current | 0mA | |
| I 13 | Frequency corresponding to I12 | 0Hz | |
| I 14 | I input max current | 20.0mA | |
| I 15 | Frequency corresponding to I14 | 50Hz | |

NOTE: Maximum and minimum frequency limits are set in screen F21(max frequency) and F23 (Start frequency).

NOTE: SD100 do not have 12-30Vdc power supply. External power supply must be required.



PID for pressure control wiring configuration.



www.power-electronics.com